



Q10,11- to avoid clock feed through and charge injection.

Q12,13 – To avoid current mismatch

Q6,8 - To keep Q4,5 out of subthreshold region.

Red box is charge pump. If you want to get into details refer to jacob baker 1st edition.