

Liberty Reference Manual

Version 2009.06

1. Technology Library Group Description and Syntax

[1.1 Library-Level Attributes and Values](#)

[1.2 General Syntax](#)

[1.3 Reducing Library File Size](#)

[1.4 library Group Name](#)

[1.4.1 Syntax](#)

[1.4.2 Example](#)

[1.5 library Group Example](#)

[1.6 Simple Attributes](#)

[1.6.1 bus_naming_style Simple Attribute](#)

[1.6.2 comment Simple Attribute](#)

[1.6.3 current_unit Simple Attribute](#)

[1.6.4 date Simple Attribute](#)

[1.6.5 default_fpga_isd Simple Attribute](#)

[1.6.6 default_threshold_voltage_group Simple Attribute](#)

[1.6.7 delay_model Simple Attribute](#)

[1.6.8 distance_unit and dist_conversion_factor Attributes](#)

[1.6.9 critical_area_lut_template Group](#)

[1.6.10 device_layer, poly_layer, routing_layer, and cont_layer Groups](#)

[1.6.11 em_temp_degradation_factor Simple Attribute](#)

[1.6.12 fpga_domain_style Simple Attribute](#)

[1.6.13 fpga_technology Simple Attribute](#)

[1.6.14 in_place_swap_mode Simple Attribute](#)

[1.6.15 input_threshold_pct_fall Simple Attribute](#)

[1.6.16 input_threshold_pct_rise Simple Attribute](#)

[1.6.17 leakage_power_unit Simple Attribute](#)

[1.6.18 nom_calc_mode Simple Attribute](#)

[1.6.19 nom_process Simple Attribute](#)

[1.6.20 nom_temperature Simple Attribute](#)

[1.6.21 nom_voltage Simple Attribute](#)

[1.6.22 output_threshold_pct_fall Simple Attribute](#)

[1.6.23 output_threshold_pct_rise Simple Attribute](#)

[1.6.24 piece_type Simple Attribute](#)

[1.6.25 power_model Simple Attribute](#)

[1.6.26 preferred_output_pad_slew_rate_control Simple Attribute](#)

[1.6.27 preferred_input_pad_voltage Simple Attribute](#)

[1.6.28 preferred_output_pad_voltage Simple Attribute](#)

[1.6.29 pulling_resistance_unit Simple Attribute](#)

[1.6.30 revision Simple Attribute](#)

[1.6.31 simulation Simple Attribute](#)

[1.6.32 slew_derate_from_library Simple Attribute](#)

[1.6.33 slew_lower_threshold_pct_fall Simple Attribute](#)

[1.6.34 slew_lower_threshold_pct_rise Simple Attribute](#)

[1.6.35 slew_upper_threshold_pct_fall Simple Attribute](#)

[1.6.36 slew_upper_threshold_pct_rise Simple Attribute](#)

[1.6.37 time_unit Simple Attribute](#)

[1.6.38 voltage_unit Simple Attribute](#)

[1.7 Defining Default Attribute Values in a CMOS Technology Library](#)

[1.8 Complex Attributes](#)

[1.8.1 capacitive_load_unit Complex Attribute](#)

[1.8.2 default_part Complex Attribute](#)

[1.8.3 define Complex Attribute](#)

[1.8.4 define_cell_area Complex Attribute](#)

[1.8.5 define_group Complex Attribute](#)

[1.8.6 library_features Complex Attribute](#)

[1.8.7 piece_define Complex Attribute](#)

[1.8.8 routing_layers Complex Attribute](#)
[1.8.9 technology Complex Attribute](#)
[1.8.10 voltage_map Complex Attribute](#)

1.9 Group Statements

[1.9.1 base_curves Group](#)
[1.9.2 base_curve_type Complex Attribute](#)
[1.9.3 curve_x Complex Attribute](#)
[1.9.4 curve_y Complex Attribute](#)
[1.9.5 compact_lut_template Group](#)
[1.9.6 base_curves_group Simple Attribute](#)
[1.9.7 variable_1 and variable_2 Simple Attributes](#)
[1.9.8 variable_3 Simple Attribute](#)
[1.9.9 index_1 and index_2 Complex Attributes](#)
[1.9.10 index_3 Complex Attribute](#)
[1.9.11 dc_current_template Group](#)
[1.9.12 em_lut_template Group](#)
[1.9.13 fall_net_delay Group](#)
[1.9.14 fall_transition_degradation Group](#)
[1.9.15 faults_lut_template](#)
[1.9.16 input_voltage Group](#)
[1.9.17 fpga_isd Group](#)
[1.9.18 iv_lut_template Group](#)
[1.9.19 lu_table_template Group](#)
[1.9.20 maxcap_lut_template Group](#)
[1.9.21 maxtrans_lut_template Group](#)
[1.9.22 noise_lut_template Group](#)
[1.9.23 normalized_driver_waveform Group](#)
[1.9.24 operating_conditions Group](#)
[1.9.25 output_current_template Group](#)
[1.9.26 output_voltage Group](#)
[1.9.27 part Group](#)
[1.9.28 pg_current_template Group](#)
[1.9.29 poly_template Group](#)
[1.9.30 power_lut_template Group](#)
[1.9.31 power_poly_template Group](#)
[1.9.32 power_supply Group](#)
[1.9.33 propagation_lut_template Group](#)
[1.9.34 rise_net_delay Group](#)
[1.9.35 rise_transition_degradation Group](#)
[1.9.36 scaled_cell Group](#)
[1.9.37 sensitization Group](#)
[1.9.38 pin_names Complex Attribute](#)
[1.9.39 vector Complex Attribute](#)
[1.9.40 scaling_factors Group](#)
[1.9.41 timing Group](#)
[1.9.42 timing_range Group](#)
[1.9.43 type Group](#)
[1.9.44 user_parameters Group](#)
[1.9.45 wire_load Group](#)
[1.9.46 wire_load_selection Group](#)
[1.9.47 wire_load_table Group](#)

2. cell and model Group Description and Syntax

2.1 cell Group

[2.1.1 Attributes and Values](#)
[2.1.2 Simple Attributes](#)
[2.1.3 Complex Attributes](#)
[2.1.4 Group Statements](#)

2.2 model Group

[2.2.1 Attributes and Values](#)

3. pin Group Description and Syntax

3.1 Syntax of a pin Group in a cell or bus Group

[3.1.1 pin Group Example](#)

- [3.1.2 Simple Attributes](#)
- [3.1.3 Complex Attributes](#)

3.2 Group Statements

- [3.2.1 ccsn_first_stage Group](#)
- [3.2.2 ccsn_last_stage Group](#)
- [3.2.3 electromigration Group](#)
- [3.2.4 hyperbolic_noise_above_high Group](#)
- [3.2.5 hyperbolic_noise_below_low Group](#)
- [3.2.6 hyperbolic_noise_high Group](#)
- [3.2.7 hyperbolic_noise_low Group](#)
- [3.2.8 internal_power Group](#)
- [3.2.9 max_cap Group](#)
- [3.2.10 max_trans Group](#)
- [3.2.11 min_pulse_width Group](#)
- [3.2.12 minimum_period Group](#)
- [3.2.13 pin_capacitance Group](#)
- [3.2.14 receiver_capacitance Group](#)
- [3.2.15 timing Group in a pin Group](#)
- [3.2.16 tlatch Group](#)

Index

1. Technology Library Group Description and Syntax

This chapter describes the role of the `library` group in defining a CMOS technology library.

The information in this chapter includes a description and syntax example for all the attributes and groups that you can define within the `library` group, with the following exceptions:

- The `cell` and `model` groups, which are described in [Chapter 2, “cell and model Group Description and Syntax”](#)
- The `pin` group, which is described in [Chapter 3, “pin Group Description and Syntax”](#)

This chapter provides information about the `library` group in the following sections:

- [Library-Level Attributes and Values](#)
- [General Syntax](#)
- [Reducing Library File Size](#)
- [library Group Name](#)
- [library Group Example](#)
- [Simple Attributes](#)
- [Defining Default Attribute Values in a CMOS Technology Library](#)
- [Complex Attributes](#)
- [Group Statements](#)

1.1 Library-Level Attributes and Values

The `library` group is the superior group in a technology library. The `library` group contains all the groups and attributes that define the technology library.

[Example 1-1](#) lists alphabetically a sampling of the attributes, groups, and values that you can define within a technology library. [Example 1-2](#) shows the general syntax and the functional order in which the attributes usually appear within a library group.

Example 1-1 Attributes, Groups, and Values in a Technology Library

```
library (name_string) {
    ... library    description ...
}

/* Library Description: Simple Attributes */

bus_naming_style : "string" ;
comment : "string" ;
current_unit : value_enum ;
```

```

date : "date" ;
delay_model : value_enum ;
em_temp_degradation_factor : float ;
fpga_technology : "fpga_technology_name_string" ;
in_place_swap_mode : match_footprint | no_swapping ;
input_threshold_pct_fall : trip_point    value ;
input_threshold_pct_rise : trip_point    value ;
leakage_power_unit : value_enum ;
nom_calc_mode : name_id ;
nom_process : float ;
nom_temperature : float ;
nom_voltage : float ;
output_threshold_pct_fall : trip_point    value ;
output_threshold_pct_rise : trip_point    value ;
piece_type : value_enum ;
power_model : table_lookup | polynomial ;
preferred_output_pad_slew_rate_control : value_enum ;
preferred_input_pad_voltage : string ;
preferred_output_pad_voltage : string ;
pulling_resistance_unit : 1ohm | 10ohm | 100ohm | 1kohm ;
revision : float | string ;
simulation : true | false ;
slew_derate_from_library : derate    value ;
slew_lower_threshold_pct_fall : trip_point    value ;
slew_lower_threshold_pct_rise : trip_point    value ;
slew_upper_threshold_pct_fall : trip_point    value ;
slew_upper_threshold_pct_rise : trip_point    value ;
time_unit : 1ps | 10ps | 100ps | 1ns ;
voltage_unit : 1mV | 10mV | 100mV | 1V ;

```

/* Library Description: Default Attributes */

```

default_cell_leakage_power : float ;
default_connection_class : name | name_list_string ;
default_fall_delay_intercept : float ; /* piecewise model only */
default_fall_pin_resistance : float ; /* piecewise model only */
default_fanout_load : float ;
default_inout_pin_cap : float ;
default_inout_pin_fall_res : float ;
default_inout_pin_rise_res : float ;
default_input_pin_cap : float ;
default_intrinsic_fall : float ;
default_intrinsic_rise : float ;
default_leakage_power_density : float ;
default_max_capacitance : float ;
default_max_fanout : float ;
default_max_transition : float ;
default_max_utilization : float ;
default_min_porosity : float ;
default_operating_conditions : name_string ;
default_output_pin_cap : float ;
default_output_pin_fall_res : float ;
default_output_pin_rise_res : float ;
default_rise_delay_intercept : float ; /* piecewise model only */
default_rise_pin_resistance : float ; /* piecewise model only */
default_slope_fall : float ;
default_slope_rise : float ;
default_wire_load : name_string ;
default_wire_load_area : float ;
default_wire_load_capacitance : float ;
default_wire_load_mode : top | segmented | enclosed ;
default_wire_load_resistance : float ;
default_wire_load_selection : namestring ;

```

/* Library Description: Scaling Attributes */

```

k_process_cell_fall : float ; /* nonlinear model only */
k_process_cell_leakage_power : float ;
k_process_cell_rise : float ; /* nonlinear model only */
k_process_drive_current : float ;
k_process_drive_fall : float ;
k_process_drive_rise : float ;

```

```
k_process_fall_delay_intercept : float ; /* piecewise model only */
k_process_fall_pin_resistance : float ; /* piecewise model only */
k_process_fall_propagation : float ; /* nonlinear model only */
k_process_fall_transition : float ; /* nonlinear model only */
k_process_hold_fall : float ;
k_process_hold_rise : float ;
k_process_internal_power : float ;
k_process_intrinsic_fall : float ;
k_process_intrinsic_rise : float ;
k_process_min_period : float ;
k_process_min_pulse_width_high : float ;
k_process_min_pulse_width_low : float ;
k_process_nochange_fall : float ; /* nonnegative value */
k_process_nochange_rise: float ; /* nonnegative value */
k_process_pin_cap : float ;
k_process_recovery_fall : float ;
k_process_recovery_rise : float ;
k_process_removal_fall : float ;
k_process_removal_rise : float ;
k_process_rise_delay_intercept : float ; /* piecewise model only */
k_process_rise_pin_resistance : float ; /* piecewise model only */
k_process_rise_propagation : float ; /* nonlinear model only */
k_process_rise_transition : float ; /* nonlinear model only */
k_process_setup_fall : float ;
k_process_setup_rise : float ;
k_process_skew_fall : float ;
k_process_skew_rise : float ;
k_process_slope_fall : float ;
k_process_slope_rise : float ;
k_process_wire_cap : float ;
k_process_wire_res : float ;
k_temp_cell_rise : float ; /* nonlinear model only */
k_temp_cell_fall : float ; /* nonlinear model only */
k_temp_cell_leakage_power : float ;
k_temp_drive_current : float ;
k_temp_drive_fall : float ;
k_temp_drive_rise : float ;
k_temp_fall_delay_intercept : float ; /* piecewise model only */
k_temp_fall_pin_resistance : float ; /* piecewise model only */
k_temp_fall_propagation : float ; /* nonlinear model only */
k_temp_fall_transition : float ; /* nonlinear model only */
k_temp_hold_fall : float ;
k_temp_hold_rise : float ;
k_temp_internal_power : float ;
k_temp_intrinsic_fall : float ;
k_temp_intrinsic_rise : float ;
k_temp_min_period : float ;
k_temp_min_pulse_width_high : float ;
k_temp_min_pulse_width_low : float ;
k_temp_nochange_fall : float ;
k_temp_nochange_rise : float ;
k_temp_pin_cap : float ;
k_temp_recovery_fall : float ;
k_temp_recovery_rise : float ;
k_temp_removal_fall : float ;
k_temp_removal_rise : float ;
k_temp_rise_delay_intercept : float ; /* piecewise model only */
k_temp_rise_pin_resistance : float ; /* piecewise model only */
k_temp_rise_propogation : float /* nonlinear model only */
k_temp_rise_transition : float ; /* nonlinear model only */
k_temp_rise_wire_resistance : float ;
k_temp_setup_fall : float ;
k_temp_rise_wire_resistance : float ;
k_temp_setup_rise : float ;
k_temp_skew_fall : float ;
k_temp_skew_rise : float ;
k_temp_slope_fall : float ;
k_temp_slope_rise : float ;
k_temp_wire_cap : float ;
k_temp_wire_res : float ;
k_volt_cell_fall : float ; /* nonlinear model only */
k_volt_cell_leakage_power : float ;
k_volt_cell_rise : float ; /* nonlinear model only */
k_volt_drive_current : float ;
k_volt_drive_fall: float ;
k_volt_drive_rise : float ;
```

```

k_volt_fall_delay_intercept : float ; /* piecewise model only */
k_volt_fall_pin_resistance : float ; /* piecewise model only */
k_volt_fall_propagation : float ; /* nonlinear model only */
k_volt_fall_transition : float ; /* nonlinear model only */
k_volt_hold_fall : float ;
k_volt_hold_rise : float ;
k_volt_internal_power : float ;
k_volt_intrinsic_fall : float ;
k_volt_intrinsic_rise : float ;
k_volt_min_period : float ;
k_volt_min_pulse_width_high : float ;
k_volt_min_pulse_width_low : float ;
k_volt_nochange_fall : float ;
k_volt_nochange_rise : float ;
k_volt_pin_cap : float ;
k_volt_recovery_fall : float ;
k_volt_recovery_rise : float ;
k_volt_removal_fall : float ;
k_volt_removal_rise : float ;
k_volt_rise_delay_intercept : float ; /* piecewise model only */
k_volt_rise_pin_resistance : float ; /* piecewise model only */
k_volt_rise_propagation : float ; /* nonlinear model only */
k_volt_rise_transition : float ; /* nonlinear model only */
k_volt_setup_fall : float ;
k_volt_setup_rise : float ;
k_volt_skew_fall : float ;
k_volt_skew_rise : float ;
k_volt_slope_fall : float ;
k_volt_slope_rise : float ;
k_volt_wire_cap : float ;
k_volt_wire_res : float ;

/* Library Description: Complex Attributes */

capacitive_load_unit (value, unit) ;
default_part (default_part_name_id, speed_grade_id) ;
define (name, object, type) ; /*user-defined attributes only */
define_cell_area (area_name, resource_type) ;
define_group (attribute_name_string, group_name_string, attribute_type_string) ;
library_features (value_1, value_2, ..., value_n) ;
piece_define ("range0 [range1 range2...]) ;
routing_layers ("routing_layer_1_name", ..., "routing_layer_n_name") ;
technology ("name") ;

/* Library Description: Group Statements */

cell (name) { }
dc_current_template (template_name_id) {
em_lut_template (name) { }
fall_net_delay : name ;
fall_transition_degradation (name) { }
faults_lut_template (name) { }
input_voltage (name) { }
iv_lut_template (name_string) { }
lu_table_template (name) { }
noise_lut_template (name_string) { }
operating_conditions (name) { }
output_voltage (name) { }
part (name){ }
poly_template (template_name_id) { }
power_lut_template (template_name_id) { }
power_poly_template () { }
power_supply () { }
propagation_lut_template (name_string) { }
rise_net_delay : name ;
rise_transition_degradation () { }
scaled_cell (name, opconds) { }
scaling_factors (name) { }
timing (name | name_list) { }
timing_range (name) { }
type (name) { }
wire_load (name) { }
wire_load_selection (name) { }
wire_load_table (name) { }

```

1.2 General Syntax

[Example 1-2](#) shows the general syntax of the library group. The first line names the library. Subsequent lines show simple and complex attributes that apply to the library as a whole, such as technology, date, and revision.

The example indicates where you place the default and scaling factors in library syntax. Group statements complete the library syntax.

Every cell in the library has a separate cell description.

Note:

[Example 1-2](#) does not contain every attribute or group listed in [Example 1-1](#).

Example 1-2 General Syntax of a Technology Library

```
library (name_string) {

    /* Library-Level Simple and Complex Attributes */

    technology (name_enum) ;
    delay_model : "model" ;
    bus_naming_style : "string" ;
    date : "date" ;
    comment : "string" ;
    time_unit : "unit" ;
    voltage_unit : "unit" ;
    leakage_power_unit : "unit" ;
    current_unit : "unit" ;
    pulling_resistance_unit : "unit" ;
    capacitive_load_unit (value,    unit) ;
    piece_type : type ;
    piece_define ( "range0    [range1    range2    ...]" ) ;
    define_cell_area (area_name,    resource_type) ;
    revision : float | string ;
    in_place_swap_mode : match_footprint | no_swapping ;
    simulation : true | false ;

    /* Default Attributes and Values (not shown here) */

    /* Scaling Factors Attributes and Values (not shown here) */

    /* Library-Level Group Statements */

    operating_conditions (name_string) {
        ... operating    conditions    description ...
    }
    timing_range (name_string) {
        ... timing    range    description ...
    }
    wire_load (name_string) {
        ... wire    load    description ...
    }
    wire_load_selection (name_string) {
        ... wire    load    selection    criteria...
    }
    poly_template (name_string) {
        ... polynomial    template    information...
    }
    power_lut_template (name_string) {
        ... power    lookup    table    template    information...
    }
    power_poly_template (name_string) {
        ... power    polynomial    template    information...
    }
    power_supply () {
        ... power    supply    information...
    }
    /* Cell definitions */
}
```

```

cell (name_string2) {
    ... cell    description   ...
}
scaled_cell (name_string1) {
    ... scaled   cell    description ...
}

...
type (name_string) {
    ... type description ...
}
input_voltage (name_string) {
    ... input    voltage   information ...
}
output_voltage (name_string) {
    ... output   voltage   information ...
}
}

```

1.3 Reducing Library File Size

Large library files can compromise disk capacity and memory resources. To reduce file size and improve file management, the syntax allows you to combine multiple source files by referencing the files from within the source file containing the library group description.

Use the `include_file` statement to reference information in another file for inclusion during library compilation. Be sure the directory of the included file is defined in your search path—the `include` attribute takes only the file name as its value; a path is not allowed.

Syntax

```
include_file(file_name_id);
```

Example

```

cell( ) {
    area : 0.1 ;
    ...
    include_file(opc_file) ;
    ...
}
```

where `opc_file` contains the `operating_conditions` group statements.

Limitations

The `include_file` attribute has these requirements:

- Recursive `include_file` statements are not allowed; that is, the source files that you include cannot also contain `include_file` statements.
- If the included file is not in the current directory, then the location of the included file must be defined in your search path.
- Multiple file names are not allowed in an `include_file` statement. However, there is no limit to the number of `include_file` statements you can have in your main source file.
- An included file cannot substitute for a value statement. For example, the following is not allowed:

```

cell ( ) {
    area : 0.1 ;
    ...
    pin_equal : include_file( source_file_id ) ;
}
```

- The `include_file` statement cannot substitute or cross the group boundary. For example, the following is not allowed:

```
cell ( A ) include ( source_file_id )
```

where `source_file_id` is the following:

```
{  
    attribute : value ;  
    attribute : value ;  
    ...  
}
```

1.4 library Group Name

The first line of the `library` group statement names the library. It is the first executable line in your library.

1.4.1 Syntax

```
library (name_string) {  
    ... library description ...  
}
```

1.4.2 Example

A library called `example1` looks like this:

```
library (example1) {  
    ... library description ...  
}
```

1.5 library Group Example

[Example 1-3](#) shows a portion of a library group for a CMOS library. It contains buses and uses a nonlinear timing delay model.

Example 1-3 CMOS Library Group

```
library (example1) {  
    technology (cmos) ;  
    delay_model : table_lookup ;  
    date : "December 12, 2003" ;  
    comment : "Copyright 2003, General Silicon, Inc." ;  
    revision : 2003.12 ;  
    bus_naming_style : "Bus%sPin%d" ;  
    ...  
}
```

1.6 Simple Attributes

Following are descriptions of the `library` group simple attributes. Similar sections describing the default, complex, and group statement attributes complete this chapter.

1.6.1 bus_naming_style Simple Attribute

The `bus_naming_style` attribute defines the naming convention for buses in the library.

Syntax

```
bus_naming_style : "string";  
  
string
```

Can contain alphanumeric characters, braces, underscores, dashes, or parentheses. Must contain one `%s` symbol and one `%d` symbol. The `%s` and `%d` symbols can appear in any order, but at least one nonnumeric character must separate them.

The colon character is not allowed in a `bus_naming_style` attribute value because the colon is used to denote a range of bus members.

You construct a complete bused-pin name by using the name of the owning bus and the member number. The owning bus

name is substituted for the %s, and the member number replaces the %d.

If you do not define the bus_naming_style attribute, Liberty applies the default naming convention, as shown in the following example.

Example

```
bus_naming_style : "%s[%d]" ;
```

When the default naming convention is applied, member 1 of bus A becomes A[1].

The next example shows how you can use the bus_naming_style attribute to apply a different naming convention.

Example

```
bus_naming_style : "Bus%sPin%d" ;
```

When this naming convention is applied, bus member 1 of bus A becomes BusAPin1, bus member 2 becomes BusAPin2, and so on.

1.6.2 comment Simple Attribute

You use the comment attribute to include copyright or other product information in the library report that you generate using the report_lib command. You can include only one comment line in a library.

Syntax

```
comment : "string" ;
```

string

You can use an unlimited number of characters in the string, but all the characters must be enclosed within quotation marks.

Example

The following comment line:

```
comment : "Copyright 2003, General Silicon, Inc." ;
```

appears in the report like this:

```
Comment : Copyright 2003, General Silicon, Inc.
```

1.6.3 current_unit Simple Attribute

The current_unit attribute specifies the unit for the drive current generated by output pads. The pulling_current attribute for a pull-up or pull-down transistor also represents its values in the specified unit.

Syntax

```
current_unit : value_enum ;
```

value

The valid values are 1uA, 10uA, 100uA, 1mA, 10mA, 100mA, and 1A. No default value exists for the current_unit attribute if the attribute is omitted.

Example

```
current_unit : 100uA ;
```

1.6.4 date Simple Attribute

The optional date attribute identifies the date your library was created. The date appears in the library report produced by the report_lib command.

Syntax

```
date : "date" ;  
  
date  
  
You can use any format within the quotation marks to report the date.
```

Example

```
date : "12 December 2003" ;
```

1.6.5 default_fpga_isd Simple Attribute

If you define more than one `fpga_isd` group, you must use the `default_fpga_isd` attribute to specify which of those `fpga_isd` groups is the default.

Syntax

```
default_fpga_isd : fpga_isd_name_id ;  
  
fpga_isd_name  
  
The name of the default fpga_isd group.
```

Example

```
default_fpga_isd : lib_isd ;
```

1.6.6 default_threshold_voltage_group Simple Attribute

The optional `default_threshold_voltage_group` attribute specifies a cell's category based on its threshold voltage characteristics.

Syntax

```
default_threshold_voltage_group : group_name_id ;  
  
group_name  
  
A string value representing the name of the category.
```

Example

```
default_threshold_voltage_group : "high_vt_cell" ;
```

1.6.7 delay_model Simple Attribute

Use the `delay_model` attribute to specify which delay model to use in the delay calculations.

The `delay_model` attribute must be the first attribute in the library if a technology attribute is not present. Otherwise, it should follow the technology attribute.

Syntax

```
delay_model : value_enum ;  
  
value  
  
Valid values are generic_cmos, table_lookup (nonlinear delay model), piecewise_cmos, dcm (delay calculation module), and polynomial (scalable polynomial delay model).
```

Example

```
delay_model : table_lookup ;
```

[1.6.8 distance_unit and dist_conversion_factor Attributes](#)

The `distance_unit` attribute specifies the distance unit and the resolution, or accuracy, of the values in the `critical_area_table` table in the `critical_area_lut_template` group. The distance and area values are represented as floating-point numbers that are rounded in the `critical_area_table`. The distance values are rounded by the `dist_conversion_factor` and the area values are rounded by the `dist_conversion_factor` squared.

[Syntax](#)

```
distance_unit : enum (um, mm);  
dist_conversion_factor : integer;
```

[Example](#)

```
library(my_library) {  
  
    distance_unit : um;  
    dist_conversion_factor : 1000;  
    critical_area_lut_template (caa_template) {  
        variable_1 : defect_size_diameter;  
        index_1 ("0.05, 0.10, 0.15, 0.20, 0.25, 0.30");  
    }  
}
```

[1.6.9 critical_area_lut_template Group](#)

The `critical_area_lut_template` group is a critical area lookup table used only for critical area analysis modeling. The `defect_size_diameter` is the only valid variable.

[Syntax](#)

```
critical_area_lut_template (template_name) {
```

[Example](#)

```
library(my_library) {  
  
    distance_unit : um;  
    dist_conversion_factor : 1000;  
    critical_area_lut_template (caa_template) {  
        variable_1 : defect_size_diameter;  
        index_1 ("0.05, 0.10, 0.15, 0.20, 0.25, 0.30");  
    }  
}
```

[1.6.10 device_layer, poly_layer, routing_layer, and cont_layer Groups](#)

Because yield calculation varies among different types of layers, Liberty syntax supports the following types of layers: device, poly, routing, and contact (via) layers. The `device_layer`, `poly_layer`, `routing_layer`, and `cont_layer` groups define layers that have critical area data modeled on them for cells in the library. The layer definition is specified at the library level. It is recommended that you declare the layers in order, from the bottom up. The layer names specified here must match the actual layer names in the corresponding physical libraries.

[Syntax](#)

```
device_layer(<string>) {} /* such as diffusion layer OD */
```

[Example](#)

```
library(my_library) {  
  
    distance_unit : um;  
    dist_conversion_factor : 1000;  
    critical_area_lut_template (caa_template) {  
        variable_1 : defect_size_diameter;  
        index_1 ("0.05, 0.10, 0.15, 0.20, 0.25, 0.30");  
    }  
  
    device_layer(<string>) {} /* such as diffusion layer OD */  
    poly_layer(<string>) {} /* such as poly layer */  
    routing_layer(<string>) {} /* such as M1, M2, ... */  
    cont_layer(<string>) {} /* via layer, such as VIA */  
}
```

[1.6.11 em_temp_degradation_factor Simple Attribute](#)

The `em_temp_degradation_factor` attribute specifies the electromigration exponential degradation factor.

Syntax

```
em_temp_degradation_factor : valuefloat ;
```

value

A floating-point number in centigrade units consistent with other temperature specifications throughout the library.

Example

```
em_temp_degradation_factor : 40.0 ;
```

1.6.12 *fpga_domain_style* Simple Attribute

Use the `fpga_domain_style` attribute to specify a value that you reference from a `calc_mode` attribute in a domain group in a polynomial table.

Syntax

```
fpga_domain_style : "nameid" ;
```

name

The style value.

Example

```
fpga_domain_style : "speed" ;
```

1.6.13 *fpga_technology* Simple Attribute

Use this attribute to specify your FPGA technology. This attribute is required when your library technology is FPGA.

Syntax

```
fpga_technology : "fpga_technology_namestring" ;
```

fpga_technology_name

The name of your FPGA technology.

Example

```
fpga_technology : "my_fpga_technology_1" ;
```

1.6.14 *in_place_swap_mode* Simple Attribute

In-place optimization occurs after placement and routing.

The `in_place_swap_mode` attribute specifies the criteria for cell swapping during in-place optimization. The basic criteria for cell swapping are:

- The cells must have the same function.
- The cells must have the same number of pins, and the pins must have the same pin names.

Syntax

```
in_place_swap_mode : match_footprint | no_swapping ;
```

match_footprint

Cells are swapped if they meet the criteria and have the same footprint attribute.

no_swapping

In-place optimization is disabled. The `cell_footprint` attribute is ignored. The `no_swapping` value is the default for CMOS libraries.

Example

```
in_place_swap_mode : match_footprint ;
```

Use the `report_lib` command to print the type of in-place swap mode your technology library is using.

1.6.15 `input_threshold_pct_fall` Simple Attribute

Use the `input_threshold_pct_fall` attribute to set the default value of the threshold point on an input pin signal falling from 1 to 0. You can specify this attribute at the pin-level to override the default value.

Syntax

```
input_threshold_pct_fall : trip_pointfloat ;
```

trip_point

A floating-point number between 0.0 and 100.0 that specifies the threshold point of an input pin signal falling from 1 to 0. The default value is 50.0.

Example

```
input_threshold_pct_fall : 60.0 ;
```

1.6.16 `input_threshold_pct_rise` Simple Attribute

Use the `input_threshold_pct_rise` attribute to set the default value of the threshold point on an input pin signal rising from 0 to 1. You can specify this attribute at the pin-level to override the default value.

Syntax

```
input_threshold_pct_rise : trip_pointfloat ;
```

trip_point

A floating-point number between 0.0 and 100.0 that specifies the threshold point of an input pin signal rising from 0 to 1. The default value is 50.0.

Example

```
input_threshold_pct_rise : 40.0 ;
```

1.6.17 `leakage_power_unit` Simple Attribute

The `leakage_power_unit` attribute is defined at the library level. It indicates the units of the power values in the library. If this attribute is missing, the leakage-power values are expressed without units.

Syntax

```
leakage_power_unit : valueenum ;
```

value

Valid values are 1mW, 100uW (for 100mW), 10uW (for 10mW), 1uW (for 1mW), 100nW, 10nW, 1nW, 100pW, 10pW, and 1pW.

Example

```
leakage_power_unit : "100uW" ;
```

1.6.18 `nom_calc_mode` Simple Attribute

This optional attribute defines a default process point, one of the nominal operating conditions for a library.

Syntax

```
nom_calc_mode : nameid ;  
  
name  
  
Represents the default process point.
```

Example

```
nom_calc_mode : nominal ;
```

1.6.19 nom_process Simple Attribute

The `nom_process` attribute defines process scaling, one of the nominal operating conditions for a library.

Syntax

```
nom_process : valuefloat ;  
  
value  
  
A floating-point number that represents the degree of process scaling in the cells of the library.
```

Example

```
nom_process : 1.0 ;
```

1.6.20 nom_temperature Simple Attribute

The `nom_temperature` attribute defines the temperature (in centigrade), one of the nominal operating conditions for a library.

Syntax

```
nom_temperature : valuefloat ;  
  
value  
  
A floating-point number that represents the temperature of the cells in the library.
```

Example

```
nom_temperature : 25.0 ;
```

1.6.21 nom_voltage Simple Attribute

The `nom_voltage` attribute defines voltage, one of the nominal operating conditions for a library.

Syntax

```
nom_voltage : valuefloat ;  
  
value  
  
A floating-point number that represents the voltage of the cells in the library.
```

Example

```
nom_voltage : 5.0 ;
```

1.6.22 output_threshold_pct_fall Simple Attribute

Use the `output_threshold_pct_fall` attribute to set the value of the threshold point on an output pin signal falling from 1

to 0.

Syntax

```
output_threshold_pct_fall : trip_pointfloat ;
```

trip_point

A floating-point number between 0.0 and 100.0 that specifies the threshold point of an output pin signal falling from 1 to 0. The default value is 50.0.

Example

```
output_threshold_pct_fall : 40.0 ;
```

1.6.23 *output_threshold_pct_rise* Simple Attribute

Use the `output_threshold_pct_rise` attribute to set the value of the threshold point on an output pin signal rising from 0 to 1.

Syntax

```
output_threshold_pct_rise : trip_pointfloat ;
```

trip_point

A floating-point number between 0.0 and 100.0 that specifies the threshold point of an output pin signal rising from 0 to 1. The default value is 50.0.

Example

```
output_threshold_pct_rise : 40.0 ;
```

1.6.24 *piece_type* Simple Attribute

The `piece_type` attribute provides the option of using capacitance to define the piecewise linear model.

Syntax

```
piece_type : valueenum ;
```

value

Valid values are `piece_length`, `piece_wire_cap`, `piece_pin_cap`, and `piece_total_cap`.

Example

```
piece_type : piece_length ;
```

The `piece_wire_cap`, `piece_pin_cap`, and `piece_total_cap` values represent the piecewise linear model extensions that cause modeling to use capacitance instead of length. These values indicate wire capacitance alone, total pin capacitance, or the total wire and pin capacitance. If the `piece_type` attribute is not defined, modeling defaults to the `piece_length` model.

1.6.25 *power_model* Simple Attribute

The `power_model` attribute allows you to specify whether your library utilizes lookup tables or scalable polynomial equations to model power.

Syntax

```
power_model : value ;
```

value

The valid values you can specify are `table_lookup` and `polynomial`. If no value is specified, `table_lookup` is used.

Example

```
power_model : polynomial ;
```

1.6.26 *preferred_output_pad_slew_rate_control Simple Attribute*

Use the `preferred_output_pad_slew_rate_control` attribute to embed directly in the library the desired preferred slew-rate control value.

Syntax

```
preferred_output_pad_slew_rate_control : valueenum ;
```

value

Valid values are high, medium, low, and none.

Example

```
preferred_output_pad_slew_rate_control : high ;
```

1.6.27 *preferred_input_pad_voltage Simple Attribute*

Use the `preferred_input_pad_voltage` and the `preferred_output_pad_voltage` attributes to embed in the library the preferred voltage values.

Syntax

```
preferred_input_pad_voltage : name1string; preferred_output_pad_voltage : name2string ;
```

name1

A string name for any of the input voltage groups defined in the library.

name2

A string name for any of the output voltage groups defined in the library.

For more information about output and input voltage groups, see the “Defining Core Cells” and “Defining I/O Pads” chapters in the Liberty User Guide, Volume 1.

1.6.28 *preferred_output_pad_voltage Simple Attribute*

For information about using the `preferred_output_pad_voltage` attribute, see the description of the [“preferred_input_pad_voltage Simple Attribute”](#).

1.6.29 *pulling_resistance_unit Simple Attribute*

Use the `pulling_resistance_unit` attribute to define pulling resistance values for pull-up and pull-down devices.

Syntax

```
pulling_resistance_unit : "unit" ;
```

unit

Valid unit values are 1ohm, 10ohm, 100ohm, and 1kohm. No default value exists for `pulling_resistance_unit` if the attribute is omitted.

Example

```
pulling_resistance_unit : "10ohm" ;
```

1.6.30 *revision Simple Attribute*

The optional `revision` attribute defines a revision number for your library.

Syntax

```
revision : value ;
```

value

The value can be either a floating-point number or a string.

Example

```
revision : V3.1a ;
```

1.6.31 simulation Simple Attribute

Setting the `simulation` attribute to true lets a tool simulation library files.

Syntax

```
simulation : true | false ;
```

The default for the `simulation` attribute is true.

Example

```
simulation : true ;
```

1.6.32 slew_derate_from_library Simple Attribute

Use the `slew_derate_from_library` attribute to specify how the transition times need to be derated to match the transition times between the characterization trip points.

Syntax

```
slew_derate_from_library : deratefloat ;
```

derate

A floating-point number between 0.0 and 1.0. The default value is 1.0.

Example

```
slew_derate_from_library : 0.5 ;
```

1.6.33 slew_lower_threshold_pct_fall Simple Attribute

Use the `slew_lower_threshold_pct_fall` attribute to set the default value of the lower threshold point used for modeling the delay of a pin falling from 1 to 0. You can specify this attribute at the pin-level to override the default value.

Syntax

```
slew_lower_threshold_pct_fall : trip_pointvalue ;
```

trip_point

A floating-point number between 0.0 and 100.0 that specifies the lower threshold point used for modeling the delay of a pin falling from 1 to 0. The default value is 20.0.

Example

```
slew_lower_threshold_pct_fall : 30.0 ;
```

1.6.34 slew_lower_threshold_pct_rise Simple Attribute

Use the `slew_lower_threshold_pct_rise` attribute to set the default value of the lower threshold point used in modeling the delay of a pin rising from 0 to 1. You can specify this attribute at the pin-level to override the default value.

Syntax

```
slew_lower_threshold_pct_rise : trip_pointvalue ;
```

trip_point

A floating-point number between 0.0 and 100.0 that specifies the lower threshold point used for modeling the delay of a pin rising from 0 to 1. The default value is 20.0.

Example

```
slew_lower_threshold_pct_rise : 30.0 ;
```

1.6.35 slew_upper_threshold_pct_fall Simple Attribute

Use the `slew_upper_threshold_pct_fall` attribute to set the default value of the upper threshold point used for modeling the delay of a pin falling from 1 to 0. You can specify this attribute at the pin-level to override the default value.

Syntax

```
slew_upper_threshold_pct_fall : trip_pointvalue ;
```

trip_point

A floating-point number between 0.0 and 100.0 that specifies the upper threshold point used to model the delay of a pin falling from 1 to 0. The default value is 80.0.

Example

```
slew_upper_threshold_pct_fall : 70.0 ;
```

1.6.36 slew_upper_threshold_pct_rise Simple Attribute

Use the `slew_upper_threshold_pct_rise` attribute to set the value of the upper threshold point used for modeling the delay of a pin rising from 0 to 1. You can specify this attribute at the pin-level to override the default value.

Syntax

```
slew_upper_threshold_pct_rise : trip_pointvalue ;
```

trip_point

A floating-point number between 0.0 and 100.0 that specifies the upper threshold point used for modeling the delay of a pin rising from 0 to 1. The default value is 80.0.

Example

```
slew_upper_threshold_pct_rise : 70.0 ;
```

1.6.37 time_unit Simple Attribute

Use attribute to identify the physical time unit used in the generated library.

Syntax

```
time_unit : unit ;
```

unit

Valid values are 1ps, 10ps, 100ps, and 1ns. The `time_unit` attribute default value is 1ns.

Example

```
time_unit : 100ps ;
```

1.6.38 voltage_unit Simple Attribute

Use this attribute to scale the contents of the `input_voltage` and `output_voltage` groups.

Additionally, the `voltage` attribute in the `operating_conditions` group represents values in the voltage units.

Syntax

```
voltage_unit : unit ;  
unit  
Valid values are 1mV, 10mV, 100mV, and 1V. The default value is 1V.
```

Example

```
voltage_unit : 100mV;
```

1.7 Defining Default Attribute Values in a CMOS Technology Library

Within the `library` group of a CMOS technology library, you can define default values for the `pin` and `timing` group attributes. Then, as needed, you can override the default settings by defining corresponding attributes at the individual `pin` or `timing` group levels.

The following tables list the default attributes that you can define within the `library` group and the attributes that override them.

- [Table 1-1](#) lists the default attributes you can use in all the CMOS models.
- [Table 1-2](#) lists the default attributes you can use in piecewise linear delay models.
- [Table 1-3](#) lists the default attributes you can use in CMOS linear delay models.

Table 1-1 CMOS Default Attributes for All Models

Default attribute	Description	Override with
<code>default_cell_leakage_power</code>	Default leakage power	<code>cell_leakage_power</code>
<code>default_connection_class</code>	Default connection class	<code>connection_class</code>
<code>default_fanout_load</code>	Fanout load of input pins	<code>fanout_load</code>
<code>default_inout_pin_cap</code>	Capacitance of inout pins	<code>capacitance</code>
<code>default_input_pin_cap</code>	Capacitance of input pins	<code>capacitance</code>
<code>default_intrinsic_fall</code>	Intrinsic fall delay of a timing arc	<code>intrinsic_fall</code>
<code>default_intrinsic_rise</code>	Intrinsic rise delay of a timing arc	<code>intrinsic_rise</code>
<code>default_leakage_power_density</code>	Default leakage power density	<code>cell_leakage_power</code>
<code>default_max_capacitance</code>	Maximum capacitance of output pins	<code>max_capacitance</code>
<code>default_max_fanout</code>	Maximum fanout of all output pins	<code>max_fanout</code>
<code>default_max_transition</code>	Maximum transition of output pins	<code>max_transition</code>
<code>default_max_utilization</code>	Maximum limit of utilization	No override available
<code>default_min_porosity</code>	Minimum porosity constraint	<code>set_min_porosity</code>
<code>default_operating_conditions</code>	Default operating conditions for the library	<code>operating_conditions</code>
<code>default_output_pin_cap</code>	Capacitance of output pins	<code>capacitance</code>
<code>default_slope_fall</code>	Fall sensitivity factor of a timing arc	<code>slope_fall</code>
<code>default_slope_rise</code>	Rise sensitivity factor of a timing arc	<code>slope_rise</code>
<code>default_wire_load</code>	Wire load	No override available
<code>default_wire_load_area</code>	Wire load area	No override available
<code>default_wire_load_capacitance</code>	Wire load capacitance	No override available

default_wire_load_mode	Wire load mode	set_wire_load -mode
default_wire_load_resistance	Wire load resistance	No override available
default_wire_load_selection	Wire load selection	No override available

Table 1-2 CMOS Default Attributes for Piecewise Linear Delay Models

Default attribute	Description	Override with
default_fall_delay_intercept	Falling-edge intercept of a timing arc	fall_delay_intercept
default_fall_pin_resistance	Fall resistance of output pins	fall_pin_resistance
default_rise_delay_intercept	Rising-edge intercept of a timing arc	rise_delay_intercept
default_rise_pin_resistance	Rise resistance of output pins	rise_pin_resistance

Table 1-3 CMOS Default Attributes for Linear Delay Models

Default attribute	Description	Override with
default inout pin fall res	Fall resistance of inout pins	fall_resistance
default inout pin rise res	Rise resistance of inout pins	rise_resistance
default output pin fall res	Fall resistance of output pins	fall_resistance
default output pin rise res	Rise resistance of output pins	rise_resistance

1.8 Complex Attributes

Following are the descriptions of the technology library complex attributes.

1.8.1 capacitive_load_unit Complex Attribute

The `capacitive_load_unit` attribute specifies the unit for all capacitance values within the technology library, including default capacitances, max fanout capacitances, pin capacitances, and wire capacitances.

Syntax

```
capacitive_load_unit (valuefloatunitenum) ;
```

value

A floating-point number.

unit

Valid values are ff and pf.

The first line in the following example sets the capacitive load unit to 1 pf. The second line represents capacitance in terms of the standard unit load of an inverter.

Example

```
capacitive_load_unit (1,pf) ;
capacitive_load_unit (0.059,pf) ;
```

The `capacitive_load_unit` attribute has no default value when the attribute is omitted.

1.8.2 default_part Complex Attribute

The `default_part` attribute specifies the default part and the speed used for an FPGA design.

Syntax

```
default_part (default_part_namestring, speed_gradestring) ;
```

default_part_name

The name of the default part.

speed_grade

The speed grade the design uses.

Example

```
default_part ( "AUTO" , "-5" ) ;
```

1.8.3 define Complex Attribute

Use this special attribute to define new, temporary, or user-defined attributes for use in symbol and technology libraries.

Syntax

```
define ("attribute_name", "group_name", "attribute_type") ;
```

attribute_name

The name of the attribute you are creating.

group_name

The name of the group statement in which the attribute is to be used.

attribute_type

The type of the attribute that you are creating; valid values are Boolean, string, integer, or float.

You can use either a space or a comma to separate the arguments. The following example shows how to define a new string attribute called `bork`, which is valid in a `pin` group:

Example

```
define ("bork", "pin", "string") ;
```

You give the new library attribute a value by using the simple attribute syntax:

```
bork : "nimo" ;
```

1.8.4 define_cell_area Complex Attribute

The `define_cell_area` attribute defines the area resources a cell uses, such as the number of pad slots.

Syntax

```
define_cell_area (area_name, resource_type) ;
```

area_name

A name of a resource type. You can associate more than one `area_name` attribute with each of the predefined resource types.

resource_type

The resource type can be

- `pad_slots`
- `pad_input_driver_sites`
- `pad_output_driver_sites`
- `pad_driver_sites`

Use the `pad_driver_sites` type when you do not need to discriminate between input and output pad driver sites.

You can define as many cell area types as you need, as shown here.

Example

```
define_cell_area (bond_pads, pad_slots) ;  
define_cell_area (pad_drivers, pad_driver_sites) ;
```

After you define the cell area types, specify the resource type in a `cell` group to identify how many of each resource type the cell requires, as shown here.

Example

```
cell(IV_PAD) {  
    bond_pads : 1 ;  
    ...  
}
```

1.8.5 `define_group` Complex Attribute

Use this special attribute to define new, temporary, or user-defined groups for use in technology libraries.

Syntax

```
define_group (group_id, parent_name_id) ;
```

group

The name of the user-defined group.

parent_name

The name of the group statement in which the attribute is to be used.

The following example shows how you define a new group called myGroup:

Example

```
define_group (myGroup, timing) ;
```

1.8.6 `library_features` Complex Attribute

The `library_features` attribute lets other other tools use the command features that you specify as attribute values.

Syntax

```
library_features (value_id) ;
```

value

Valid values are `report_delay_calculation`, `report_power_calculation`, `report_noise_calculation`, `report_user_data` and `allow_update_attribute`. The default value is none.

report_delay_calculation

Displays timing information.

report_power_calculation

Displays power numbers specified in the library .db file when the `report_power_calculation` command is run.

report_noise_calculation

Displays noise information for tied-off cells.

report_user_data

Allows the `report_lib` command to display information about user-defined attributes and groups.

allow_update_attribute

Allows the `update_lib` and `set_lib_attribute` commands to overwrite user-defined attribute values.

Example

```
library_features (report_delay_calculation) ;
```

1.8.7 `piece_define` Complex Attribute

The `piece_define` complex attribute statement defines the pieces used in the piecewise linear delay model. With this attribute, you can define the ranges of length or capacitance for indexed variables, such as `rise_pin_resistance`, used in the delay equations.

Syntax

```
piece_define ("range0 [range1 range2 ...]) ;
```

Each range is a floating-point number defining the lower limit of the respective range. If the piecewise linear model is in the `piece_length` mode, as described in the `piece_type` attribute section, a wire whose length is between `range0` and `range1` is named as piece 0, a wire whose length is between `range1` and `range2` is piece 1, and so on.

For example, in the following `piece_define` specification, a wire of length 5 is referred to as piece 0, a wire of length 12 is piece 1, and a wire of length 20 or more is piece 2.

Example

```
piece_define ("0 10 20") ;
```

Each capacitance is a positive floating-point number defining the lower limit of the respective range. A piece of wire whose capacitance is between `range0` and `range1` is identified as `piece0`, a capacitance between `range1` and `range2` is piece 1, and so on.

You must include in the `piece_define` statement all ranges of wire length or capacitance for which you want to enter a unique attribute value.

1.8.8 `routing_layers` Complex Attribute

The `routing_layers` attribute declares the routing layers available for place and route for the library. The `routing_layers` attribute is a string that represents the symbolic name used later in a library to describe routability information associated with each layer. The `routing_layers` attribute must be defined in the library before other routability information in a cell. Otherwise, cell routability information in the library is considered an error. Each different library can have only one `routing_layers` complex attribute.

Syntax

```
routing_layers("routing_layer_1_name",...,  
"routing_layer_n_name");
```

The `report_lib` command displays library routing layer information. The report looks similar to the following example.

```
Porosity information:  
Routing_layers:  
  "metal2" "metal3"  
default_min_porosity: 15.0
```

If there is no porosity information in the library, `report_lib` displays the following line:

```
No porosity information specified.
```

1.8.9 `technology` Complex Attribute

Use this attribute to specify which technology family is used in the library. When you define the `technology` attribute, it must be the first attribute you use and it must be placed at the top of the listing (see [Example 1-2](#)).

Syntax

```
technology (name_enum);
```

name

Valid values are CMOS or FPGA. If you specify FPGA, you must also specify the `fpga_technology` attribute at the library level. The default is CMOS.

Example

```
technology (cmos) ;
```

1.8.10 `voltage_map` Complex Attribute

Use this attribute to specify the cell-level `pg_pin` groups.

Syntax

```
voltage_map (voltage_name_id, voltage_value_float) ;
```

voltage_name

Specifies a power supply.

voltage_value

Specifies a voltage value.

Example

```
voltage_map (VDD1, 3.0) ;
```

1.9 Group Statements

Following are the descriptions of the technology library group statement attribute.

1.9.1 `base_curves` Group

The `base_curves` group is a library-level group that contains the detailed description of normalized base curves.

Syntax

```
library(my_compact_ccs_lib) {  
    ...  
    base_curves (base_curves_name) {  
        ...  
    }  
}
```

Example

```
library(my_lib) {  
    ...  
    base_curves (ctbct1) {  
        ...  
    }  
}
```

Complex Attributes

```
base_curve_type  
curve_x  
curve_y
```

1.9.2 `base_curve_type` Complex Attribute

The `base_curve_type` attribute specifies the type of base curve. The valid values for `base_curve_type` are `ccs_timing_half_curve` and `ccs_half_curve`. The `ccs_half_curve` value allows you to model compact CCS power and compact CCS timing data within the same `base_curves` group. You must specify `ccs_half_curve` before specifying `ccs_timing_half_curve`.

Syntax

```
base_curve_type: enum (ccs_half_curve, ccs_timing_half_curve);
```

Example

```
base_curve_type : ccs_timing_half_curve ;
```

1.9.3 curve_x Complex Attribute

Each base curve consists of one `curve_x` and one `curve_y`. The `curve_x` attribute should be defined before `curve_y` for better readability and easier implementation. Only one `curve_x` attribute can be specified for each `base_curves` group. The data array is the x-axis value of the normalized base curve. For a `ccs_timing_half_curve` base curve, the `curve_x` value must be between 0 and 1 and increase monotonically.

Syntax

```
curve_x ("float..., float") ;
```

Example

```
curve_x ("0.2, 0.5, 0.8") ;
```

1.9.4 curve_y Complex Attribute

Each base curve consists of one `curve_x` and one `curve_y`. The `curve_x` attribute should be defined before `curve_y` for better readability and easier implementation. For compact CCS power, the valid region for `curve_y` is [-30, 30].

The `curve_y` attribute includes the following:

- The `curve_id` value, which specifies the base curve identifier.
- The data array, which is the Y-axis value of the normalized base curve.

Syntax

```
curve_y (curve_id, "float..., float") ;
```

Example

```
curve_y (1, "0.8, 0.5, 0.2");
```

1.9.5 compact_lut_template Group

The `compact_lut_template` group is a lookup table template used for compact CCS timing and power modeling.

Syntax

```
library (my_compact_ccs_lib) {  
    ...  
    compact_lut_template (template_name) {  
        ...  
    }  
}
```

Example

```
library (my_lib) {  
    ...  
    compact_lut_template (LTT3) {  
        ...  
    }  
}
```

Simple Attributes

```
base_curves_group  
variable_1  
variable_2  
variable_3
```

Complex Attributes

```
index_1
```

```
index_2  
index_3
```

1.9.6 base_curves_group Simple Attribute

The `base_curves_group` attribute is required in the `compressed_lut_template` group. Its value is the specified `base_curves` group name. The type of base curve in the `base_curves` group determines the `index_3` values when the `compact_lut_template` is used.

Syntax

```
base_curves_group : base_curves_name ;
```

Example

```
base_curves_group : ctbc1 ;
```

1.9.7 variable_1 and variable_2 Simple Attributes

The only valid values for the `variable_1` and `variable_2` attributes are `input_net_transition` and `total_output_net_capacitance`.

Syntax

```
variable_1 : input_net_transition | total_output_net_capacitance;  
variable_2 : input_net_transition | total_output_net_capacitance;
```

Example

```
variable_1 : input_net_transition ;  
variable_2 : total_output_net_capacitance ;
```

1.9.8 variable_3 Simple Attribute

The only legal string value for the `variable_3` attribute is `curve_parameters`.

Syntax

```
variable_3 : curve_parameters ;
```

Example

```
variable_3 : curve_parameters ;
```

1.9.9 index_1 and index_2 Complex Attributes

The `index_1` and `index_2` attributes are required. The `index_1` and `index_2` attributes define the `input_net_transition` and `total_output_net_capacitance` values. The `index` value for `input_net_transition` or `total_output_net_capacitance` is a floating-point number.

Syntax

```
index_1 ("float..., float") ;  
index_2 ("float..., float") ;
```

Example

```
index_1 ("0.1, 0.2") ;  
index_2 ("1.0, 2.0") ;
```

1.9.10 index_3 Complex Attribute

The string values in `index_3` are determined by the `base_curve_type` value in the `base_curve` group. When `ccs_timing_half_curve` is the `base_curve_type` value, the following six string values (parameters) should be defined: `init_current`, `peak_current`, `peak_voltage`, `peak_time`, `left_id`, `right_id`; their order is not fixed.

More than six parameters are allowed if a more robust syntax is required or for circumstances where more parameters are needed in order to describe the original data.

Syntax

```
index_3 ("string..., string") ;
```

Example

```
index_3 ("init_current, peak_current, peak_voltage,  
peak_time, left_id, right_id") ;
```

1.9.11 dc_current_template Group

The `dc_current_template` group defines a template for specifying a two-dimensional `dc_current` table or a three-dimensional `vector` table.

Syntax

```
library (name_string) {  
    dc_current_template (template_name_id) {  
        ... template description ...  
    }  
}
```

Simple Attributes

```
variable_1  
variable_2  
variable_3
```

Complex Attributes

```
index_1  
index_2  
index_3
```

variable_1, variable_2, and variable_3 Simple Attributes

For a two-dimensional `dc_current` table, the value you can assign to `variable_1` is `input_voltage`, and the value you can assign to `variable_2` is `output_voltage`.

For a three-dimensional `vector` table, the value you can assign to `variable_1` is `input_net_transition`, and the value you can assign to `variable_2` is `output_net_transition`. The value you can assign to `variable_3` is `time`.

index_1, index_2, and index_3 Complex Attributes

Along with `variable_1`, `variable_2`, and `variable_3`, you must specify the index values.

```
index_1 ("float, ..., float") ;  
index_2 ("float, ..., float") ;  
index_3 ("float, ..., float") ;
```

Example

```
library (my_library) {  
    ...  
    dc_current_template (my_template) {  
        variable_1 : input_net_transition ;  
        variable_2 : output_net_transition ;  
        variable_3 : time ;  
        index_1 ("0.0, 0.0") ;  
        index_2 ("0.0, 0.0") ;  
        index_3 ("0.0, 0.0") ;  
    }  
    ...  
}
```

1.9.12 em_lut_template Group

The `em_lut_template` group is defined at the `library` group level.

Syntax

```
library (name_string) {
    em_lut_template(name_string) {
        variable_1 : input_transition_time | total_output_net_capacitance ;
        variable_2 : input_transition_time | total_output_net_capacitance ;
        index_1 : ("float, ..., float");
        index_2 : ("float, ..., float");
    }
}
```

The `em_lut_template` group creates a template of the index used by the `electromigration` group defined in the `pin` group level.

`variable_1`, `variable_2`, and `variable_3` Simple Attributes

Following are the values that you can assign to the templates for electromigration tables. Use `variable_1` to assign values to one-dimensional tables; use `variable_2` to assign values for two-dimensional tables; and use `variable_3` to assign values for three-dimensional tables:

```
variable_1 : input_transition_time | total_output_net_capacitance ;
variable_2 : input_transition_time | total_output_net_capacitance ;
```

The value you assign to `variable_1` is determined by how the `index_1` complex attribute is measured, and the value you assign to `variable_2` is determined by how the `index_2` complex attribute is measured.

Assign `input_transition_time` to `variable_1` if the complex attribute `index_1` is measured with the input net transition time of the pin specified in the `related_pin` attribute or the pin associated with the `electromigration` group. Assign `total_output_net_capacitance` to `variable_1` if the complex attribute `index_1` is measured with the loading of the output net capacitance of the pin associated with the `em_max_toggle_rate` group.

Assign `input_transition_time` to `variable_2` if the complex attribute `index_2` is measured with the input net transition time of the pin specified in the `related_pin` or the `related_bus_pins` attribute or the pin associated with the `electromigration` group. Assign `total_output_net_capacitance` to `variable_2` if the complex attribute `index_2` is measured with the loading of the output net capacitance of the pin associated with the `electromigration` group.

`index_1` and `index_2` Complex Attributes

You can use these optional attributes to specify the first and second dimension breakpoints used to characterize cells for electromigration within the library.

Syntax

```
index_1 ("float, ..., float");
index_2 ("float, ..., float");
```

`float`

For `index_1`, the floating-point numbers that specify the breakpoints of the first dimension of the electromigration table used to characterize cells for electromigration within the library. For `index_2`, the floating-point numbers that specify the breakpoints for the second dimension of the electromigration table used to characterize cells for electromigration within the library.

You can overwrite the values entered for the `em_lut_template` group's `index_1` by entering values for the `em_max_toggle_rate` group's `index_1`. You can overwrite the values entered for the `em_lut_template` group's `index_2` by entering values for the `em_max_toggle_rate` group's `index_2`.

The following rules describe the relationship between variables and indexes:

- If you have `variable_1`, you can have only `index_1`.
- If you have `variable_1` and `variable_2`, you can have `index_1` and `index_2`.
- The value you enter for `variable_1` (used for one-dimensional tables) is determined by how `index_1` is measured. The value you enter for `variable_2` (used for two-dimensional tables) is determined by how `index_2` is measured.

Examples

```
em_lut_template (output_by_cap_and_trans) {
    variable_1 : total_output_net_capacitance ;
    variable_2 : input_transition_time ;
```

```

    index_1 ("0.0, 5.0, 20.0");
    index_2 ("0.0, 1.0, 2.0");
}
em_lut_template (input_by_trans) {
    variable_1 : input_transition_time;
    index_1 ("0.0, 1.0, 2.0");
}

```

1.9.13 fall_net_delay Group

The fall_net_delay group is defined at the library level, as shown here:

```

library (name) {
    fall_net_delay (name){
        ... fall    net      delay    description ...
    }
}

```

Complex Attributes

```

index_1 ("float,...,float");
index_2 ("float,...,float");
values ("float,...,float", "float,...,float");

```

The rise_net_delay and the fall_net_delay groups define, in the form of lookup tables, the values for rise and fall net delays. This indexing allows the library developer to model net delays as any function of output_transition and rc_product.

The net delay tables in one library have no effect on computations related to cells from other libraries. To overwrite the lookup table default index values, specify the new index values before the net delay values.

[Example 1-4](#) shows an example of the fall_net_delay group.

Example 1-4 fall_net_delay Group

```

fall_net_delay (net_delay_table_template) {
    index_1 ("0, 1, 2");
    index_2 ("1, 0, 2");
    values ("0.00, 0.57", "0.10, 0.48");
}

```

1.9.14 fall_transition_degradation Group

The fall_transition_degradation group is defined at the library level, as shown here:

```

library (name) {
    fall_transition_degradation(name) {
        ... fall    transition   degradation   description ...
    }
}

```

Complex Attributes

```

index_1 ("float, ..., float");
index_2 ("float,     ...,     float");
values ("float, ..., float", "float, ..., float");

```

The fall_transition_degradation group and the rise_transition_degradation group describe, in the form of lookup tables, the transition degradation functions for rise and fall transitions. The lookup tables are indexed by the transition time at the net driver and the connect delay between the driver and a particular load. This indexing allows the library developer to model degraded transitions as any function of output-pin transition and connect delay between the driver and the load.

Transition degradation tables are used for indexing into any delay table in a library that has the input_net_transition, constrained_pin_transition, or related_pin_transition table parameters in the lu_table_template group.

The transition degradation tables in one library have no effect on computations related to cells from other libraries. [Example 1-5](#) shows a fall_transition_degradation group.

Example 1-5 fall_transition_degradation Group

```
fall_transition_degradation(trans_deg) {  
    index_1 ("1, 0, 2") ;  
    index_2 ("0, 1, 2") ;  
    values ("0.0, 0.8", "1.0, 1.8") ;  
}
```

1.9.15 faults_lut_template

To model yield information, use the faults_lut_template group to specify fab names and time ranges applicable for all fault tables in the .lib file. You define fault tables in the cell-level functional_yield_metric group using the average_number_of_faults attribute. See [“functional yield metric Group”](#). Define the faults_lut_template group at the library level, as shown here:

Syntax

```
library (name_string) {  
    ...  
    faults_lut_template(name_string) {  
        variable_1 : value_enum ;  
        variable_2 : value_enum ;  
        index_1 ("float, ..., float");  
        index_2 ("float, ..., float");  
    }  
}
```

Simple Attributes

```
variable_1  
variable_2
```

Complex Attributes

```
index_1  
index_2
```

The following are the values you can assign to the variables:

```
faults_lut_template(name_string) {  
    variable_1 : fab_name;  
    variable_2 : time_range;  
}
```

Example

```
library ( my_library_name ) {  
    ...  
    faults_lut_template ( my_faults_temp ) {  
        variable_1 : fab_name;  
        variable_2 : time_range;  
        index_1 ( " fab1, fab2, fab3 " );  
        index_2 ( " 2005.01, 2005.07, 2006.01, 2006.07 " );  
    }  
    ...  
    cell ( and2 ) {  
        ...  
        functional_yield_metric () {  
            average_number_of_faults ( my_faults_temp ) {  
                values ( " 73.5, 78.8, 85.0, 92 ",  
                    " 74.3, 78.7, 84.8, 92.2 ",  
                    " 72.2, 78.1, 84.3, 91.0 " );  
            }  
        }  
    }  
}
```

```
 } /* end of cell */  
 } /* end of library */
```

This template example represents fault data for three fab lines (fab1, fab2, fab3) and holds fault data collected for four time ranges:

- 2005.01 represents a time range from January 2005 to June 2005
- 2005.07 represents a time range from July 2005 to December 2005
- 2006.01 represents a time range from January 2006 to June 2006
- 2006.07 represents July 2006 or later

For details on the `functional_yield_metric` group, see [“functional_yield_metric Group”](#).

1.9.16 `input_voltage` Group

An `input_voltage` group is defined in the `library` group to designate a set of input voltage ranges for your cells.

Syntax

```
library (name_string) {  
    input_voltage (name_string) {  
        vil : float | expression ;  
        vih : float | expression ;  
        vimin : float | expression ;  
        vimax : float | expression ;  
    }  
}
```

`vil`

The maximum input voltage for which the input to the core is guaranteed to be a logic 0.

`vih`

The minimum input voltage for which the input to the core is guaranteed to be a logic 1.

`vimin`

The minimum acceptable input voltage.

`vimax`

The maximum acceptable input voltage.

After you define an `input_voltage` group, you can use its name with the `input_voltage` simple attribute in a `pin` group of a cell. For example, you can define an `input_voltage` group with a set of high and low thresholds and minimum and maximum voltage levels and use the `pin` group to assign those ranges to the cell pin, as shown here.

Example

```
pin() {  
    ...  
    input_voltage : my_input_voltages ;  
    ...  
}
```

The value of each attribute is expressed as a floating-point number, an expression, or both. [Table 1-4](#) lists the predefined variables that can be used in an expression.

Table 1-4 Voltage-Level Variables for the `input_voltage` Group

CMOS/BiCMOS variable	Default value
VDD	5V
VSS	0V
VCC	5V

The default values represent nominal operating conditions. These values fluctuate with the voltage range defined in the `operating_conditions` group.

All voltage values are in the units you define with the library group `voltage_unit` attribute.

[Example 1-6](#) shows a collection of `input_voltage` groups.

Example 1-6 input_voltage Groups

```
input_voltage(CMOS) {
    vil : 0.3 * VDD ;
    vih : 0.7 * VDD ;
    vimin : -0.5 ;
    vimax : VDD + 0.5 ;
}

input_voltage(TTL_5V) {
    vil : 0.8 ;
    vih : 2.0 ;
    vimin : -0.5 ;
    vimax : VDD + 0.5 ;
}
```

1.9.17 fpga_isd Group

You can define one or more `fpga_isd` groups at the library level to specify the drive current, I/O voltages, and slew rates for FPGA parts and cells.

Note:

When you specify more than one `fpga_isd` group, you must also define the library-level `default_fpga_isd` attribute to specify which `fpga_isd` group to use as the default.

Syntax

```
library (name_string) {
    fpga_isd (fpga_isd_name_string) {
        ... description ...
    }
}
```

Example

```
fpga_isd (part_cell_isd) {
    ... description ...
}
```

Simple Attributes

```
drive
io_type
slew
```

drive Simple Attribute

The `drive` attribute is optional and specifies the output current of the FPGA part or the FPGA cell.

Syntax

```
drive : value_id
```

`value`

A string

Example

```
drive : 24 ;
```

io_type Simple Attribute

The `io_type` attribute is required and specifies the input or output voltage of the FPGA part or the FPGA cell.

Syntax

```
io_type : valueid
```

`value`

A string

Example

```
io_type : LVTTL ;
```

slew Simple Attribute

The `slew` attribute is optional and specifies whether the slew of the FPGA part or the FPGA cell is FAST or SLOW.

Syntax

```
slew : valueid
```

`value`

Valid values are FAST and SLOW.

Example

```
slew : FAST ;
```

1.9.18 iv_lut_template Group

The `iv_lut_template` group describes a template for specifying a current-voltage curve. The template specifies I-V output voltage of the breakpoints.

Syntax

```
library (namestring) {
    iv_lut_template (template_namestring) {
        ... template description ...
    }
}
```

Simple Attribute

```
variable_1
```

Complex Attribute

```
index_1
```

variable_1 Simple Attribute

You can assign the following value to the template for one-dimensional current-voltage tables.

```
variable_1 : iv_output_voltage ;
```

index_1 Complex Attribute

```
index_1 ("float, ..., float");
```

Example

```
library (my_library) {
```

```

...
iv_lut_template (my_template) {
    variable_1 : iv_output_voltage ;
    index_1 ("-1, -0.1, 0.8, 1.6, 2" ) ;
}
...
}
```

1.9.19 lu_table_template Group

Use the lu_table_template group to define templates of common information to use in lookup tables. Define the lu_table_template group at the library level, as shown here:

Syntax

```

library (name_string) {

...
lu_table_template(name_string) {
    variable_1 : value_enum ;
    variable_2 : value_enum ;
    variable_3 : value_enum ;
    index_1 ("float, ..., float");
    index_2 ("float, ..., float");
    index_3 ("float, ..., float");
    domain(domain_1_name_string) {
        ...
    }
}
}
```

Simple Attributes

```

variable_1
variable_2
variable_3
```

Complex Attributes

```

index_1
index_2
index_3
```

Group

```
domain
```

normalized_voltage Variable

The normalized_voltage variable is specified under the lu_table_template table in order to describe a collection of waveforms under various input slew values. For a given input slew in index_1 (for example, index_1[0] = 1.0 ns), the index_2 values are a set of points that represent how the voltage rises from 0 to VDD in a rise arc, or from VDD to 0 in a fall arc.

Note:

The normalized_voltage variable can be used only with driver waveform syntax. For more information, see the “Driver Waveform Support” section in the “Timing Arcs” chapter in the Liberty User Guide, Volume 1.

Syntax

```

lu_table_template (waveform_template) {
    variable_1 : input_net_transition;
    variable_2 : normalized_voltage;
    index_1 ("0.1, 0.2, 0.3, 0.4, 0.5, 0.6, 0.7");
    index_2 ("0.1, 0.2, 0.3, 0.4, 0.5, 0.6, 0.7, 0.8, 0.9");
}
```

Rise Arc Example

```
normalized_driver_waveform (waveform_template) {
    index_1 ("1.0"); /* Specifies the input net transition*/
    index_2 ("0, 0.1, 0.3, 0.5, 0.7, 0.9, 1.0"); /* Specifies the voltage
normalized
    to VDD */
    values ("0, 0.2, 0.4, 0.6, 0.8, 0.9, 1.1"); /* Specifies the time when
the
    voltage reaches the index_2
values*/
}
```

The lu_table_template table represents an input slew of 1.0 ns, when the voltage is 0%, 10%, 30%, 50%, 70%, 90% or 100% of VDD, and the time values are 0, 0.2, 0.4, 0.6, 0.8, 0.9, 1.1 (ns). Note that the time value can go beyond the corresponding input slew because a long tail might exist in the waveform before it reaches the final status.

variable_1, variable_2, variable_3, and variable_4 Simple Attributes

In Composite Current Source (CCS) Noise Tables:

Use lookup tables to create the lookup-table templates for the following groups within the ccsn_first_stage and ccsn_last_stage groups: the dc_current group and vectors of the output_voltage_rise group, output_voltage_fall group, propagated_noise_low group, and propagated_noise_high group.

You can assign the following values to the variables to specify the template used for the dc_current tables:

```
lu_table_template(<dc_template_name>) {
    variable_1 : input_voltage;
    variable_2 : output_voltage;
}
```

You can assign the following values to the variables to specify the template used for the vectors of the output_current_rise group and output_current_fall group.

```
lu_table_template(<output_voltage_template_name>) {

    variable_1 : input_net_transition;
    variable_2 : total_output_net_capacitance;
    variable_3 : time;
}
```

You can assign the following values to the variables to specify the template used for the vector's of the propagated_noise_low and propagated_noise_high group.

```
lu_table_template(<propagated_noise_template_name>) {
    variable_1 : input_noise_height;
    variable_2 : input_noise_width;
    variable_3 : total_output_net_capacitance;
    variable_4 : time;
```

In Timing Delay Tables:

Following are the values that you can assign for variable_1, variable_2, and variable_3 to the templates for timing delay tables:

```
input_net_transition | total_output_net_capacitance |
output_net_length | output_net_wire_cap |
output_net_pin_cap |
related_out_total_output_net_capacitance |
related_out_output_net_length |
related_out_output_net_wire_cap |
related_out_output_net_pin_cap ;
```

The values that you can assign to the variables of a table specifying timing delay depend on whether the table is one-, two-, or three-dimensional.

In Constraint Tables:

Following are the values (divided into sets) that you can assign for variable_1, variable_2, and variable_3 to the templates for constraint tables:

```
constrained_pin_transition | related_pin_transition |
related_out_total_output_net_capacitance |
related_out_output_net_length |
related_out_output_net_wire_cap |
related_out_output_net_pin_cap ;
```

In Wire Delay Tables:

The following is the value set that you can assign for variable_1, variable_2, and variable_3 to the templates for wire delay tables:

```
fanout_number | fanout_pin_capacitance | driver_slew ;
```

The values that you can assign to the variables of a table specifying wire delay depends on whether the table is one-, two-, or three-dimensional.

In Net Delay Tables:

The following is the value set that you can assign for variable_1 and variable_2 to the templates for net delay tables:

```
output_transition | rc_product ;
```

The values that you can assign to the variables of a table specifying net delay depend on whether the table is one- or two-dimensional.

In Degradation Tables:

The following values apply only to templates for transition time degradation tables:

```
variable_1 : output_pin_transition | connect_delay ;
variable_2 : output_pin_transition | connect_delay ;
```

The cell degradation table template allows only one-dimensional tables:

```
variable_1 : input_net_transition
```

Following are the rules for the relationship between variables and indexes:

- If you have variable_1, you must have index_1.
- If you have variable_1 and variable_2, you must have index_1 and index_2.
- If you have variable_1, variable_2, and variable_3, you must have index_1, index_2, and index_3.

CMOS Nonlinear Timing Model Examples

```
lu_table_template (constraint) {
    variable_1 : related_pin_transition ;
    variable_2 : related_out_total_output_net_capacitance ;
    variable_3 : constrained_pin_transition ;
    index_1 ("1.0, 1.5, 2.0") ;
    index_2 ("1.5, 1.0, 2.0") ;
    index_3 ("1.0, 2.0, 1.5") ;
}

lu_table_template (basic_template) {
    variable_1 : input_net_transition;
    variable_2 : total_output_net_capacitance;
    index_1 ("0.0, 0.5, 1.5, 2.0");
    index_2 ("0.0, 2.0, 4.0, 6.0");
}
```

Syntax

```
calc_mode : namestring;
```

name

The name of the associated process mode.

domain Group

In the case of a piecewise lookup table, use one or more domain groups in the lu_table_template group to specify subsets of the lookup table template. Variables in a domain group can be the variables in the lu_table_template group.

Syntax

```
library (name_string) {
    lu_table_template (template_name_id) {
        domain(domain_1_name_id) {
            ... domain description ...
        }
    }
}
```

domain_1_name

A string representing the name of the domain.

Simple Attributes

```
calc_mode
variable_1
variable_2
variable_3
```

Complex Attributes

```
index_1
index_2
index_3
```

calc_mode Simple Attribute

An optional attribute, you can use calc_mode to specify an associated process mode.

Example

```
calc_mode : OC1 ;
```

variable_1, variable_2, and variable_3 Simple Attributes

The variables in a domain group are a subset of the variables in the lu_table_template group.

1.9.20 maxcap_lut_template Group

The maxcap_lut_template group defines a template for specifying the maximum acceptable capacitance of an input or an output pin.

Syntax

```
library (name_string) {
    maxcap_lut_template (template_name_id) {
        ... template description ...
    }
}
```

Simple Attributes

```
variable_1
variable_2
```

Complex Attributes

```
index_1  
index_2
```

variable_1 and variable_2 Simple Attributes

The value you can assign to variable_1 is frequency. The value you can assign to variable_2 is input_transition_time.

index_1 and index_2 Complex Attributes

Along with variable_1 and variable_2, you must specify the index values.

```
index_1 ("float, ..., float") ;  
index_2 ("float, ..., float") ;
```

Example

```
library (my_library) {  
    ...  
    maxcap_lut_template (my_template) {  
        variable_1 : frequency ;  
        variable_2 : input_transition_time ;  
        index_1 ("100.0000, 200.0000") ;  
        index_2 ("0.0, 0.0") ;  
    }  
    ...  
}
```

1.9.21 maxtrans_lut_template Group

The maxtrans_lut_template group defines a template for specifying the maximum acceptable transition time of an input or an output pin.

Syntax

```
library (name_string) {  
    maxtrans_lut_template (template_name_id) {  
        ... template description ...  
    }  
}
```

Simple Attributes

```
variable_1  
variable_2
```

Complex Attributes

```
index_1  
index_2
```

variable_1 and variable_2 Simple Attributes

The value you can assign to variable_1 is frequency. The value you can assign to variable_2 is input_transition_time.

index_1 and index_2 Complex Attributes

Along with variable_1 and variable_2, you must specify the index values.

```
index_1 ("float, ..., float") ;  
index_2 ("float, ..., float") ;
```

Example

```

library (my_library) {
    ...
    maxtrans_lut_template (my_template) {
        variable_1 : frequency ;
        variable_2 : input_transition_time ;
        index_1 ("100.0000, 200.0000") ;
        index_2 ("0.0, 0.0") ;
        values ("0, 0.2, 0.4, 0.6, 0.8, 0.9, 1.1") ;
    }
    ...
}

```

1.9.22 noise_lut_template Group

The `noise_lut_template` group defines a template for specifying a noise immunity curve. Use the template to specify the input noise width output load and breakpoints that represent the input height table.

Syntax

```

library (name_string) {
    noise_lut_template (template_name_id) {
        ... template description ...
    }
}

```

Simple Attributes

```

variable_1
variable_2

```

Complex Attributes

```

index_1
index_2

```

variable_1 and variable_2 Simple Attributes

The values you can assign to `variable_1` and `variable_2` are `input_noise_width` and `total_output_net_capacitance`.

index_1 and index_2 Complex Attributes

Along with `variable_1` and `variable_2`, you must define both `index_1` and `index_2`.

```

index_1 ("float, ..., float");
index_2 ("float, ..., float");

```

Example

```

library (my_library) {
    ...
    noise_lut_template (my_template) {
        variable_1 : input_noise_width ;
        variable_2 : total_output_capacitance ;
        index_1 ("0, 0.1, 2") ;
        index_2 ("0, 2") ;
    }
    ...
}

```

1.9.23 normalized_driver_waveform Group

The library-level `normalized_driver_waveform` group represents a collection of driver waveforms under various input slew values. The `index_1` specifies the input slew and `index_2` specifies the normalized voltage. Note that the slew index in the `normalized_driver_waveform` table is based on the slew derate and slew trip points of the library (global values). When applied on a pin or cell with different slew or slew derate, the new slew should be interpreted from the waveform.

Simple Attributes

```
driver_waveform_name
```

Complex Attributes

```
index_1  
index_2  
values
```

Syntax

```
normalized_driver_waveform(waveform_template_name) {  
    driver_waveform_name : string; /* Specifies the name of  
        the driver waveform table */  
    index_1 ("float..., float"); /* Specifies input net  
        transition */  
    index_2 ("float..., float"); /* Specifies normalized  
        voltage */  
    values ( "float..., float", \ /* Specifies the time in  
        library units */  
        ..., \  
        "float..., float");  
}
```

Example

```
normalized_driver_waveform (waveform_template) {  
    index_1 ("1.0"); /* Specifies the input net transition*/  
    index_2 ("0, 0.1, 0.3, 0.5, 0.7, 0.9, 1.0"); /* Specifies the voltage  
normalized  
        to VDD */  
    values ("0, 0.2, 0.4, 0.6, 0.8, 0.9, 1.1"); /* Specifies the time when  
the  
        voltage reaches the index_2  
values*/  
}
```

driver_waveform_name Simple Attribute

The `driver_waveform_name` string attribute differentiates the driver waveform table from other driver waveform tables when multiple tables are defined. Cell-specific and rise- and fall-specific driver waveform usage modeling depend on this attribute.

The `driver_waveform_name` attribute is optional. You can define a driver waveform table without the attribute, but there can be only one table in a library, and that table is regarded as the default driver waveform table for all cells in the library. If more than one table is defined without the attribute, the last table is used. The other tables are ignored and not stored in the .db file.

Syntax

```
driver_waveform_name : string ;
```

Example

```
normalized_driver_waveform (waveform_template) {  
    driver_waveform_name : clock_driver ;  
    index_1 ("0.15, 0.25, 0.35, 0.45, 0.55, 0.65, 0.75");  
    index_2 ("0.1, 0.2, 0.3, 0.4, 0.5, 0.6, 0.7, 0.8, 0.9");  
    values ("0.012, 0.03, 0.045, 0.06, 0.075, 0.090, 0.105,  
        0.13, 0.145", \  
        ... ...  
        "0.1, 0.2, 0.3, 0.4, 0.5, 0.6, 0.7, 0.8, 0.9");
```

1.9.24 operating_conditions Group

Use this group to define operating conditions; that is, process, voltage, and temperature. You define an `operating_conditions` group at the library-level, as shown here:

Syntax

```
library (name_string) {
```

```
operating_conditions (namestring) {
    ... operating conditions description ...
}
```

Simple Attributes

```
calc_mode : nameid ;
parameteri : float ;
process : float ;
temperature : float ;
tree_type : valueenum ;
voltage : float ;
```

Complex Attribute

```
power_rail (string,   float) ; /* one or more */
```

calc_mode Simple Attribute

An optional attribute, you can use calc_mode to specify an associated process mode.

Syntax

```
calc_mode : nameid ;
```

name

The name of the associated process mode.

parameter i Simple Attribute

Use this optional attribute to specify values for up to five user-defined variables.

Syntax

```
parameteri : valuefloat; /* i = 1..5 */
```

value

A floating-point number representing the variable value.

process Simple Attribute

Use the process attribute to specify a scaling factor to account for variations in the outcome of the actual semiconductor manufacturing steps.

Syntax

```
process : valuefloat ;
```

value

A floating-point number from 0 through 100.

temperature Simple Attribute

Use the temperature attribute to specify the ambient temperature in which the design is to operate.

Syntax

```
temperature : valuefloat ;
```

value

A floating-point number representing the ambient temperature.

tree_type Simple Attribute

Use the `tree_type` attribute to specify the environment interconnect model.

Syntax

```
tree_type : valueenum ;  
  
value  
  
Valid values are best_case_tree, balanced_tree, and worst_case_tree.
```

voltage Simple Attribute

Use the `voltage` attribute to specify the operating voltage of the design; typically 5 volts for a CMOS library.

Syntax

```
voltage : valuefloat ;  
  
value  
  
A floating-point number from 0 through 1000, representing the absolute value of the actual voltage.
```

power_rail Complex Attribute

Use the `power_rail` attribute in the `operating_conditions` group to specify a voltage value for each power supply.

Syntax

```
power_rail (power_supply_namestring, voltage_valuefloat) ;  
  
power_supply_name  
  
Specifies a power supply name that can be used later for reference. You can refer to it by assigning a string to the rail connection input_signal_level or the output_signal_level attribute.  
  
voltage_value  
  
Identifies the voltage value associated with the power_supply_name. The value is specified by the units you define in the library group voltage_unit attribute.
```

Example

```
operating_conditions (MPSS) {  
    calc_mode : worst ;  
    process : 1.5 ;  
    temperature : 70 ;  
    voltage : 4.75 ;  
    tree_type : worse_case_tree ;  
    power_rail (VDD1, 4.8) ;  
    power_rail (VDD2, 2.9) ;  
}
```

1.9.25 output_current_template Group

Use the `output_current_template` group to describe a table template for composite current source (CCS) modeling.

Syntax

```
library (namestring) {  
    output_current_template(template_nameid) {  
        variable_1 : valueenum ;  
        variable_2 : valueenum ;  
        variable_3 : valueenum ;  
        index_1 : ("float, ..., float") ;  
        index_2 : ("float, ..., float") ;  
        index_3 : ("float, ..., float") ;  
    }  
}
```

Simple Attributes

```
variable_1  
variable_2  
variable_3
```

Complex Attributes

```
index_1  
index_2  
index_3
```

variable_1, variable_2, and variable_3 Simple Attributes

The table template specifying composite current source (CCS) driver and receiver models can have three variables: `variable_1`, `variable_2`, and `variable_3`. The valid values for `variable_1` and `variable_2` are `input_net_transition` and `total_output_net_capacitance`. The only valid value for `variable_3` is `time`.

index_1, index_2, and index3 Complex Attributes

Along with `variable_1` and `variable_2`, you must specify the index values.

```
index_1 ("float, ..., float") ;  
index_2 ("float, ..., float") ;
```

Example

```
library (my_library) {  
    ...  
    output_current_template (CCT) {  
        variable_1 : input_transition ;  
        variable_2 : total_output_net_capacitance ;  
        variable_3 : time ;  
        index_1 ("0.1, 0.2") ;  
        index_2 ("1.0, 2.0") ;  
        index_3 ("0.1, 0.2, 0.3, 0.4, 0.5") ;  
    }  
    ...  
}
```

1.9.26 *output_voltage* Group

You define an `output_voltage` group in the `library` group to designate a set of output voltage level ranges to drive output cells.

Syntax

```
library (namestring) {  
    output_voltage(namestring) {  
        vol : float | expression ;  
        voh : float | expression ;  
        vomin : float | expression ;  
        vomax : float | expression ;  
    }  
    output_voltage (namestring) {  
        ... output_voltage description ... ;  
    }  
}
```

The value for `vol`, `voh`, `vomin`, and `vomax` is a floating-point number or an expression. An expression allows you to define voltage levels as a percentage of VSS or VDD.

`vol`

The maximum output voltage generated to represent a logic 0.

voh

The minimum output voltage generated to represent a logic 1.

vomin

The minimum output voltage the pad can generate.

vomax

The maximum output voltage the pad can generate.

[Table 1-5](#) lists the predefined variables you can use in an `output_voltage` expression attribute. Separate variables are defined for CMOS and BiCMOS.

Table 1-5 Voltage-Level Variables for the `output_voltage` Group

CMOS/BiCMOS variable	Default value
VDD	5V
VSS	0V
VCC	5V

The default values represent nominal operating conditions. These values fluctuate with the voltage range defined in the `operating_conditions` groups.

All voltage values are in the units you define with the `voltage_unit` attribute within the `library` group.

[Example 1-7](#) shows an example of an `output_voltage` group.

Example 1-7 `output_voltage` Group

```
output_voltage(GENERAL) {  
    vol : 0.4 ;  
    voh : 2.4 ;  
    vomin : -0.3 ;  
    vomax : VDD + 0.3 ;  
}
```

1.9.27 `part` Group

You use a `part` group to describe a specific FPGA device. Use multiple `part` groups to describe multiple devices.

Syntax

```
library (name_string) {  
    part(name_string) {  
        ...device description...  
    }  
    part(name_string) {  
        ...device description...  
    }  
}
```

Simple Attributes

```
default_step_level  
fpga_isd  
num_blockrams  
num_cols  
num_ffs  
num_luts  
num_rows  
pin_count
```

Complex Attributes

```
max_count  
valid_speed_grade  
valid_step_level
```

Group

```
speed_grade
```

default_step_level Simple Attribute

Use the `default_step_level` attribute to specify one of the valid step levels as the default for the FPGA device. You specify valid step levels with the `valid_step_levels` complex attribute.

Syntax

```
default_step_level : "nameid" ;  
"name"
```

An alphanumeric string identifier, enclosed within double quotation marks, representing the default step level for the device.

Example

```
default_step_level ("STEP0") ;
```

fpga_isd Simple Attribute

Use this optional attribute to reference the `drive`, `io_type`, and `slew` information contained in a library-level `fpga_isd` group.

Syntax

```
fpga_isd : fpga_isd_nameid;  
fpga_isd_name
```

The name of a library-level `fpga_isd` group.

Example

```
fpga_isd : part_cell_isd ;
```

num_blockrams Simple Attribute

Use the `num_blockrams` attribute to specify the number of block select RAMs on the FPGA device.

Syntax

```
num_blockrams : valueint ;  
value
```

An integer representing the number of block select RAMs on the device.

Example

```
num_blockrams : 10 ;
```

num_cols Simple Attribute

Use the `num_cols` attribute to specify the number of logic block columns on the FPGA device.

Syntax

```
num_cols : valueint ;  
value
```

An integer representing the number of logic blocks on the FPGA device.

Example

```
num_cols : 30 ;
```

num_ffs Simple Attribute

Use the `num_ffs` attribute to specify the number of flip-flops on the device.

Syntax

```
num_ffs : valueint ;
```

value

An integer representing the number of flip-flops on the FPGA device.

Example

```
num_ffs : 2760 ;
```

num_luts Simple Attribute

Use the `num_luts` attribute to specify the total number of lookup tables available for the FPGA device. The `num_luts` value is used to determine the total number of slices that make up all the configurable logic blocks (CLBs) of the FPGA device, as shown in the following equation.

Syntax

```
num_luts : valueint ;
```

value

An integer representing the number of lookup tables on the FPGA device.

Example

```
num_luts : 100 ;
```

num_rows Simple Attribute

Use the `num_rows` attribute to specify the number of logic block rows on the FPGA device.

Syntax

```
num_rows : valueint ;
```

value

An integer representing the number of block rows on the FPGA device.

Example

```
num_rows : 20 ;
```

pin_count Simple Attribute

Use the `pin_count` attribute to specify the number of pins on the device.

Syntax

```
pin_count : valueint ;
```

value

An integer representing the number of pins on the FPGA device.

Example

```
pin_count : 94 ;
```

max_count Complex Attribute

Use the `max_count` attribute to specify the resource constraints for the FPGA device.

Syntax

```
max_count (resource_nameid, valueint) ;
```

resource_name

The name of the resource being constrained.

value

An integer representing the maximum constraint of the resource.

Example

```
max_count (BUGFGTS, 4) ;
```

valid_speed_grade Complex Attribute

Use the `valid_speed_grade` attribute to specify the various speed grades for the FPGA device.

Syntax

```
valid_speed_grade ("name_1id", "name_2id", ..."name_nid") ;
```

“name_1”, “name_2”, “name_n”

A list of alphanumeric string identifiers, each enclosed within double quotation marks, represents the various speed grades for the device. Each identifier corresponds to an operating condition under which the library is characterized and under which the device is used.

Example

```
valid_speed_grade ("−6", "−5", "−4") ;
```

valid_step_levels Complex Attribute

Use the `valid_step_levels` attribute to specify the various step levels for the FPGA device.

Syntax

```
valid_step_levels ("name_1id", "name_2id", ..."name_nid") ;
```

“name_1”, “name_2”, “name_n”

A list of alphanumeric string identifiers, each enclosed within double quotation marks, representing various step levels for the device. Each identifier corresponds to an operating condition under which the library is characterized and under which the device is used.

Example

```
valid_step_levels ("STEP0", "STEP1", "STEP2") ;
```

speed_grade Group

The `speed_grade` group associates a valid speed grade with a valid step level.

Syntax

```

part(name_string) {
    ...
    speed_grade (name_string) {
        ...step_level description...
    }
}

name

```

Specifies one of the valid speed grades listed in the `valid_speed_grade` attribute.

Simple Attribute

`fpga_isd`

Complex Attribute

`step_level`

Example

```

speed_grade ( ) {
    ...
}

```

fpga_isd Simple Attribute

Use this optional attribute to reference the `drive`, `io_type`, and `slew` information contained in a library-level `fpga_isd` group.

Syntax

`fpga_isd : fpga_isd_name_id;`

`fpga_isd_name`

The name of a library-level `fpga_isd` group.

Example

`fpga_isd : part_cell_isd ;`

step_level Complex Attribute

Use the `step_level` attribute to specify one of the valid step levels listed in the `valid_step_level` attribute.

Syntax

`step_level (name_string) ;`

`name`

The alphanumeric identifier for a valid step level.

Example

`step_level () ;`

1.9.28 pg_current_template Group

In the composite current source (CCS) power library format, instantaneous power data is specified as 1- to n- dimensional tables of current waveforms in the `pg_current_template` group. This library-level group creates templates of common information that power and ground current vectors use.

Syntax

```

library (name_string) {
    pg_current_template (template_name_id) {
        ... template description ...
    }
}

```

Simple Attributes

```

variable_1
variable_2
variable_3
variable_4

```

Complex Attributes

```

index_1
index_2
index_3
index_4

```

variable_1, variable_2, variable_3, and variable_4 Simple Attributes

The variable values can be `input_net_transition`, `total_output_net_capacitance`, and `time`. The last variable must be `time` and is required. The group can contain none or at most one `input_net_transition` variable. It can contain none or up to two `total_output_net_capacitance` variables.

index_1, index_2, index_3, and index_4 Complex Attributes

The index values are optional.

```

index_1 ("float, ...") ;
index_2 ("float, ...") ;
index_3 ("float, ...") ;
index_4 ("float, ...") ;

```

Example

```

library (my_library) {
    ...
    pg_current_template (my_template) {
        variable_1 : input_net_transition ;
        variable_2 : total_output_net_capacitance ;
        variable_3 : total_output_net_capacitance ;
        variable_4 : time ;
        index_1 ("100.0000, 200.0000") ;
        index_2 ("0.0, 0.0") ;
        index_3 ("0.0, 0.0") ;
        index_4 ("0.0, 0.0") ;
    }
    ...
}

```

1.9.29 poly_template Group

Use the `poly_template` group to define a template of polynomials to be used by the `timing` group. For reference purposes, the `poly_template` group requires a name.

Syntax

```

library (library_name_id) {
    ...
    poly_template(poly_template_name_id) {
        variables(variable_i_enum, ..., variable_n_enum) ;
        variable_1_range(min_value_float, max_value_float) ;
        ...
        variable_n_range(min_value_float, max_value_float) ;
        mapping(value_enum, power_rail_nameid) ;
    }
}

```

```

orders () ;
domain(domain_name_id) {
    calc_mode : name_id ;
    variables(variable_1_enum, ..., variable_n_enum) ;
    variable_1_range(min_value_float max_value_float) ;
    ...
    variable_n_range(min_value_float max_value_float) ;
    mapping(value_enum, power_rail_name_id) ;
    orders () ;
}
}

poly_template_name

```

The name of the template.

Complex Attributes

```

variables
variable_n_range
mapping
orders

```

Group

domain

variables Complex Attribute

Use the *variables* attribute to specify the name of a variable or a list of the variables that characterizes library cells for timing, noise immunity, and noise propagation. The variable or variables are used in the polynomial equations.

Note:

At least one variable name is required.

Syntax

```
variables(variable_1_enum, ..., variable_n_enum) ;
```

variable_1 , ..., *variable_n*

The values depend on the group as shown in the following.

The valid variables for a noise immunity template referenced by a noise immunity polynomial, such as *noise_immunity_high*, are:

```
input_noise_width | total_output_net_capacitance | voltage
| voltagei | temperature | parametern
```

The valid variables for a noise propagation template referenced by a noise propagation group, such as *propagated_noise_height_high*, are:

```
input_noise_height | input_noise_width |
input_noise_time_to_peak | total_output_net_capacitance |
voltage, voltagei, temperature | parametern
```

The valid variables in a steady state group, such as *steady_state_current_high*, are:

```
iv_output_voltage | voltage | voltagei | temperature |
parametern
```

The valid variables in a timing group are generally divided into four sets:

- Set 1

- `input_net_transistion|constrained_pin_transition`
- Set 2
 - `total_output_net_capacitance|output_net_length,output_net_wire_cap|output_net_pin_cap|related_pin_transistion`
- Set 3
 - `related_out_total_output_net_capacitance|related_out_output_net_length|related_out_output_net_wire_cap|related_out_output_net_pin_cap`
- Set 4
 - `temperature,voltage|voltage i`

In Set 4, `voltage` is the default power supply voltage for the design and `voltagel` is normally used only when your design requires dual power supplies for the cell; for example, for a level shifter.

For a one-dimensional polynomial, substitute the values in Sets 1 and 2 for `variable_1`. For a two-dimensional polynomial, substitute the values in Sets 1, 2, and 4 for `variable_1` and `variable_2`. For polynomials with three or more dimensions, substitute the values in Sets 1, 2, 3, and 4 for `variable_1`, `variable_2`, ..., `variable_n`.

Example

```
variables( temperature, voltage,
          total_output_net_capacitance) ;
```

variable_n_range Complex Attribute

Use the `variable_n_range` attribute to specify the range of the value for the *n*th variable in the `variables` attribute.

Note:

A `variable_n_range` attribute is required for each variable listed in the `variables` attribute.

Syntax

```
variable_n_range(float, float) ;
```

float, *float*

Floating-point number pairs that specify the value range.

Example

```
variable_2_range(1.5, 2.0) ;
```

mapping Complex Attribute

The `mapping` attribute specifies the relationship between `voltage` attribute (as used in the polynomial) and the corresponding `power_rail` attribute defined in the `power_supply` attribute.

Note:

You can have no more than two `mapping` attributes in a `poly_template` group.

Syntax

```
mapping(value_enum, power_rail_name_id);
```

value

Valid values are `voltage` and `voltagel`.

power_rail_name

Identifies the corresponding power rail.

Example

```
mapping(voltage, VDD2) ;
```

orders Complex Attribute

Use the `orders` attribute to specify the order for the variables for the polynomial.

Syntax

```
variable_n_range(float, float);
```

Example

```
variable_2_range(1.5, 2.0);
```

domain Group

In the case of a piecewise polynomial, use one or more `domain` groups in the `poly_template` group. The variables in a `domain` group are the same as the variables in the `poly_template` group.

Note:

A domain name is required and the name must be unique.

Syntax

```
library (library_name_id) {
    poly_template (poly_template_name_id) {
        ...
        domain (domain_name_id) {
            ...
        }
    }
}
```

Simple Attribute

```
calc_mode
```

Complex Attributes

```
variables
variable_n_range
mapping
orders
```

calc_mode Simple Attribute

Use the `calc_mode` attribute to specify the associated process mode.

Syntax

```
calc_mode : name_id;
```

`name`

The name of the associated process mode.

Example

```
calc_mode : best ;
```

variables, variable_n_range, mapping, and orders Complex Attributes

For the description of how each of these attributes is used, see the [“poly_template Group”](#).

Example

```
domain (D1) {
    calc_mode : best ;
    variables (temperature, voltage,
```

```

        total_output_net_capacitance);
variable_1_range (1.5, 2.0);
variable_2_range (1.0, 2.0);
variable_3_range (1.0, 2.0);
mapping(voltage, VDD2);
}

```

1.9.30 power_lut_template Group

The `power_lut_template` group is defined within the `library` group, as shown here:

Syntax

```

library (name) {
    power_lut_template (template_name) {
        variable_1 : input_transition_time |
            total_output_net_capacitance
            |equal_or_opposite_output_net_capacitance ;
        variable_2 : input_transition_time |
            total_output_net_capacitance
            |equal_or_opposite_output_net_capacitance ;
        variable_3 : input_transition_time |
            total_output_net_capacitance
            |equal_or_opposite_output_net_capacitance ;
        index_1 ("float, ..., float") ;
        index_2 ("float, ..., float") ;
        index_3 ("float, ..., float") ;
    }
}

```

Simple Attributes

```

variable_1
variable_2
variable_3

```

Complex Attributes

```

index_1
index_2
index_3

```

Group

```
domain
```

The `power_lut_template` group creates a template of the index used by the `internal_power` group (defined in a `pin` group within a cell).

The name of the template (`template_name`) is a name you choose that can be used later for reference.

Note:

A `power_lut_template` with the name `scalar` is predefined; its size is 1. You can refer to it by entering `scalar` as the name of a `fall_power` group, `power` group, or `rise_power` group within the `internal_power` group (defined in the `pin` group).

`variable_1`, `variable_2`, and `variable_3` Simple Attributes

The `variable_1` attribute in the `power_lut_template` group specifies the first dimensional variable used by the library developer to characterize cells in the library for internal power.

The `variable_2` attribute in the `power_lut_template` group specifies the second dimensional variable the library developer uses to characterize cells in the library for internal power.

The `variable_3` attribute in the `power_lut_template` group specifies the third dimensional variable the library developer uses to characterize cells in the library for internal power.

If the `index_1` attribute is measured with the loading of the output net capacitance of the pin specified in the `pin` group that contains the `internal_power` group (defined in a `cell` group), the value for `variable_1`

is equal_or_opposite_output_net_capacitance.

If the index_1 attribute is measured with the input transition time of the pin specified in the pin group or the related_pin attribute of the internal_power group, the value for variable_1 is input_transition_time.

If the index_2 attribute is measured with the loading of the output net capacitance of the pin specified in the pin group that contains the internal_power group (defined in a cell group), the value for variable_2 is equal_or_opposite_output_net_capacitance.

If the index_2 attribute is measured with the input transition time of the pin specified in the pin group or the related_pin attribute of the internal_power group, the value for variable_2 is input_transition_time.

If the index_3 attribute is measured with the loading of the output net capacitance of the pin specified in the pin group that contains the internal_power group (defined in a cell group), the value for variable_3 is equal_or_opposite_output_net_capacitance.

If the index_3 attribute is measured with the input transition time of the pin specified in the pin group or the related_pin attribute of the internal_power group, the value for variable_3 is input_transition_time.

index_1, index_2, and index_3 Complex Attributes

The index_1 complex attribute in the power_lut_template group specifies the breakpoints of the first dimension used to characterize cells for internal power within the library. The values specified in this attribute must be in a monotonically increasing order. You can overwrite the index_1 attribute by providing the same attribute in the fall_power group, power group, or rise_power group within the internal_power group (defined in the pin group). The index_1 attribute is required in the power_lut_template group.

The index_2 complex attribute in the power_lut_template group specifies the breakpoints of the second dimension used to characterize cells for internal power within the library. You can overwrite the index_2 attribute by providing the same attribute in the fall_power group, power group, or rise_power group within the internal_power group (defined in the pin group). The index_2 attribute is required in the power_lut_template group if the variable_2 attribute is present.

The index_3 complex attribute in the power_lut_template group specifies the breakpoints of the third dimension used to characterize cells for internal power within the library. You can overwrite the index_3 attribute in the internal_power group by providing the same attribute in the fall_power group, power group, or rise_power group within the internal_power group (defined in the pin group). The index_3 attribute is required in the power_lut_template group if the variable_3 attribute is present.

[Example 1-8](#) shows four power_lut_template groups.

Example 1-8 Four power_lut_template Groups

```
power_lut_template (output_by_cap) {
    variable_1 : total_output_net_capacitance ;
    index_1 ("0.0, 5.0, 20.0") ;
}
power_lut_template (output_by_cap_and_trans) {
    variable_1 : total_output_net_capacitance ;
    variable_2 : input_transition_time ;
    index_1 ("0.0, 5.0, 20.0") ;
    index_2 ("0.1, 1.0, 5.0") ;
}
power_lut_template (input_by_trans) {
    variable_1 : input_transition_time ;
    index_1 ("0.0, 1.0, 5.0") ;
}
power_lut_template (output_by_cap2_and_trans) {
    variable_1 : total_output_net_capacitance ;
    variable_2 : input_transition_time ;
    variable_3 : equal_or_opposite_output_net_capacitance ;
    index_1 ("0.0, 5.0, 20.0") ;
    index_2 ("0.1, 1.0, 5.0") ;
    index_3 ("0.1, 0.5, 1.0") ;
}
```

Use the report_lib -timing command to report power_lut_template information in the library. You can do this only while reading in the library source file in the same session. The report will resemble the one shown in [Example 1-9](#).

Example 1-9 power_lut_template Report

Internal Power Lookup Template:

Template_name	variable_1	variable_2
---------------	------------	------------

```
-----
output_by_cap      total_output_net_capacitance
  index_1 : 0.0000 5.0000 20.0000
output_by_cap_and_trans total_output_net_capacitance input_transition_time
  index_1 : 0.0000 5.0000 20.0000
  index_2 : 0.1000 1.0000 5.0000
input_by_trans     input_transition_time
  index_1 : 0.0000 1.0000 5.0000
output_by_cap2_and_trans   equal_or_opposite_output_net_capacitance
  index_1 : 0.0000 5.0000 20.0000
  index_2 : 0.1000 1.0000 5.0000
  index_3 : 0.1000 0.5000 1.0000
```

domain Group

In the case of a piecewise polynomial, use one or more domain groups in the `power_lut_template` group. The variables in a domain group are the same as the variables in the `power_lut_template` group. For more information about using a domain group, see [“domain Group”](#).

1.9.31 `power_poly_template` Group

Use the `power_poly_template` group to define a template of polynomials to be used by the `timing` group. For reference purposes, the `power_poly_template` group requires a name.

Syntax

```
library (library_nameid) {
  ...
  power_poly_template(power_poly_template_nameid) {
    variables(variable_ienum, ..., variable_nenum);
    variable_1_range(min_valuefloat, max_valuefloat);
    ...
    variable_n_range(min_valuefloat, max_valuefloat);
    mapping(valueenum, power_rail_nameid);
    domain(domain_nameid) {
      calc_mode : nameid;
      variables(variable_ienum, ..., variable_nenum);
      variable_1_range(min_valuefloat, max_valuefloat);
      ...
      variable_n_range(min_valuefloat, max_valuefloat);
      mapping(valueenum, power_rail_nameid);
    }
  }
}

power_poly_template_name
```

The name of the template.

Complex Attributes

```
variables
variable_n_range
mapping
```

Group

```
domain
```

variables Complex Attribute

Use the `variables` attribute to specify the name of a variable or a list of the variables that characterize library cells for power; that is, the variables used in the polynomial equations.

Note:

At least one variable name is required. A maximum of seven variables is allowed.

Syntax

```
variables(variable_1enum,..., variable_nenum) ;  
  
variable_1 , ..., variable_n  
  
Valid values for polynomial variables are: equal_or_opposite_output_net_capacitance, input_net_transition,  
total_output_net_capacitance, output_net_length, temperature, voltage, voltage i, and parameter i.
```

Example

```
variables( temperature, voltage,  
          total_output_net_capacitance) ;
```

variable_n_range Complex Attribute

Use the variable_n_range attribute to specify the range of the value for the *n*th variable in the variables attribute.

Note:

A variable_n_range attribute is required for each variable listed in the variables attribute.

Syntax

```
variable_n_range(value_1float value_2float) ;  
  
value_1 , value_2
```

Floating-point number pairs that specify the value range.

Example

```
variable_2_range(1.5, 2.0);
```

mapping Complex Attribute

The mapping attribute specifies the relationship between the voltage attribute (as used in the polynomial) and the corresponding power_rail attribute defined in the power_supply attribute.

Note:

You can have no more than two mapping attributes in a power_poly_template group.

Syntax

```
mapping(valueenum power_rail_nameid);  
  
value  
  
Valid values are voltage and voltage1.  
  
power_rail_name  
  
Identifies the corresponding power rail.
```

Example

```
mapping(voltage, VDD2) ;
```

domain Group

In the case of a piecewise polynomial, use one or more domain groups in the poly_template group. The variables in a domain group are the same as the variables in the poly_template group.

Note:

A domain name is required and the name must be unique.

Syntax

```
library (library_nameid) {  
    power_poly_template (power_poly_template_nameid) {  
        ...  
        domain (domain_nameid) {  
            ...  
        }  
    }  
}
```

Simple Attribute

calc_mode

Complex Attributes

```
variables  
variable_n_range  
mapping
```

calc_mode Simple Attribute

Use the calc_mode attribute to specify the associated process mode.

Syntax

```
calc_mode : nameid;
```

name

The name of the associated process mode.

variables, variable_n_range, and mapping Complex Attributes

For the description of how each of these attributes is used, see the [“poly_template Group”](#).

1.9.32 power_supply Group

The power_supply group is defined in the library group, as shown here:

```
library (name) {  
    power_supply (name) {  
        default_power_rail : string;  
        power_rail(power_supply_namestring,voltage_valuefloat)  
        power_rail(power_supply_namestring,voltage_valuefloat)  
        ...  
    }  
}
```

Simple Attribute

default_power_rail

Complex Attribute

power_rail

The power_supply group captures all nominal information on voltage variation.

default_power_rail Simple Attribute

The default_power_rail attribute receives, by default, the value of the voltage attribute defined in the nominal_operating_conditions group.

Syntax

```
default_power_rail : power_supply_name<string>;
```

power_supply_name

An identifier for the power supply.

Example

```
default_power_rail : VDD0 ;
```

power_rail Complex Attribute

The `power_rail` attribute identifies all power supplies that have the nominal operating conditions (defined in the `operating_conditions` group) and the nominal voltage values. The `power_supply` group can define one or more `power_rail` attributes.

Syntax

```
power_rail (power_supply_name<string>, voltage_value<float>)
```

power_supply_name

Specifies a power supply name that can be used later for reference. You can refer to it by assigning a string to the rail connection `input_signal_level` or `output_signal_level` attribute.

voltage_value

A floating-point number that identifies the voltage value associated with the `power_supply_name`. The value is in the units you define within the `library` group `voltage_unit` attribute.

Example

```
power_rail (VDD1, 5.0) ;
```

[Example 1-10](#) shows a library containing a `power_supply` group.

Example 1-10 Library Example With power_supply Group

```
library (multiple_power_supply) {
    power_supply () {
        /* Define before operating conditions and cells. */
        default_power_rail : VDD0 ;
        power_rail (VDD1, 5.0) ;
        power_rail (VDD2, 3.3) ;
        ...
    }
}
```

Multiple Power Supply Library Requirements

Use the `report_lib -power` command to report multiple power supply information in the library. The report will resemble the one shown in [Example 1-11](#).

Example 1-11 Multiple Power Supply Report

Power Supply Group:

```
default_power_rail      : VDD0
power Rail  Value
-----
VDD1      5.00
VDD2      3.30
```

Power Rail in the Operating Conditions Groups:

```
Name      : MPSS
power Rail  Value
-----
VDD1      4.80
VDD2      2.90
```

```

Power Rail Connection Information:
Name      : IBUF1
RAIL CONNECTION(PV1): VDD1
RAIL CONNECTION(PV2): VDD2

Signal Level Information:
CELL(IBUF1):
PIN(A):
INPUT_SIGNAL_LEVEL(A): VDD1
END_PIN A;

PIN(EN):
INPUT_SIGNAL_LEVEL(EN): VDD1
END_PIN EN;

PIN(Z):
OUTPUT_SIGNAL_LEVEL(Z): VDD2
END_PIN Z;

PIN(Z1):
INPUT_SIGNAL_LEVEL(Z1): VDD1
OUTPUT_SIGNAL_LEVEL(Z1): VDD2
END_PIN Z1;
END_CELL IBUF1;

```

1.9.33 propagation_lut_template Group

The propagation_lut_template group defines a template for specifying noise propagation through a cell.

Syntax

```

library (name_string) {
    propagation_lut_template (template_name_string) {
        ... template description ...
    }
}

```

Simple Attributes

```

variable_1
variable_2
variable_3

```

Complex Attributes

```

index_1
index_2
index_3

```

variable_1, variable_2, and variable_3 Simple Attributes

The values you can assign to variable_1 and variable_2 are input_noise_width, input_noise_height, and total_output_net_capacitance.

index_1, index_2, and index_3 Complex Attributes

Along with variable_1, variable_2, and variable_3, you must define index_1, index_2, and index_3, as shown:

```

index_1 ("float, ..., float");
index_2 ("float, ..., float");
index_3 ("float, ..., float");

```

Example

```

library (my_library) {
    ...
    propagation_lut_template (my_template) {
        variable_1 : input_noise_width ;

```

```

variable_2 : input_noise_height ;
variable_3 : total_output_net_capacitance ;
index_1 ("0.01, 0.2, 2") ;
index_2 ("0.2, 0.8") ;
index_2 ("0, 2") ;
}
...
}

```

1.9.34 *rise_net_delay Group*

The `rise_net_delay` group is defined at the library level, as shown here:

```

library (name) {
  rise_net_delay(name) {
    ...rise net delay description ...
  }
  fall_net_delay (name){
    ...fall net delay description ...
  }
}

```

Complex Attributes

```

index_1 ("float,...,float") ;
index_2 ("float,...,float") ;
values ("float,...,float","float,...,float");

```

The `rise_net_delay` and the `fall_net_delay` groups define, in the form of lookup tables, the values for rise and fall net delays. This indexing allows the library developer to model net delays as any function of `output_transition` and `rc_product`.

The net delay tables in one library have no effect on computations related to cells from other libraries.

To overwrite the lookup table default index values, specify the new index values before the net delay values.

[Example 1-12](#) shows an example of the `rise_net_delay` group.

Example 1-12 *rise_net_delay Group*

```

rise_net_delay (net_delay_template_table) {
  index_1 ("0, 1, 2") ;
  index_2 ("1, 0, 2") ;
  values ("0.00, 0.21", "0.11, 0.23") ;
}

```

See also [fall_net_delay Group](#).

1.9.35 *rise_transition_degradation Group*

The `rise_transition_degradation` group is defined at the library level, as shown here:

```

library (name) {
  rise_transition_degradation(name) {
    ...rise transition degradation description ...
  }
}

```

Complex Attributes

```

index_1 ("float, ..., float") ;
index_2 ("float, ..., float") ;
values ("float, ..., float", "float, ..., float");

```

The `rise_transition_degradation` group and the `fall_transition_degradation` group describe, in the form of lookup tables, the transition degradation functions for rise and fall transitions. The lookup tables are indexed by the transition time at the net driver and the connect delay between the driver and a particular load. This indexing allows the

library developer to model degraded transitions as any function of output-pin transition and connect delay between the driver and the load.

Transition degradation tables are used for indexing into any delay table in a library that has the `input_net_transition`, `constrained_pin_transition`, or `related_pin_transition` table parameters in the `lu_table_template` group.

The transition degradation tables in one library have no effect on computations related to cells from other libraries. [Example 1-13](#) shows an example of the `rise_transition_degradation` group.

Example 1-13 rise_transition_degradation Group

```
rise_transition_degradation (trans_deg) {
    index_1 ("0, 1, 2") ;
    index_2 ("1, 0, 2") ;
    values ("0.0, 0.6", "1.0, 1.6") ;
}
```

See also [“fall_transition_degradation Group”](#).

1.9.36 scaled_cell Group

You define a `scaled_cell` group within the `library` group to supply an alternative set of values for an existing cell, based on the set of operating conditions used.

Operating conditions are defined in the [“operating_conditions Group”](#).

Syntax

```
scaled_cell (existing_cell, operating_conditions_group) {
    ... scaled cell description ...
}
```

existing_cell

The name of a cell defined in a previous `cell` group.

operating_conditions_group

The library-level `operating_conditions` group with which the scaled cell is associated.

Simple Attributes

The following attributes are also defined in the `cell` group.

```
area : float ;
auxiliary_pad_cell : true | false ;
bus_naming_style : "string" ;
cell_footprint : footprint_type string ;
cell_leakage_power : float ;
clock_gating_integrated_cell : string_value ;
contention_condition: "Boolean      expression" ;
dont_fault : sa0 | sa1 | sa01 ;
dont_touch : true | false ;
dont_use : true | false ;
handle_negative_constraint : true | false;
is_clock_gating_cell : true | false ;
map_only : true | false ;
pad_cell : true | false ;
pad_type : clock ;
preferred : true | false ;
scaling_factors : group_name      ;
single_bit_degenerate : string ;
/* black box, bus, and bundle cells only*/
use_for_size_only : true | false ;
vhdl_name : "string" ;
```

Complex Attributes

The following attributes are also defined in the `cell` group.

```

pin_equal ("name_list_string") ;
pin_opposite ("name_list1_string", "name_list2_string") ;
rail_connection (connection_name_string,
power_supply_name_string) ;

```

Group Statements

The following groups are also defined in the `cell` group.

```

bundle
bus
ff
ff_bank
generated_clock
latch
latch_bank
leakage_power
lut
mode_definition
pin
routing_track
statetable
test_cell
type

```

1.9.37 sensitization Group

The `sensitization` group defined at the library level describes the complete state patterns for a specific list of pins (defined by the `pin_names` attribute) that will be referenced and instantiated as stimuli in the timing arc.

Vector attributes in the group define all possible pin states used as stimuli. Actual stimulus waveforms can be described by a combination of these vectors. Multiple `sensitization` groups are allowed in a library. Each `sensitization` group can be referenced by multiple cells, and each cell can make reference to multiple `sensitization` groups.

Syntax

```

library(library_name) {
...
sensitization (sensitization_group_name) {
...
}
}

```

Complex Attributes

```

pin_names
vector

```

1.9.38 pin_names Complex Attribute

The `pin_names` attribute specified at the library level defines a default list of pin names. All vectors in this `sensitization` group are the exhaustive list of all possible transitions of the input pins and their subsequent output response.

The `pin_names` attribute is required, and it must be declared in the `sensitization` group before all vector declarations.

Syntax

```

pin_names (string..., string);

```

Example

```

pin_names (IN1, IN2, OUT);

```

1.9.39 vector Complex Attribute

Similar to the `pin_names` attribute, the `vector` attribute describes a transition pattern for the specified pins. The stimulus is described by an ordered list of vectors.

The arguments for the `vector` attribute are as follows:

```
vector id
```

The `vector id` argument is an identifier to the vector string (a number tag that defines the list of possible sensitization combinations in a cell). The `vector id` value must be an integer greater than or equal to zero and unique among all vectors in the current sensitization group. It is recommended that you start numbering from 0 or 1.

```
vector string
```

The `vector string` argument represents a pin transition state. The string consists of the following transition status values: 0, 1, X, and Z where each character is separated by a space. The number of elements in the vector string must equal the number of arguments in `pin_names`.

The `vector` attribute can also be declared as:

```
vector (positive_integer, "{0|1|X|Z} [0|1|X|Z]...");
```

Syntax

```
vector (integer, string);
```

Example

```
sensitization(sensitization_nand2) {
    pin_names ( IN1, IN2, OUT1 );
    vector ( 1, "0 0 1" );
    vector ( 2, "0 1 1" );
    vector ( 3, "1 0 1" );
    vector ( 4, "1 1 0" );
```

1.9.40 scaling_factors Group

A `scaling_factors` group is defined within the `library` group.. .

Syntax

```
library (name_string) {
    scaling_factors ("name_string") {
        ... scaling factors ...
    }
}
```

Simple Attributes

The `scaling_factors` group uses the simple scaling attributes (that is, those with the `k_` prefix) included in [Example 1-1](#).

1.9.41 timing Group

A `timing` group is defined in a `bundle`, a `bus`, or a `pin` group within a cell. The `timing` group can be used to identify the name or names of multiple timing arcs. A `timing` group identifies multiple timing arcs, by identifying a timing arc in a `pin` group that has more than one related pin or when the timing arc is part of a bundle or a bus.

The following syntax shows a `timing` group in a `pin` group within a `cell` group.

Syntax

```
library (name_string) {
    cell (name) {
        pin (name) {
            timing (name | name_list) {
                ... timing description ...
            }
        }
    }
}
```

1.9.42 timing_range Group

Use the `timing_range` group to specify scaling factors that control signal arrival time.

Syntax

```
library (namestring) {
    timing_range (namestring) {
        ... timing range description ...
    }
}
```

Simple Attributes

```
faster_factor  
slower_factor
```

faster_factor Simple Attribute

Use this attribute to specify a scaling factor to apply to the signal arrival time to model the fastest-possible arrival time.

Syntax

```
faster_factor : valuefloat ;
```

value

A floating-point number representing the scaling factor.

Example

```
faster_factor: 0.0 ;
```

slowest_factor Simple Attribute

Use this attribute to specify a scaling factor to apply to the signal arrival time to model the slowest-possible arrival time.

Syntax

```
slowest_factor : valuefloat ;
```

value

A floating-point number representing the scaling factor.

Example

```
slowest_factor: 0.0 ;
```

1.9.43 type Group

If your library contains bused pins, you must define `type` groups and define the structural constraints of each bus type in the library. The `type` group is defined at the `library` group level, as shown here:

Syntax

```
library (namestring) {
    type (name) {
        ... type description ...
    }
}
```

name

Identifies the bus type.

Simple Attributes

```
base_type : base ;
bit_from : integer ;
bit_to : integer ;
bit_width : integer ;
```

```

data_type : data ;
downto : true | false ;

base_type : base ;

Only the array base type is supported.

bit_from : integer ;

Indicates the member number assigned to the most significant bit (MSB) of successive array members. The default is 0.

bit_to : integer ;

Indicates the member number assigned to the least significant bit (LSB) of successive array members. The default is 0.

bit_width : integer ;

Designates the number of bus members. The default is 1.

data_type : data ;

Indicates that only the bit data type is supported.

downto : true | false ;

A true value indicates that member number assignment is from high to low. A false value indicates that member number assignment is from low to high.

```

[Example 1-14](#) illustrates a `type` group statement.

Example 1-14 type Group Description

```

type (BUS4) {
    base_type : array ;
    bit_from : 0 ;
    bit_to : 3 ;
    bit_width : 4 ;
    data_type : bit ;
    downto : false ;
}

```

It is not necessary to use all attributes.

Example 1-15 Alternative type Group Descriptions

```

type (BUS4) {
    base_type : array ;
    data_type : bit ;
    bit_width : 4 ;
    bit_from : 0 ;
    bit_to : 3 ;
}

type (BUS4) {
    base_type : array ;
    data_type : bit ;
    bit_width : 4 ;
    bit_from : 3 ;
    downto : true ;
}

```

After you define a `type` group, you can use it in a `bus` group to describe bused pins.

1.9.44 user_parameters Group

Use the `user_parameters` group to specify default values for up to five user-defined process variables.

You define a `user_parameters` group in a `library` group as follows.

Syntax

```
library (name) {
```

```
user_parameters () {
    ... parameter descriptions...
}
```

Simple Attributes

parameter*i*

parameter *i* Simple Attributes

Use each generic attribute to specify a default value for a user-defined process variable. You can specify up to five variables.

Syntax

```
parameteri: valuefloat;
```

value

A floating-point number representing a variable value.

Example

```
parameter1: 0.5 ;
```

1.9.45 wire_load Group

A wire_load group is defined in a library group, as follows.

Syntax

```
library (name) {
    wire_load (name) {
        ... wire load description ...
    }
}
```

Simple Attributes

```
area : float ;
capacitance : float ;
resistance : float ;
slope : float ;
```

Complex Attribute

fanout_length

area Simple Attribute

Use this attribute to specify area per unit length of interconnect wire.

Syntax

```
area : valuefloat;
```

value

A floating-point number representing the area.

Example

```
area: 0.5 ;
```

capacitance Simple Attribute

Use this attribute to specify capacitance per unit length of interconnect wire.

Syntax

```
capacitance : valuefloat ;
```

value

A floating-point number representing the capacitance.

Example

```
capacitance : 1.2 ;
```

resistance Simple Attribute

Use this attribute to specify wire resistance per unit length of interconnect wire.

Syntax

```
resistance : valuefloat ;
```

value

A floating-point number representing the resistance.

Example

```
resistance : 0.001 ;
```

slope Simple Attribute

Use this attribute to characterize linear fanout length behavior beyond the scope of the longest length specified in the fanout_length attribute.

Syntax

```
slope : valuefloat ;
```

value

A floating-point number representing the slope in units per fanout.

Example

```
slope : 0.186
```

fanout_length Complex Attribute

Use this attribute to define values for fanout and length when you create the wire load manually. The create_wire_load command generates these values automatically.

Syntax

```
fanout_length(fanoutint,lengthfloat,average_capacitancefloat, \
              standard_deviationfloat, \
              number_of_netsint) ;
```

fanout

An integer representing the total number of pins, minus one, on the net driven by the given output.

length

A floating-point number representing the estimated amount of metal that is statistically found on a network with the given number of pins.

```
average_capacitance , standard_deviation , number_of_nets
```

The Floorplan Manager tool is the only Synopsys product that uses average_capacitance, standard_deviation, and number_of_nets values. For more information, see the *Floorplan Manager User Guide*.

Examples

```
library (example)
...
wire_load (small) {
    area : 0.0 ;
    capacitance : 1.0 ;
    resistance : 0.0 ;
    slope : 0.0 ;
    fanout_length (1,1.68) ;
}
}

library (example) {
...
wire_load ("90x90") {
    lu_table_template (wire_delay_table_template) {
        variable_1 : fanout_number;
        variable_2 : fanout_pin_capacitance;
        variable_3 : driver_slew;
        index_1("0.12,3.4");
        index_2("0.12,4.24");
        index_3("0.1,2.7,3.12");
    }
}
}
```

1.9.46 wire_load_selection Group

A wire_load_selection group is defined in a library group, as follows.

Syntax

```
library (name) {
    wire_load_selection (name) {
        ... wire load selection criteria ...
    }
}
```

Complex Attribute

```
wire_load_from_area (float, float, string) ;
```

Example

```
wire_load_selection (normal) {
    wire_load_from_area (100, 200, average) ;
}
```

1.9.47 wire_load_table Group

A wire_load_table group is defined in a library group, as follows.

Syntax

```
library (name) {
    wire_load_table (name) {
        ... wire_load table description ...
    }
}
```

Complex Attributes

```

fanout_area (integer,    float) ;
fanout_capacitance (integer,   float) ;
fanout_length (integer,    float) ;
fanout_resistance (integer,   float) ;

```

Example

```

library (wlut) {
    wire_load_table ("05x05") {
        fanout_area (1, 0.2) ;
        fanout_capacitance (1, 0.15) ;
        fanout_length (1, 0.2) ;
        fanout_resistance (1, 0.17) ;
    }
}

```

2. cell and model Group Description and Syntax

Every cell in a library has a separate cell description (a `cell` group) within the `library` group. A `cell` group can contain simple and complex attributes and other group statements.

Every model in a library also has a separate model description (a `model` group) within the `library` group. A `model` group can include the same simple and complex attributes and group statements as a `cell` group, plus two new attributes that can be used only in the `model` group.

This chapter describes the attributes and groups that can be included within `cell` and `model` groups, with the exception of the `pin` group, which is described in [Chapter 3, “pin Group Description and Syntax.”](#)

This chapter is organized as follows:

- [cell Group](#)
 - Attributes and values
 - Simple attributes
 - Complex attributes
 - Group statements
- [model Group](#)
 - Attributes and values

Within each division, the attributes and group statements are presented alphabetically.

2.1 cell Group

A `cell` group is defined within a `library` group, as shown here:

```

library (name_string) {
    cell (name_string) {
        ... cell    description ...
    }
}

```

2.1.1 Attributes and Values

[Example 2-1](#) lists alphabetically all the attributes and groups that you can define within a `cell` group.

Example 2-1 Attributes and Values for a cell Group

```

/* Simple Attributes for cell group */

area : float ;
auxiliary_pad_cell : true | false ;
base_name : cell_base_name_string ;
bus_naming_style : "string" ;
cell_footprint : footprint_type_string ;
cell_leakage_power : float ;
clock_gating_integrated_cell : string_value ;

```

```

contention_condition: "Boolean      expression" ;
dont_fault : sa0 | sa1 | sa01 ;
dont_touch : true | false ;
dont_use : true | false ;
driver_type : name_id ;
edif_name: name_id ;
em_temp_degradation_factor : valuefloat ;
fpga_domain_style : name_id ;
handle_negative_constraint : true | false;
interface_timing : true | false ;
io_type :   name_id ;
is_clock_gating_cell : true | false ;
map_only : true | false ;
pad_cell : true | false ;
pad_type : clock ;
power_cell_type : ;
preferred : true | false ;
scaling_factors : group_name    ;
single_bit_degenerate : string ;
/* black box, bus, and bundle cells only*/
slew_type : name_id ;
timing_model_type : "string" ;
use_for_size_only : true | false ;
vhdl_name : "string" ;

/* Complex Attributes for cell Group */

pin_equal ("name_list_string") ;
pin_opposite ("name_list1_string", "name_list2_string") ;
rail_connection (connection_name_string,
    power_supply_name_string) ;
resource_usage (resource_name_id, number_of_resources_id);

/* Group Statements for cell Group */

bundle (name_string) { }
bus (name_string) { }
dynamic_current () {}
ff (variable1_string, variable2_string) { }
ff_bank (variable1_string, variable2_string, bitsinteger) { }
functional_yield_metric () {}
generated_clock () {}
intrinsic_parasitic () {}
latch (variable1_string, variable2_string) { }
latch_bank (variable1_string, variable2_string, bitsinteger) { }
leakage_current () {}
leakage_power () { }
lut (name_string) { }
mode_definition () {}
pin (name_string | name_list_string) { }
routing_track (routing_layer_name_string) { }
statetable ("input      node      names", "internal      node      names") { }
test_cell () { }
type (name_string) { }

```

Descriptions of the attributes and group statements follow.

2.1.2 Simple Attributes

This section lists, alphabetically, the simple attributes for the `cell` and `model` groups.

`always_on` Simple Attribute

The `always_on` simple attribute models always-on cells or signal pins. Specify the attribute at the cell level to determine whether a cell is an always-on cell. Specify the attribute at the pin level to determine whether a pin is an always-on signal pin.

Syntax

```
always_on : Boolean expression ;  
  
Boolean expression  
  
Valid values are true and false.
```

Example

```
always_on : true ;
```

auxiliary_pad_cell Simple Attribute

See “[pad_cell Simple Attribute](#)”.

base_name Simple Attribute

Use the **base_name** attribute to define a name for the output cell generated by VHDL or Verilog. If you omit this attribute, the cell is given the name "io_cell_name".

Syntax

```
base_name : "cell_base_nameid" ;
```

cell_base_name

An alphanumeric string, enclosed in quotation marks, representing a name for the output cell.

Example

```
base_name : "IBUF" ;
```

bus_naming_style Simple Attribute

Use the **bus_naming_style** attribute to define the naming convention for buses in the library.

Syntax

```
bus_naming_style : "string" ;
```

Example

```
bus_naming_style : "Bus%sPin%d" ;
```

cell_footprint Simple Attribute

Use the **cell_footprint** attribute to assign a footprint class to a cell.

Syntax

```
cell_footprint : class_nameid ;
```

class_name

A character string that represents a footprint class. The string is case-sensitive: And4 is different from and4.

Example

```
cell_footprint : 5MIL ;
```

Use this attribute to assign the same footprint class to all cells that have the same geometric layout characteristics.

Cells with the same footprint class are considered interchangeable and can be swapped during in-place optimization. Cells without **cell_footprint** attributes are not swapped during in-place optimization.

When you use **cell_footprint**, you also set the **in_place_swap_mode** attribute to **match_footprint**.

cell_leakage_power Simple Attribute

Use the `cell_leakage_power` attribute to define the leakage power of a cell. You must define this attribute for cells with state-dependent leakage power. If `cell_leakage_power` is missing or negative, the value of the `default_cell_leakage_power` attribute defined in the library is assumed.

Note:

Cells with state-dependent leakage power also need the `leakage_power` Group.

Syntax

```
cell_leakage_power : valuefloat ;
```

value

A floating-point number indicating the leakage power of the cell.

Example

```
cell_leakage_power : 0.2
```

The `cell_leakage_power` attribute is also recognized in the `scaled_cell` group, where it allows you to model nonlinear scaling of leakage power relative to certain process, voltage, and temperature conditions.

clock_gating_integrated_cell Simple Attribute

You can use the `clock_gating_integrated_cell` attribute to enter specific values that determine which integrated cell functionality the clock-gating software uses.

Syntax

```
clock_gating_integrated_cell:generic|valueid;
```

generic

When specified, the actual value is determined by accessing the state tables and state functions of the library cell pins.

value

A concatenation of up to four strings that describe the functionality of the cell to the clock-gating software:

The first string specifies the type of sequential element you want. The options are latch-gating logic and none.

The second string specifies whether the logic is appropriate for rising- or falling-edge-triggered registers. The options are posedge and negedge.

The third (optional) string specifies whether you want test control logic located before or after the latch or flip-flop, or not at all. The options for cells set to latch or flip-flop are precontrol (before), postcontrol (after), or no entry. The options for cells set to no gating logic are control and no entry.

The fourth (optional) string, which exists only if the third string does, specifies whether you want observability logic or not. The options are obs and no entry. [Table 2-1](#) lists some example values for the `clock_gating_integrated_cell` attribute.

Table 2-1 Some Values for the `clock_gating_integrated_cell` Attribute

Value of <code>clock_gating_integrated_cell</code>	Integrated cell must contain
<code>latch_negedge</code>	1. Latch-based gating logic2. Logic appropriate for falling-edge-triggered registers
<code>latch_posedge_postcontrol</code>	1. Latch-based gating logic2. Logic appropriate for rising-edge-triggered registers3. Test control logic located after the latch
<code>latch_negedge_precontrol</code>	1. Latch-based gating logic2. Logic appropriate for falling-edge-triggered registers3. Test control logic located before the latch
<code>none_posedge_control_obs</code>	1. Latch-free gating logic2. Logic appropriate for rising-edge-triggered registers3. Test control logic (no latch)4. Observability logic

For more details about the clock-gating integrated cells, see the “Modeling Power and Electromigration” chapter in the Liberty User Guide, Volume 1.

Example

```
clock_gating_integrated_cell : latch_posedge_precontrol_obs ;
```

Setting Pin Attributes for an Integrated Cell

The clock-gating software requires setting the pins of your integrated cells using the attributes listed in [Table 2-2](#). Setting some of the pin attributes, such as those for test and observability, is optional.

Table 2-2 Pin Attributes for Integrated Clock Gating Cells

Integrated cell pin name	Data direction	Required attribute
clock	in	clock_gate_clock_pin
enable	in	clock_gate_enable_pin
test_mode or scan_enable	in	clock_gate_test_pin
enable_clock	out	clock_gate_out_pin

Setting Timing for an Integrated Cell

You set both the setup and hold arcs on the enable pin by setting the `clock_gate_enable_pin` attribute for the integrated cell to true. The setup and hold arcs for the cell are determined by the edge values you enter for the `clock_gating_integrated_cell` attribute. [Table 2-3](#) lists the edge values and the corresponding setup and hold arcs.

Table 2-3 Values of the `clock_gating_integrated_cell` Attribute

Value of <code>clock_gating_integrated_cell</code> attribute	Setup arc	Hold arc
latch_posedge	rising	rising
latch_negedge	falling	falling
none_posedge	falling	rising
none_negedge	rising	falling

contention_condition Simple Attribute

Specifies the contention conditions for a cell. Contention is a clash of “0” and “1” signals. In certain cells, it may be a forbidden condition and cause circuits to short.

Syntax

```
contention_condition : "Boolean expression" ;
```

Example

```
contention_condition : "ap * an" ;
```

dont_fault Simple Attribute

This attribute is used by test tools. It is a string attribute that you can set on a library cell or pin.

Syntax

```
dont_fault : sa0 | sa1 | sa01 ;
```

```
sa0, sa1, sa01
```

The value you enter determines whether the `dont_fault` attribute will be placed on stuck at 0 (sa0), stuck at 1 (sa1), or stuck on both faults (sa01).

Example

```
dont_fault : sa0 ;
```

The `dont_fault` attribute can also be defined in the `pin` group.

`dont_touch` Simple Attribute

The `dont_touch` attribute with a true value indicates that all instances of the cell must remain in the network.

Syntax

```
dont_touch : valueBoolean ;
```

value

Valid values are true and false.

Example

```
dont_touch : true ;
```

In addition to defining `dont_touch` in a `cell` group or a `model` group, you can also apply the `dont_touch` attribute to a cell, by using the `set_dont_touch` command.

`dont_use` Simple Attribute

The `dont_use` attribute with a true value indicates that a cell should not be added to a design during optimization.

Syntax

```
dont_use : valueBoolean ;
```

value

Valid values are true and false.

Example

```
dont_touch : true ;
```

In addition to defining `dont_touch` in a `cell` group or a `model` group, you can also apply the `dont_touch` attribute to a cell, by using the `set_dont_touch` command.

`driver_type` Simple Attribute

Use the `driver_type` attribute to specify the drive power of the output or the I/O cell.

Syntax

```
driver_type : nameid ;
```

name

An alphanumeric string identifier, enclosed in quotation marks, representing the drive power.

Example

```
driver_type : "4" ;
```

`driver_waveform` Simple Attribute

The `driver_waveform` attribute is an optional string attribute that allows you to define a cell-specific driver waveform. The value must be the `driver_waveform_name` predefined in the `normalized_driver_waveform` table.

When the attribute is defined, the cell uses the specified driver waveform during characterization. When it is not specified, the common driver waveform (the `normalized_driver_waveform` table without the `driver_waveform_name` attribute) is used for the cell.

Syntax

```
cell (cell_name) {  
    ...  
    driver_waveform : string;  
    driver_waveform_rise : string;
```

```
driver_waveform_fall : string;
```

Example

```
cell (my_cell1) {
    driver_waveform : clock_driver;
    ...
}
cell (my_cell2) {
    driver_waveform : bus_driver;
    ...
}
cell (my_cell3) {
    driver_waveform_rise : rise_driver;
    driver_waveform_fall : fall_driver;
    ...
}
```

driver_waveform_rise and driver_waveform_fall Simple Attributes

The `driver_waveform_rise` and `driver_waveform_fall` string attributes are similar to the `driver_waveform` attribute. These two attributes allow you to define rise-specific and fall-specific driver waveforms. The `driver_waveform` attribute can coexist with the `driver_waveform_rise` and `driver_waveform_fall` attributes, though the `driver_waveform` attribute becomes redundant.

You should specify a driver waveform for a cell by using the following priority:

1. Use the `driver_waveform_rise` for a rise arc and the `driver_waveform_fall` for a fall arc during characterization. If they are not defined, specify the second and third priority driver waveforms.
2. Use the cell-specific driver waveform (defined by the `driver_waveform` attribute).
3. Use the library-level default driver waveform (defined by the `normalized_driver_waveform` table without the `driver_waveform_name` attribute).

The `driver_waveform_rise` attribute can refer to a `normalized_driver_waveform` that is either rising or falling. It is possible to invert the waveform automatically during runtime if necessary.

Syntax

```
cell (cell_name) {
    ...
    driver_waveform : string;
    driver_waveform_rise : string;
    driver_waveform_fall : string;
}
```

Example

```
cell (my_cell1) {
    driver_waveform : clock_driver;
    ...
}
cell (my_cell2) {
    driver_waveform : bus_driver;
    ...
}
cell (my_cell3) {
    driver_waveform_rise : rise_driver;
    driver_waveform_fall : fall_driver;
    ...
}
```

edif_name Simple Attribute

Use the `edif_name` attribute to define the name of the output cell generated by EDIF. If you omit this attribute, the cell is given the name "io_cell_name".

Syntax

```
edif_name : name_id;
```

name

An alphanumeric string, enclosed in quotation marks, representing a name for the output EDIF cell.

Example

```
edif_name : "OBUF" ;
```

fpga_temp_degradation_factor Simple Attribute

The `em_temp_degradation_factor` attribute specifies the electromigration exponential degradation factor.

Syntax

```
em_temp_degradation_factor : valuefloat ;
```

value

A floating-point number in centigrade units consistent with other temperature specifications throughout the library.

Example

```
em_temp_degradation_factor : 40.0 ;
```

fpga_cell_type Simple Attribute

Specifies whether a tool interprets a combination timing arc between the clock pin and the output pin as a rising edge arc or as a falling edge arc.

Syntax

```
fpga_cell_type : valueenum ;
```

value

Valid values are `rising_edge_clock_cell` and `falling_edge_clock_cell`.

Example

```
fpga_cell_type : rising_edge_clock_cell ;
```

fpga_domain_style Simple Attribute

Use this attribute to reference a `calc_mode` value in a `domain` group in a polynomial table.

Syntax

```
fpga_domain_style : "nameid" ;
```

name

The `calc_mode` value.

Example

```
fpga_domain_style : "speed" ;
```

fpga_isd Simple Attribute

Use the `fpga_isd` attribute to reference the `drive`, `io_type`, and `slew` information contained in a library-level `fpga_isd` group.

Syntax

```
fpga_isd : fpga_isd_nameid ;
```

`fpga_isd_name`

The name of the library-level `fpga_isd` group.

Example

```
fpga_isd : part_cell_isd ;
```

`handle_negative_constraint Simple Attribute`

You use this attribute during generation of VITAL models to indicate whether a cell needs negative constraint handling. It is an optional attribute for timing constraints in a `cell` or `model` group.

Syntax

```
handle_negative_constraint : true | false ;
```

Example

```
handle_negative_constraint : true ;
```

`interface_timing Simple Attribute`

Indicates that the timing arcs are interpreted according to interface timing specifications semantics. If this attribute is missing or its value is set to false, the timing relationships are interpreted as those of a regular cell rather than according to interface timing specification semantics.

Syntax

```
interface_timing : true | false ;
```

The following example shows a cell with `interface_timing` set to true, indicating that interface timing semantics are to be applied.

Example

```
interface_timing : true ;
```

`io_type Simple Attribute`

Use the `io_type` attribute to define the I/O standard used by this I/O cell.

Syntax

```
io_type : name_id ;
```

name

An alphanumeric string identifier, enclosed in quotation marks, representing the I/O standard.

Example

```
io_type : "LVTTL" ;
```

`is_pll_cell Simple Attribute`

The `is_pll_cell` Boolean attribute identifies a phase-locked loop cell. A phase-locked loop (PLL) is a feedback control system that automatically adjusts the phase of a locally-generated signal to match the phase of an input signal.

Syntax

```
cell (<cell_name>) {  
    is_pll_cell : true;  
    pin (<ref_pin_name>) {  
        is_pll_reference_pin : true;  
        direction : output;  
    ...  
}
```

Example

```
cell(my_pll) {
    is_pll_cell : true;
    pin( REFCLK ) {
        direction : input;
        is_pll_reference_pin : true;
    }

    pin( FBKCLK ) {
        direction : input;
        is_pll_feedback_pin : true;
    }

    pin (OUTCLK1) {
        direction : output;
        is_pll_output_pin : true;
        timing() { /*Timing Arc*/
            related_pin: "REFCLK";
            timing_type: combinational_rise;
            timing_sense: positive_unate;
            cell_rise(scalar) { /*Can be a LUT as well to support NLDM and CCS
models*/
                values("0.0")
            }
        }
        timing() { /*Timing Arc*/
            related_pin: "REFCLK";
            timing_type: combinational_fall;
            timing_sense: positive_unate;
            cell_fall(scalar) {
                values("0.0")
            }
        }
    }

    pin (OUTCLK2) {
        direction : output;
        is_pll_output_pin : true;
        timing() { /*Timing Arc*/
            related_pin: "REFCLK";
            timing_type: combinational_rise;
            timing_sense: positive_unate;
            cell_rise(scalar) { /*Can be a LUT as well to support NLDM and CCS
models*/
                values("0.0")
            }
        }
        timing() { /*Timing Arc*/
            related_pin: "REFCLK";
            timing_type: combinational_fall;
            timing_sense: positive_unate;
            cell_fall(scalar) {
                values("0.0")
            }
        }
    }
}
```

is_clock_gating_cell Simple Attribute

The cell-level **is_clock_gating_cell** attribute specifies that a cell is for clock gating.

Syntax

```
is_clock_gating_cell : true | false ;
```

Example

```
is_clock_gating_cell : true;
```

Set this attribute only on 2-input AND, NAND, OR, and NOR gates; inverters; buffers; and 2-input D latches.

is_isolation_cell Simple Attribute

The cell-level **is_isolation_cell** attribute specifies that a cell is an isolation cell. The pin-

`level_isolation_cell_enable_pin` attribute specifies the enable input pin for the isolation cell.

Syntax

`is_isolation_cell : Boolean expression ;`

Boolean expression

Valid values are true and false.

Example

```
is_isolation_cell : true ;
```

is_level_shifter Simple Attribute

The cell-level `is_level_shifter` attribute specifies that a cell is a level shifter cell. The pin-level `level_shifter_enable_pin` attribute specifies the enable input pin for the level shifter cell.

Syntax

`is_level_shifter : Boolean expression ;`

Boolean expression

Valid values are true and false.

Example

```
is_level_shifter : true ;
```

is_macro_cell Simple Attribute

The `is_macro_cell` simple Boolean attribute identifies whether a cell is a macro cell. If the attribute is set to true, the cell is a macro cell. If it is set to false, the cell is not a macro cell.

Syntax

`is_macro_cell : Boolean expression ;`

Boolean expression

Valid values are true and false.

Example

```
is_macro_cell : true ;
```

level_shifter_type Simple Attribute

The `level_shifter_type` attribute specifies the voltage conversion type that is supported. Valid values are:

LH

Low to High

HL

High to Low

HL_LH

High to Low and Low to High

The `level_shifter_type` attribute is optional.

Syntax

`level_shifter_type : level_shifter_type_value ;`

Example

```
level_shifter_type : HL_LH ;
```

map_only Simple Attribute

The `map_only` attribute with a `true` value indicates that a cell is excluded from logic-level optimization during compilation.

Syntax

```
map_only : true | false ;
```

In addition to defining `map_only` in a `cell` group or a `model` group, you can also apply the `map_only` attribute to a cell by using the `set_map_only` command.

pad_cell Simple Attribute

In a `cell` group or a `model` group, the `pad_cell` attribute identifies a cell as a pad cell.

Syntax

```
pad_cell : true | false ;
```

If the `pad_cell` attribute is included in a cell definition (`true`), at least one pin in the cell must have an `is_pad` attribute.

Example

```
pad_cell : true ;
```

If more than one pad cell can be used to build a logical pad, use the `auxiliary_pad_cell` attribute in the cell definitions of all the component pad cells.

Syntax

```
auxiliary_pad_cell : true | false ;
```

Example

```
auxiliary_pad_cell : true ;
```

If the `pad_cell` or `auxiliary_pad_cell` attribute is omitted, the cell is treated as an internal core cell rather than as a pad cell.

Note:

A cell with an `auxiliary_pad_cell` attribute can also be used as a core cell; a pull-up or pull-down cell is an example of such a cell.

pad_type Simple Attribute

Use the `pad_type` attribute to identify a type of `pad_cell` or `auxiliary_pad_cell` that requires special treatment.

Syntax

```
pad_type : value ;
```

Example

```
pad_type : clock;
```

power_cell_type Simple Attribute

Use the `power_cell_type` attribute to specify the cell type.

Syntax

```
power_cell_type : valueenum ;
```

value

Valid values are `stdcell` (standard cell) and `macro` (macro cell).

Example

```
power_cell_type : stdcell ;
```

`power_gating_cell` Simple Attribute

Note:

The `power_gating_cell` attribute has been replaced by the `retention_cell` attribute. See "["retention_cell Simple Attribute"](#)".

The cell-level `power_gating_cell` attribute specifies that a cell is a power gating cell. A power gating cell has two modes. When functioning in normal mode, the power gating cell functions as a regular cell. When functioning in power-saving mode, the power gating cell's power supply is shut off.

The pin-level `map_to_logic` attribute specifies which logic level the `power_gating_cell` is tied to when the cell is functioning in normal mode.

Syntax

```
power_gating_cell : power_gating_cell_name_id ;
```

power_gating_cell_name

A string identifying the power gating cell name.

Example

```
power_gating_cell : "my_gating_cell" ;
```

`preferred` Simple Attribute

The `preferred` attribute with a `true` value indicates that the cell is the preferred replacement during the gate-mapping phase of optimization.

Syntax

```
preferred : true | false ;
```

Example

```
preferred : true ;
```

This attribute can be applied to a cell with preferred timing or area attributes. For example, in a set of 2-input NAND gates, you might want to use gates with higher drive strengths wherever possible. This practice is useful primarily in design translation.

`retention_cell` Simple Attribute

The `retention_cell` attribute identifies a retention cell. The `retention_cell_style` value is a random string.

Syntax

```
retention_cell : retention_cell_style ;
```

Example

```
retention_cell : my_retention_cell ;
```

`scaling_factors` Simple Attribute

Use the `scaling_factors` attribute to apply to a cell the scaling factor values defined in the `scaling_factors` group at the library level.

Syntax

```
scaling_factors : group_name_id;  
  
group_name  
Name of the set of special scaling factors in a scaling_factors statement at the library level.
```

[Example 2-2](#) shows one of these special scaling factors in the library description and cell description.

Example 2-2 Individual Scaling Factors

```
library (example) {  
    k_volt_intrinsic_rise : 0.987 ;  
    ...  
    scaling_factors (IO_PAD_SCALING) {  
        k_volt_intrinsic_rise : 0.846 ;  
        ...  
    }  
    cell (INPAD_WITH_HYSTERESIS) {  
        area : 0 ;  
        scaling_factors : IO_PAD_SCALING ;  
        ...  
    }  
    ...  
}
```

[Example 2-2](#) defines a scaling factor group called `IO_PAD_SCALING` that contains scaling factors different from the library-level scaling factors. The `scaling_factors` attribute in the `INPAD_WITH_HYSTERESIS` cell is set to `IO_PAD_SCALING`, so all scaling factors set in the `IO_PAD_SCALING` group are applied to this cell.

sensitization_master Simple Attribute

The `sensitization_master` attribute defines the sensitization group referenced by the cell to generate stimuli for characterization. The attribute is required if the cell contains sensitization information. Its string value should be any sensitization group name predefined in the current library.

Syntax

```
sensitization_master : sensitization_group_name;  
  
sensitization_group_name  
A string identifying the sensitization group name predefined in the current library.
```

Example

```
sensitization_master : sensi_2in_1out;  
  
single_bit_degenerate Simple Attribute
```

The `single_bit_degenerate` attribute names a single-bit library cell to link a multibit black box cell with the single-bit version of the cell.

Syntax

```
single_bit_degenerate : "cell_name_id";  
  
cell_name  
A character string identifying a single-bit cell.
```

Example

```
cell (FDX2) {  
    area : 18 ;  
    single_bit_degenerate : "FDB" ;  
    /* FDB must be a single-bit cell in the library*/  
    bundle (D) {  
        members (D0, D1) ;  
        direction : input ;
```

```

...
timing ( ) {
  ...
  ...
}
}
cell (FDX4) {
  area : 32 ;
  single_bit_degenerate : "FDB" ;
  bus (D) {
    bus_type : bus4 ;
    direction : input ;
    ...
    timing ( ) {
      ...
      ...
    }
  }
}

```

slew_type Simple Attribute

Use the `slew_type` attribute to specify the slew type for the output pins of the output or the I/O cell.

Syntax

```
slew_type : "nameid";
```

name

An alphanumeric string identifier, enclosed in quotation marks, representing the slew type.

Example

```
slew_type : "slow" ;
```

switch_cell_type Simple Attribute

The `switch_cell_type` cell-level attribute provides a description of the switch cell so that the switch cell does not need to be inferred through the other information specified in the cell.

Syntax

```
switch_cell_type : coarse_grain | fine_grain;
```

Example

```
switch_cell_type : coarse_grain ;
```

threshold_voltage_group Simple Attribute

The optional `threshold_voltage_group` attribute specifies a cell's category based on its threshold voltage characteristics.

Syntax

```
threshold_voltage_group : "group_nameid" ;
```

group_name

A string value representing the name of the category.

Example

```
cell () {
  ...
  threshold_voltage_group : "high_vt_cell" ;
  ...
  threshold_voltage_group : "low_vt_cell" ;
  ...
}
```

```
}
```

timing_model_type Simple Attribute

Indicates not to infer transparent level-sensitive latch devices from timing arcs defined in the cell. To indicate that transparent level-sensitive latches should be inferred for input pins, use the tLatch group.

Syntax

```
timing_model_type : "nameid";
```

name

Valid values are “abstracted”, “extracted”, and “qtm”.

Example

```
timing_model_type : "abstracted";
```

use_for_size_only Simple Attribute

You use this attribute to specify the criteria for sizing optimization. You set this attribute on a cell at the library level.

Syntax

```
use_for_size_only : valueBoolean;
```

value

Valid values are true and false.

Example

```
library(lib1){  
    cell(cell1){  
        area : 14;  
        use_for_size_only : true;  
        pin(A){  
            ...  
        }  
        ...  
    }  
}
```

vhdl_name Simple Attribute

In `cell`, `model`, and `pin` groups, this attribute resolves conflicts of invalid object names when porting from .db to VHDL. Some .db object names might violate the more restrictive VHDL rules for identifiers.

Note:

The `report_lib -vhdl_name` command produces a table of .db names and VHDL name mapping.

Syntax

```
vhdl_name : "nameid";
```

name

A name to substitute for the pin name when you write it out to VHDL.

Example

```
cell (INV) {  
    area : 1;  
    pin(IN) {  
        vhdl_name : "INb";  
        direction : input;  
        capacitance : 1;
```

```

    }
    pin(Z) {
        direction : output ;
        function : "IN' " ;
        timing () {
            intrinsic_rise : 0.23 ;
            intrinsic_fall : 0.28 ;
            rise_resistance : 0.13 ;
            fall_resistance : 0.07 ;
            related_pin : "IN" ;
        }
    }
}

```

2.1.3 Complex Attributes

This section lists, alphabetically, the complex attributes for the `cell` and `model` groups.

`input_voltage_range` Attribute

The `input_voltage_range` attribute specifies the allowed voltage range of the level-shifter input pin and the voltage range for all input pins of the cell under all possible operating conditions (defined across multiple libraries). The attribute defines two floating values: the first is the lower bound, and second is the upper bound.

The `input_voltage_range` syntax differs from the pin-level `input_signal_level_low` and `input_signal_level_high` syntax in the following ways:

- The `input_signal_level_low` and `input_signal_level_high` attributes are defined on the input pins under one operating condition.
- The `input_signal_level_low` and `input_signal_level_high` attributes are used to specify the partial voltage swing of an input pin (that is, to prevent from swinging from ground rail VSS to full power rail VDD). Note that `input_voltage_range` is not related to the voltage swing.

Note:

The `input_voltage_range` and `output_voltage_range` attributes should always be defined together.

Syntax

```
input_voltage_range (float, float) ;
```

Example

```
input_voltage_range (1.0, 2.0) ;
```

`output_voltage_range` Attribute

The `output_voltage_range` attribute is similar to the `input_voltage_range` attribute except that it specifies the allowed voltage range of the level shifter for the output pin instead of the input pin.

The `output_voltage_range` syntax differs from the pin-level `output_signal_level_low` and `output_signal_level_high` syntax in the following ways:

- The `output_signal_level_low` and `output_signal_level_high` attributes are defined on the output pins under one operating condition.
- The `output_signal_level_low` and `output_signal_level_high` attributes are used to specify the partial voltage swing of an output pin (that is, to prevent from swinging from ground rail VSS to full power rail VDD). Note that `output_voltage_range` is not related to the voltage swing.

Note:

The `input_voltage_range` and `output_voltage_range` attributes should always be defined together.

Syntax

```
output_voltage_range (float, float) ;
```

Example

```
output_voltage_range (1.0, 2.5) ;
```

pin_equal Complex Attribute

Use the `pin_equal` attribute to describe functionally equal (logically equivalent) groups of input or output pins.

Syntax

```
pin_equal ("name_list");
```

name_list

A list of input or output pins whose values must be equal.

Example

In the following example, input pins IP1 and IP0 are logically equivalent.

```
pin_equal ("IP1 IP0");
```

pin_name_map Complex Attribute

The `pin_name_map` attribute defines the pin names that are used to generate stimuli from the sensitization group for all timing arcs in the cell. The `pin_name_map` attribute is optional when the pin names in the cell are the same as the the pin names in the sensitization master, but it is required when they are different.

If the `pin_name_map` attribute is set, the number of pins must be the same as that in the sensitization master, and all pin names should be legal pin names for the cell.

Syntax

```
pin_name_map (string..., string);
```

Example

```
pin_name_map (A, B, Z);
```

pin_opposite Complex Attribute

Use the `pin_opposite` attribute to describe functionally opposite (logically inverse) groups of input or output pins.

Syntax

```
pin_opposite ("name_list1", "name_list2");
```

name_list1 , *name_list2*

A *name_list* of output pins requires the supplied output values to be opposite. A *name_list* of input pins requires the supplied input values to be opposite.

In the following example, pins IP and OP are logically inverse.

```
pin_opposite ("IP", "OP");
```

The `pin_opposite` attribute also incorporates the functionality of the `pin_equal` complex attribute. In the following example, Q1, Q2, and Q3 are equal; QB1 and QB2 are equal; and the pins in the first group are opposite of the pins in the second group.

```
pin_opposite ("Q1 Q2 Q3", "QB1 QB2");
```

rail_connection Complex Attribute

Use the `rail_connection` attribute to specify the presence of multiple power supplies in the cell. A cell with multiple power supplies contains two or more `rail_connection` attributes.

Syntax

```
rail_connection (connection_nameid,power_supply_nameid);
```

connection_name

A string that specifies a power connection for the pin name.

power_supply_name

A string that specifies the power supply group already defined in the `power_supply` group at the `library` level to be used as the value for the `power_level` attribute in the `internal_power` group (defined in the `pin` group).

Example

```
cell (IBUF1) {
    ...
    rail_connection (PV1, VDD1) ;
    rail_connection (PV2, VDD2) ;
    ...
}
```

resource_usage Complex Attribute

Use the `resource_usage` attribute to specify the name and the number of resources the cell uses.

Syntax

```
resource_usage ( resource_name_id, number_of_resources_int ) ;
```

resource_name

An alphanumeric identifier that matches the first argument in a `max_count` attribute in the library. You can specify multiple `resource_usage` attributes with different resource names.

number_of_resources

An integer representing the number of resources the cell uses.

Example

```
resource_usage (RES1, 1) ;
```

2.1.4 Group Statements

This section lists, alphabetically, the group statements for the `cell` and `model` groups.

cell Group Example

[Example 2-3](#) shows cell definitions that include some of the CMOS cell attributes described so far.

Example 2-3 cell Group Example

```
library (cell_example){
    date : "December 12, 2003" ;
    revision : 2.3 ;
    scaling_factors( IO_PAD_SCALING ) {
        k_volt_intrinsic_rise : 0.846 ;
    }
    cell (in){
        vhdl_name : "inpad" ;
        area : 0; /* pads do not normally consume
                    internal core area*/
        cell_footprint : 5MIL ;
        scaling_factors : IO_PAD_SCALING ;
        pin (A) {
            direction : input;
            capacitance : 0;
        }
        pin (Z) {
            direction : output;
            function : "A";
            timing () {...}
        }
    }
    cell(inverter_med){
        area : 3;
        preferred : true;
    }
}
```

```

/* Application tools use this inverter first during optimization */
pin (A) {
    direction : input;
    capacitance : 1.0;
}
pin (Z) {
    direction : output;
    function : "A'";
    timing () { ... }
}
cell(and_nand){
    area : 4;
    pin_opposite("Y", "Z");
    pin(A) {
        direction : input;
        capacitance : 1
        fanout_load : 1.0
    }
    pinup) {
        direction : input;
        capacitance : 1
        fanout_load : 1.0
    }
    pin (Y) {
        direction : output;
        function : "(A * B)'"
        timing() { ... }
    }
    pin (Z){
        direction : output;
        function : "(A * B)"
        timing() { ... }
    }
}
cell(buff1){
area : 3;
pin_equal ("YZ");
pin (A) {
    direction : input;
    capacitance : 1.0;
}
pin (Y) {
    direction : output;
    function : "A";
    timing () { ... }
}
pin (Z) {
    direction : output;
    function : "A";
    timing () { ... }
}
}
} /* End of Library */

```

critical_area_table Group

The `critical_area_table` group specifies a critical area table at the cell level that is used for critical area analysis modeling. The `critical_area_table` group uses `critical_area_lut_template` as the template. The `critical_area_table` group contains the `defect_type`, `related_layer`, `index_1`, and `values` attributes.

Syntax

```

library(my_library) {
...
critical_area_table (<template_name>) {
    defect_type : enum (open, short, open_and_short);
    related_layer : string;
    index_1 ("float...float");
    values ("float...float");
}
}
}
```

Example

```

library(my_library) {
...
    critical_area_table (caa_template) {
        defect_type : short;
        related_layer : M1 ;
        index_1 ("0.08, 0.09, 0.1, 0.11, 0.12, 0.13, 0.14, 0.15, 0.16,
                  0.17");
        values ("0.03, 0.08, 0.17, 0.28, 0.40, 0.54, 0.68, 0.81, 0.95,
                 1.09");
    }
...
}

```

defect_type Attribute

The `defect_type` attribute value indicates whether the critical area analysis table values are measured against a short or open electrical failure when particles fall on the wafer. The following enumerated values are accepted: `short`, `open` and `open_and_short`. The `open_and_short` attribute value specifies that the critical area analysis table is modeled for both short and open failure types. If `defect_type` is not specified, the `default` value is `open_and_short`.

Syntax

```
defect_type : enum (open, short, open_and_short);
```

Example

```

library(my_library) {
...
    critical_area_table (caa_template) {
        defect_type : short;
        related_layer : M1 ;
        index_1 ("0.08, 0.09, 0.1, 0.11, 0.12, 0.13, 0.14, 0.15, 0.16,
                  0.17");
        values ("0.03, 0.08, 0.17, 0.28, 0.40, 0.54, 0.68, 0.81, 0.95,
                 1.09");
    }
...
}

```

related_layer Attribute

The `related_layer` attribute defines the names of the layers to which the critical area analysis table values apply. All layer names must be predefined in the library's layer definitions.

Syntax

```
related_layer : string;
```

Example

```

library(my_library) {
...
    critical_area_table (caa_template) {
        defect_type : short;
        related_layer : M1 ;
        index_1 ("0.08, 0.09, 0.1, 0.11, 0.12, 0.13, 0.14, 0.15, 0.16,
                  0.17");
        values ("0.03, 0.08, 0.17, 0.28, 0.40, 0.54, 0.68, 0.81, 0.95,
                 1.09");
    }
...
}

```

index_1 Attribute

The `index_1` attribute defines the defect size diameter array in the unit of `distance_unit`. The attribute is optional if the values for this array are the same as that in the `critical_area_lut_template`.

Syntax

```
index_1 ("float...float");
```

Example

```

library(my_library) {
    ...
    critical_area_table (caa_template) {
        defect_type : short;
        related_layer : M1 ;
        index_1 ("0.08, 0.09, 0.1, 0.11, 0.12, 0.13, 0.14, 0.15, 0.16,
                  0.17");
        values ("0.03, 0.08, 0.17, 0.28, 0.40, 0.54, 0.68, 0.81, 0.95,
                  1.09");
    }
    ...
}

```

values Attribute

The `values` attribute defines critical area values for nonvia layers in the unit of `distance_unit` squared. For via layers, the `values` attribute specifies the number of single cuts on the layer.

Syntax

```
values ("float...float");
```

Example

```

library(my_library) {
    ...
    critical_area_table (caa_template) {
        defect_type : short;
        related_layer : M1 ;
        index_1 ("0.08, 0.09, 0.1, 0.11, 0.12, 0.13, 0.14, 0.15, 0.16,
                  0.17");
        values ("0.03, 0.08, 0.17, 0.28, 0.40, 0.54, 0.68, 0.81, 0.95,
                  1.09");
    }
    ...
}

```

bundle Group

A `bundle` group uses the `members` complex attribute (unique to bundles) to group together in multibit cells—such as quad latches and 4-bit registers—several pins that have similar timing or functionality.

The `bundle` group contains the following three elements:

- The `members` complex attribute. It must be declared first in a `bundle` group.
- All simple attributes that also appear in a `pin` group.
- The `pin` group statement (including all the `pin` group simple and complex attributes, and group statements).

Syntax

```

library (nameid) {
    cell (nameid) {
        single_bit_degenerate : string ;
        bundle (string) {
            members (string); /*Must be declared first*/
            capacitance : float ;
            ...
            pin (Z0) {
                capacitance : float ;
                ...
                timing () {
                    ...
                }
            }
        }
    }
}

```

Note:

Bundle names, bundle elements, bundle members, members, and member pins are all valid terms for pin names in a `bundle` group.

Simple Attributes

All `pin` group simple attributes are valid in a `bundle` group. Following are examples of three simple attributes, which are described later in this section.

```
capacitance : float ;
direction : input | output | inout | internal ;
function : "Boolean" ;
```

Complex Attribute

```
members (name_id) ;
```

Group Statement

All `pin` group statements are valid in a `bundle` group.

```
pin (name_id | name_list_id) { }
```

pin Attributes in a bundle Group

The `pin` group simple attributes in a `bundle` group define default attribute values for all pins in that `bundle` group. The `pin` attributes can also appear in a `pin` group within the `bundle` group.

capacitance Simple Attribute

Use the `capacitance` attribute to define the load of an input, output, inout, or internal pin.

Syntax

```
capacitance : value_float ;
```

`value`

A floating-point number in units consistent with other capacitance specifications throughout the library. Typical units of measure for capacitance include picofarads and standardized loads.

The following example shows a `bundle` group that defines a `capacitance` attribute value of 1 for input pins D0, D1, D2, and D3 in bundle D:

Example

```
bundle (D) {
    members(D0, D1, D2, D3) ;
    direction : input ;
    capacitance : 1 ;
}
```

direction Simple Attribute

The `direction` attribute states the direction of member pins in a `bundle` group.

The direction listed for this attribute should be the same as that given for the pin in the same `bundle` group (see the `bundle Z` pin in [Example 2-4](#)).

Syntax

```
direction : input | output | inout | internal ;
```

Example

In a `bundle` group, the direction of all pins must be the same. [Example 2-4](#) shows two `bundle` groups. The first group shows two pins (Z0 and Z1) whose direction is output. The second group shows one pin (D0) whose direction is input.

Example 2-4 Direction of Pins in bundle Groups

```
cell(inv) {
```

```

area : 16 ;
cell_leakage_power : 8 ;
bundle(Z) {
    members(Z0, Z1, Z2, Z3) ;
    direction : output ;
    function : "D" ;
    pin(Z0) {
        direction : output ;
        timing() {
            intrinsic_rise : 0.4 ;
            intrinsic_fall : 0.4 ;
            related_pin : "D0" ;
        }
    }
    pin(Z1) {
        direction : output ;
        timing() {
            intrinsic_rise : 0.4 ;
            intrinsic_fall : 0.4 ;
            related_pin : "D1" ;
        }
    }
}
bundle(D) {
    members (D0, D1, D2, D3) ;
    direction : input ;
    capacitance : 1 ;
    pin (D0 {
        direction : input ;
        ...
    }
}
}

```

function Simple Attribute

The `function` attribute in a `bundle` group defines the value of an output pin or inout pin in terms of the input pins or inout pins in the `cell` group or `model` group.

Syntax

```
function : "Boolean expression" ;
```

[Table 2-4](#) lists the Boolean operators valid in a function statement.

Table 2-4 Valid Boolean Operators

Operator	Description
'	invert previous expression
!	invert following expression
^	logical XOR
*	logical AND
&	logical AND
space	logical AND
+	logical OR
	logical OR
1	signal tied to logic 1
0	signal tied to logic 0

The order of precedence of the operators is left to right, with inversion performed first, then XOR, then AND, then OR.

Pin Names as Function Arguments

The following example describes bundle `Q` with the function A OR B:

```

bundle (Q) {
    direction : output ;
    function : "A + B" ;
}

```

A pin name beginning with a number must be enclosed in double quotation marks preceded by a backslash (\), as in the following example.

```
function : "\"1A\" + \"1B\" ;
```

The absence of a backslash causes the quotation marks to terminate the `function` string.

The following `function` statements all describe 2-input multiplexers. The parentheses are optional. The operators and operands are separated by spaces.

```

function : "A S + B S'" ;
function : "A & S | B & !S" ;
function : "(A * S) + (B * S')" ;

```

members Complex Attribute

The `members` attribute lists the pin names of signals in a bundle. It provides the bundle element names, and it groups a set of pins that have similar properties. It must be the first attribute you declare in a `bundle` group.

Syntax

```

bundle (namestring) {
    members (member1, member2 ... ) ;
    ...
}

member1 , member2 ...

```

The number of bundle members defines the width of the bundle.

Example

```
members (D1, D2, D3, D4) ;
```

If the `function` attribute has been defined for the `bundle`, the `function` value is copied to all `bundle` `members`.

Example

```

bundle(A) {
    members(A0, A1, A2, A3);
    direction : output ;
    function : "B' + C" ;
    ...
}
bundle(B) {
    members(B0, B1, B2, B3);
    direction : input;
    ...
}

```

The previous example shows that the members of the `A` bundle have these values:

```

A0 = B0' + C ;
A1 = B1' + C ;
A2 = B2' + C ;
A3 = B3' + C ;

```

Each bundle operand (`B`) must have the same width as the function parent bundle (`A`).

[Example 2-5](#) shows how to define a `bundle` group in a cell with a multibit latch.

Example 2-5 Multibit Latch With Signal Bundles

```

cell (latch4) {
    area: 16 ;
    single_bit_degenerate : FDB ;
    pin (G) { /* active-high gate enable signal */
        direction : input ;
        ...
    }
    bundle (D){ /* data input with four member
        pins */
        members (D1, D2, D3, D4) ; /*must be first
            attribute */
        direction : input ;
    }
    bundle (Q) {
        members (Q1, Q2, Q3, Q4) ;
        direction : output ;
        function : "IQ" ;
    }
    bundle (QN) {
        members (Q1N, Q2N, Q3N, Q4N) ;
        direction : output ;
        function : "IQN" ;
    }
    latch_bank(IQ, IQN, 4) {
        enable : "G" ;
        data_in : "D" ;
    }
}

```

pin Group Statement in a bundle Group

You can define attribute values for specific pins or groups of pins in a `pin` group within a `bundle` group. Values in a `pin` group override the default attribute values defined for the `bundle` (described previously).

Syntax

```

bundle(name_string) {
    pin (name_string) {
        ... pin description ...
    }
}

```

The following example shows a `pin` group in a `bundle` group that defines a new `capacitance` attribute value for member `A0` in `bundle A`:

Example

```

bundle (A) {
    pin (A0) {
        capacitance : 4 ;
    }
}

```

To identify the name of a pin in a `pin` group within a `bundle` group, use the full name of a pin, such as `pin (A0)` in the previous example.

All pin names within a single `bundle` group must be unique. Pin names are case-sensitive; for example, pins named `A` and `a` are different pins.

[Example 2-4](#) shows a `pin` group within a `bundle` group.

bus Group

A `bus` group, defined in a `cell` group or a `model` group, defines the bused pins in the library. Before you can define a `bus` group you must first define a `type` group at the library level.

From the `type` group you define at the library level, use the type name (`bus4` in [Example 2-6](#)) as the value for the `bus_type` attribute in the `bus` group in the same library.

[Example 2-6](#) shows a `bus` group in a `cell` group.

Example 2-6 Bused Pins

```
library (ExamBus) {
    type (bus4) { /* bus name */
        bit_width : 4; /* number of bused pins */
        ...
        ...
    }
    cell (bused cell) {
        ...
        bus (A) {
            bus_type : bus4; /* bus name */
            ...
            ...
        }
    }
}
```

Simple Attributes

You can use all the `pin` simple attributes in a `bus` group, plus the following attribute.

`bus_type : name;`

Group Statement

`pin (namestring | name_liststring) {}`

All group statements that appear in a `pin` group are valid in a `bus` group.

bus_type Simple Attribute

The `bus_type` attribute is a required element of all `bus` groups. The attribute defines the type of bus. It must be the first attribute declared in a `bus` group.

Syntax

`bus_type : name;`

`name`

Define this name in the applicable `type` group in the library, as shown in [Example 2-6](#).

pin Simple Attributes in a bus Group

The `pin` simple attributes in a `bus` group define default attribute values for all pins in the `bus` group.

Note:

Bus names, bus members, bus pins, bused pins, pins, members, member numbers, and range of bus members are valid terms for pin names in a `bus` group.

All `pin` group simple attributes are valid within a `bus` group and within a `pin` group in a `bus` group.

The `capacitance` and `direction` attributes are frequently used in `bus` groups.

capacitance Simple Attribute

Use the `capacitance` attribute to define the load of an input, output, inout, or internal pin.

Syntax

`capacitance : valuefloat;`

`value`

A floating-point number in units consistent with other capacitance specifications throughout the library. Typical units of measure for capacitance include picofarads and standardized loads.

The following example shows a `bus` group that defines bus A with default values assigned for direction and capacitance.

Example

```
bus (A) {  
    bus_type : bus1 ;  
    direction : input ;  
    capacitance : 3 ;  
}
```

direction Simple Attribute

The `direction` attribute states the direction of bus members (pins) in a `bus` group.

The value of the `direction` attribute of all bus members (pins) in a `bus` group must be the same. (To see a `bus` group with more than one pin, refer to [Example 2-7](#).)

Syntax

```
direction : input | output | inout | internal ;
```

Example

```
direction : inout ;
```

pin Group Statement in a bus Group

This group defines attribute values for specific bused pins or groups of bused pins in a `pin` group within a `bus` group. Values used in a `pin` group within a `bus` group override the defined default bus pin attribute values described previously.

Note:

You can use a defined bus or buses in Boolean expressions in the `function` attribute of a pin in a `bus` group, as shown in [Example 2-7](#).

The following example shows a bus pin group that defines a new `capacitance` attribute value for member AO in bus A.

```
bus(A) {  
    pin (AO) {  
        capacitance : 4 ;  
    }  
}
```

To identify the name of a bused pin in a `pin` group within a `bus` group, use the full name of the pin. You can identify bus member numbers as single numbers or as a range of numbers separated by a colon. No spaces can appear between the colon and the member numbers.

Example

```
pin (A[0:2]) {}
```

The next example shows a `pin` group within a `bus` group that defines a new `capacitance` attribute value for a single pin number.

```
bus(A) {  
    pin (A) {  
        capacitance : 4 ;  
    }  
}
```

The next example shows a `pin` group within a `bus` group that defines a new `capacitance` attribute value for bus members 0, 1, 2, and 3 in bus A.

```
bus(A) {  
    pin (A[0:3]) {  
        capacitance : 4 ;  
    }  
}
```

Sample Bus Description—Technology Library

[Example 2-7](#) illustrates a complete bus description that includes a library-defined type group and cell-defined bus groups. The example also illustrates the use of bus variables in a function attribute in a pin group and in a related_pin attribute in a timing group.

Example 2-7 Bus Description

```
library (ExamBus) {
    date : "November 12, 2000" ;
    revision : 2.3 ;
    bus_naming_style : "%s[%d]" ;
    /* Optional; this is the default */
    type (bus4) {
        base_type : array /* Required */
        data_type : bit /* Required if base_type is array */
        bit_width : 4 /* Optional; default is 1 */
        bit_from : 0 /* Optional MSB; defaults to 0 */
        bit_to : 3 /* Optional LSB; defaults to 0 */
        downto : false /* Optional; defaults to false */
    }
    cell (bused_cell) {
        area : 10 ;
        single_bit_degenerate : FDB ;
        bus (A) {
            bus_type : bus4 ;
            direction : input ;
            capacitance : 3 ;
            pin (A[0:2]) {
                capacitance : 2 ;
            }
            pin (A[3]) {
                capacitance : 2.5 ;
            }
        }
        bus (B) {
            bus_type : bus4 ;
            direction : input ;
            capacitance : 2 ;
        }
        bus (E) {
            direction : input ;
            capacitance 2 ;
        }
        bus(X) {
            bus_type : bus4 ;
            direction : output ;
            capacitance : 1 ;
            pin (X[0:3]) {
                function : "A & B'" ;
                timing() {
                    related_pin : "A B" ;
                    /* A[0] and B[0] are related to X[0],
                     A[1] and B[1] are related to X[1], etc. */
                }
            }
        }
        bus (Y) {
            bus_type : bus4 ;
            direction : output ;
            capacitance : 1 ;
            pin (Y[0:3]) {
                function : "B" ;
                three_state : "!E" ;
                timing () {
                    related_pin : "A[0:3] B E" ;
                }
            }
        }
        bus (Z) {
            bus_type : bus4 ;
            direction : output ;
            pin (Z[0:1]) {
```

```

        function : "!A[0:1]" ;
        timing () {
            related_pin : "A[0:1]" ;
        }
    }
    pin (Z[2]) {
        function "A[2]" ;
        timing () {
            related_pin : "A[2]" ;
        }
    }
    pin (Z[3]) {
        function : "!A[3]" ;
        timing () {
            related_pin : "A[3]" ;
        }
    }
}
}

```

dynamic_current Group

Use the `dynamic_current` group to specify a current waveform vector when the power and ground current is dependent on the logical condition of a cell. A `dynamic_current` group is defined in a `cell` group, as shown here:

```

library (name) {
    cell (name) {
        dynamic_current () {
            when : <boolean expression>
            related_inputs : <input_pin_name>;
            related_outputs : <output_pin_name>;
            typical_capacitances("<float>, ...");
            switching_group() {
                input_switching_condition(<enum(rise, fall)>);
                output_switching_condition(<enum(rise, fall)>);
                pg_current(<pg_pin_name>) {
                    vector(<template_name> {
                        reference_time : <float>;
                        index_output : <output_pin_name>;
                        index_1(<float>);
                        ...
                        index_n(<float>);
                        index_n+1("<float>, ...");
                        values("<float>, ...");
                    } /* vector */
                    ...
                } /* pg_current */
                ...
            } /* switching_group */
            ...
        } /* dynamic_current */
        ...
    } /* cell */
}

```

Simple Attributes

`related_inputs`
`related_outputs`
`typical_capacitances`
`when`

Group Statement

`switching_group`

related_inputs Simple Attribute

This attribute defines the input condition of input pins. If only one input is switching during the time period, the input condition is defined as “single input event.” If more than one input pin is switching, the input condition is defined as “multiple input events.”

- This attribute is required.

- A list of input pins can be specified in the attribute.
- Because “single input event” is supported, exactly one of the input pins in the list must be toggling to match the input condition.
- “Multiple input events” are not supported.
- The pins in the list can be in any order.
- Bus and bundle are supported.

Syntax

`related_inputs : <input_pin_name>;`

input_pin_name

Name of input pin.

Example

`related_inputs : A ;`

`related_outputs` Simple Attribute

The `related_outputs` attribute defines the output condition of specified output pins. If no toggling output occurs as a trigger event is given, the condition is called a “non-propagating event.” If an event propagates through the cell and causes at least one output toggling, then it is called a “propagating event.”

- This attribute is optional.
- A list of output pins can be specified in the attribute. A “single input event” matches the output condition for all toggling output pins in the list. The pins in the list can be in any order. Bus and bundle are supported only in bit level. For a standard cell, if the attribute is specified, it represents a “propagating event.” Otherwise, if it is missing, it represents a “non-propagating event.” There is no `related_outputs` attribute for macro cells. Therefore, you do not need to distinguish between non-propagating and propagating event tables.

Syntax

`related_outputs : <output_pin_name> ;`

output_pin_name

Name of output pin.

Example

`related_outputs : D ;`

`typical_capacitances` Simple Attribute

The `typical_capacitances` attribute defines fixed capacitance values for all output pins specified in `related_outputs`. The order in the list of this attribute is mapped to the same order of output pins in the `related_outputs` attribute. For example:

```
...
/* the fixed capacitance of Q1 is 10.0, Q2 is 20.0, and Q3
is 30.0.*/
related_outputs : "Q1 Q2 Q3";
typical_capacitances(10.0 20.0 30.0);
...
```

The attribute is required for cross type. If data in the vector group is not defined as a sparse cross table, the specified values in the attribute will be ignored.

Syntax

`typical_capacitances ("<float>, ...");`

float

Value of capacitance on pin.

Example

`typical_capacitances (10.0 20.0);`

when Simple Attribute

Use the `when` attribute to specify a state-dependent condition that determines whether the instantaneous power data can be accessed.

Syntax

```
when : <boolean expression>  
  
    boolean expression  
  
        Expression determines whether the instantaneous power data is accessed.
```

switching_group Group

Use the `switching_group` group to specify a current waveform vector when the power and ground current is dependent on pin switching conditions.

```
library (name) {  
    cell (name) {  
        dynamic_current () {  
            ...  
            switching_group() {  
                ... switching_group      description...  
            }  
        }  
    }  
}
```

Simple Attributes

```
input_switching_condition  
output_switching_condition  
min_input_switching_count  
max_input_switching_count
```

Group

```
pg_current
```

input_switching_condition Simple Attribute

Use the `input_switching_condition` attribute to specify the sense of the toggling input. If there is more than one `switching_group` group specified within the `dynamic_current` group, you can place the attribute in any order. The order in the list of the `output_switching_condition` attribute is mapped to the same order of output pins in the `related_outputs` attribute. Two values are allowed: `rise` represents a rising pin and can be applied for input/output switching conditions and `fall` represents a falling pin and can be applied for input/output switching conditions.

Syntax

```
input_switching_condition (<enum(rise, fall)>);  
  
    enum(rise, fall)  
  
        Enumerated type specifying the rise or fall condition.
```

Example

```
input_switching_condition (rise);
```

output_switching_condition Simple Attribute

Use the `output_switching_condition` attribute to specify the sense of the toggling output. If there is more than one `switching_group` group specified within the `dynamic_current` group, you can place the attribute in any order. The order in the list of the `output_switching_condition` attribute is mapped to the same order of output pins in the `related_outputs` attribute. Currently, two values are considered: `rise` represents a rising pin and can be applied for input/output switching conditions and `fall` represents a falling pin and can be applied for input/output switching conditions.

Syntax

```
output_switching_condition (<enum(rise, fall)>);
```

`enum(rise, fall)`

Enumerated type specifying the rise or fall condition.

Example

```
output_switching_condition (rise, fall);
```

min_input_switching_count Simple Attribute

The `min_input_switching_count` attribute specifies the minimum number of bits in the input bus that are switching simultaneously. The following applies to the `min_input_switching_count` attribute:

- The count must be an integer.
- The count must be greater than 0 and less than the `max_input_switching_count` value.

Syntax

```
switching_group() {  
    min_input_switching_count : integer;  
    max_input_switching_count : integer;  
    ...  
}
```

Example

```
switching_group() {  
    min_input_switching_count : 1;  
    max_input_switching_count : 3;  
    ...  
}
```

max_input_switching_count Attribute

The `max_input_switching_count` attribute specifies the maximum number of bits in the input bus that are switching simultaneously. The following applies to the `max_input_switching_count` attribute:

- The count must be an integer.
- The count must be greater than the `min_input_switching_count` value.
- The count within a `dynamic_current` should cover the total number of input bits specified in `related_inputs`.

Syntax

```
switching_group() {  
    min_input_switching_count : integer;  
    max_input_switching_count : integer;  
    ...  
}
```

Example

```
switching_group() {  
    min_input_switching_count : 1;  
    max_input_switching_count : 3;  
    ...  
}
```

pg_current Group

Use the `pg_current` group to specify current waveform data in a vector group. If all vectors under the group are dense, data in this group is represented as a dense table. If all vectors under the group are sparse in cross type, data in this group is represented as a sparse cross table. If all vectors under the group are sparse in diagonal type, data in this group is represented as a sparse diagonal table.

```
library (name) {  
    cell (name) {  
        dynamic_current () {  
            ...  
            switching_group() {  
                ...  
                pg_current () {}  
                ...  
            }  
        }  
    }  
}
```

```

        }
    }
}
}
```

Group

vector

compact_ccs_power Group

The `compact_ccs_power` group contains a detailed description for compact CCS power data. The `compact_ccs_power` group includes the following optional attributes: `base_curves_group`, `index_1`, `index_2`, `index_3` and `index_4`. The description for these attributes in the `compact_ccs_power` group is the same as in the `compact_lut_template` group. However, the attributes have a higher priority in the the `compact_ccs_power` group. For more information, see "[compact_lut_template Group](#)".

The `index_output` attribute is also optional. It is used only on cross type tables. For more information about the `index_output` attribute, see "[index_output Simple Attribute](#)".

```

library (name) {
    cell(<cell_name>) {
        dynamic_current() {
            switching_group() {
                pg_current(<pg_pin_name>) {
                    compact_ccs_power (<template_name>) {
                        base_curves_group : <bc_name>;
                        index_output : <pin_name>;
                        index_1 ("float, ..., float");
                        index_2 ("float, ..., float");
                        index_3 ("float, ..., float");
                        index_4 ("string, ..., string");
                        values ("float/integer, ..., float/integer");
                    } /* end of compact_ccs_power */
                }
            }
        }
    }
}
```

Complex Attributes

```

base_curves_group : <bc_name>;
index_output : <pin_name>;
index_1 ("float, ..., float");
index_2 ("float, ..., float");
index_3 ("float, ..., float");
index_4 ("string, ..., string");
values ("float/integer, ..., float/integer");
```

values Attribute

The `values` attribute is required in the `compact_ccs_power` group. The data within the quotation marks (" "), or *line*, represent the current waveform for one index combination. Each value is determined by the corresponding curve parameter. In the following line,

"t0, c0, 1, t1, c1, 2, t2, c2, 3, t3, c3, 4, t4, c4"

the size is $14 = 8+3*2$. Therefore, the curve parameters are as follows:

```
"init_time, init_current, bc_id1, point_time1, point_current1, bc_id2, \
point_time2, point_current2, bc_id3, point_time3, point_current3,
bc_id4, \
end_time, end_current"
```

The elements in the `values` attribute are floating-point numbers for time and current and integers for the base curve ID. The number of current waveform segments can be different for each slew and load combination, which means that each line size can be different. As a result, Liberty syntax supports tables with varying sizes, as shown:

```
compact_ccs_power (<template_name>) {
...
    index_1("0.1, 0.2"); /* input_net_transition */
    index_2("1.0, 2.0"); /* total_output_net_capacitance */
    index_3 ("init_time, init_current, bc_id1, point_time1, point_current1,
\
```

```

bc_id2, [point_time2, point_current2, bc_id3, ...], \
end_time, end_current"); /* curve_parameters */
values
("t0, c0, 1, t1, c1, 2, t2, c2, 3, t3, c3, 4, t4, c4", /* segment=4 */
 "t0, c0, 1, t1, c1, 2, t2, c2", /* segment=2 */
 "t0, c0, 1, t1, c1, 2, t2, c2, 3, t3, c3", /* segment=3 */
 "t0, c0, 1, t1, c1, 2, t2, c2, 3, t3, c3"); /* segment=3 */
}

```

vector Group

Use the vector group to specify the current waveform for a power and ground pin. This group represents a single current waveform based on specified input slew and output load.

- Data in this group is represented as a dense table, if a template with two `total_output_net_capacitance` variables is applied to the group. If a dense table is applied, the order of `total_output_net_capacitance` variables must map to the order of values in the `related_outputs` attribute.
- Data in this group is represented as a sparse cross table, if the `index_output` attribute is defined in the group.
- Data in this group is represented as a sparse diagonal table, if no `index_output` attribute is defined in the group and a template with exact one `total_output_net_capacitance` variable is applied to the group.

```

library (name) {
  cell (name) {
    dynamic_current () {
      switching_group() {
        pg_current () {
          vector () {
            ...
          }
        }
      }
    }
  }
}

```

Simple Attributes

```

index_1 (<float>);
index_2 (<float>);
index_3 (<float>);
index_4 (<float>);
index_output : <output_pin_name>;
reference_time:<float>;
values ("<float>, ...");

```

index_1, index_, index_3, and index_4 Simple Attributes

The index attributes specify values for variables specified in the `pg_current_template`. The index value for `input_net_transition` or `total_output_net_capacitance` is a single floating-point number. You create a list of floating-point numbers for the index values for time. Note the following:

- Different numbers of points are allowed for each waveform.
- If no output or only one output is specified in `related_outputs`, the table must be dense.
- If two outputs are specified in `related_outputs`, the table can be either dense or sparse.
- If more than two outputs are specified, the table must be sparse.
- For a cross-type sparse table, a fixed capacitance of all outputs must be specified in `typical_capacitances`. The sweeping output must be specified in `index_output`, and the varied capacitance of that output must be specified in one of the index attributes. The specified index attribute must map to the `total_output_net_capacitance` variable in the template.
- For a diagonal-type sparse table, capacitances of all outputs are identical and they can be specified in one of the index attributes. The specified index must map to the `total_output_net_capacitance` variable in the template.

index_output Simple Attribute

This attribute specifies which output capacitance is sweeping while the others are held as fixed values. This attribute is required for cross type. The attribute cannot be defined if the vector table is not defined as a sparse cross table.

Syntax

```
index_output : <output_pin_name>;
```

output_pin_name

Name of the pin that the output capacitance is sweeping.

Example

```
index_output : "QN";
```

reference_time Simple Attribute

This attribute represents the time at which the input waveform crosses the reference voltage.

Syntax

```
reference_time : <float>;
```

float

Specifies the time at which the input waveform crosses the reference voltage.

Example

```
reference_time : 0.01;
```

values Simple Attribute

The **values** attribute defines a list of floating-point numbers that represent the dynamic current waveform of a specified power and ground pin.

Syntax

```
values("<float>, ...");
```

float

Defines a list of floating-point numbers that represent the dynamic current waveform of a specified power and ground pin.

Example

```
values : ("0.002, 0.009, 0.134, 0.546");
```

ff Group

The **ff** group describes either a single-stage or a master-slave flip-flop in a cell or test cell. The syntax for a cell is shown here. For information about the **test_cell** group, see ["test_cell Group"](#).

Syntax

```
library (namestring) {  
    cell (namestring) {  
        ff (variable1string, variable2string) {  
            ... flip-flop description ...  
        }  
    }  
}
```

The **variable1** value is the state of the noninverting output of the flip-flop; the **variable2** value is the state of the inverting output. The **variable1** value can be considered the 1-bit storage of the flip-flop. Valid values for **variable1** and **variable2** are anything except a pin name used in the cell being described. Both of these variables must be assigned, even if one of them is not connected to a primary output pin.

Simple Attributes

```
clear : "Boolean expression" ;  
clear_preset_var1 : L | H | N | T | X ;  
clear_preset_var2 : L | H | N | T | X ;  
clocked_on : "Boolean expression" ;  
clocked_on_also : "Boolean expression" ;  
next_state : "Boolean expression" ;  
preset : "Boolean expression" ;
```

clear Simple Attribute

The `clear` attribute gives the active value for the clear input.

Syntax

```
clear : "Boolean expression" ;
```

Example

```
clear : "CD' " ;
```

["Single-Stage Flip-Flop"](#) contains more information about the `clear` attribute.

clear_preset_var1 Simple Attribute

The `clear_preset_var1` attribute gives the value that `variable1` has when clear and preset are both active at the same time.

Syntax

```
clear_preset_var1 : L | H | N | T | X ;
```

Example

```
clear_preset_var1 : H ;
```

[Table 2-5](#) shows the valid variable values for the `clear_preset_var1` simple attribute.

Table 2-5 Valid Values for the `clear_preset_var1` and `clear_preset_var2` Attributes

Variable values	Equivalence
L	0
H	1
N	No change ¹
T	Toggle the current value from 1 to 0, 0 to 1, or X to X
X	Unknown

¹ Use these values to generate VHDL models.

["Single-Stage Flip-Flop"](#) contains more information about the `clear_preset_var1` attribute, including its function and values.

clear_preset_var2 Simple Attribute

The `clear_preset_var2` attribute gives the value that `variable2` has when clear and preset are both active at the same time.

Syntax

```
clear_preset_var2 : L | H | N | T | X ;
```

Example

```
clear_preset_var2 : L ;
```

["Single-Stage Flip-Flop"](#) contains more information about the `clear_preset_var2` attribute, including its function and values.

clocked_on and clocked_on_also Simple Attributes

The `clocked_on` and `clocked_on_also` attributes identify the active edge of the clock signals and are required in all `ff` groups. For example, use `clocked_on : "CP"` to describe a rising-edge-triggered device and use `clocked_on_also : "CP"` for a falling-edge-triggered device.

Note:

A single-stage flip-flop does not use `clocked_on_also`. See “[Single-Stage Flip-Flop](#)” for details.

When describing flip-flops that require both a master clock and a slave clock, use the `clocked_on` attribute for the master clock and the `clocked_on_also` attribute for the slave clock.

Syntax

```
clocked_on : "Boolean expression" ;
clocked_on_also : "Boolean expression" ;
```

Boolean expression

Active edge of a clock signal.

Example

```
clocked_on : "CP" ;
clocked_on_also : "CP'" ;
```

Syntax

```
next_state : "Boolean expression" ;
```

The following example shows an `ff` group for a single-stage D flip-flop.

```
ff (IQ, IQN) {
    next_state : "D" ;
    clocked_on : "CP" ;
}
```

The example defines two variables, `IQ` and `IQN`. The `next_state` equation determines the value of `IQ` after the next active transition of the `clocked_on` attribute. In this example, `IQ` is assigned the value of the `D` input.

In some flip-flops, the next state depends on the current state. In this case, the first state variable (`IQ` in the example) can be used in the `next_state` statement; the second state variable, `IQN`, cannot.

For example, the `ff` declaration for a JK flip-flop looks like this:

```
ff(IQ,IQN) {
    next_state : "(J K IQ') + (J K') + (J' K' IQ)" ;
    clocked_on : "CP" ;
}
```

The `next_state` and `clocked_on` attributes completely define the synchronous behavior of the flip-flop.

`preset` Simple Attribute

The `preset` attribute gives the active value for the preset input.

Syntax

```
preset : "Boolean expression" ;
```

Example

```
preset : "PD'" ;
```

[Single-Stage Flip-Flop](#)

A single-stage flip-flop does not use the optional `clocked_on_also` attribute.

The `clear` attribute gives the active value for the clear input. The `preset` attribute gives the active value for the preset input. For example, the following statement defines an active-low clear signal:

```
clear : "CD" ;
```

[Table 2-6](#) shows the functions of the attributes in the `ff` group for a single-stage flip-flop.

Table 2-6 Function Table for a Single-Stage Flip-Flop

clocked_on	clear	preset	variable1	variable2
active edge	inactive	inactive	next_state	!next_state
--	active	inactive	0	1
--	inactive	active	1	0
--	active	active	clear_preset_var1	clear_preset_var2

The `clear_preset_var1` and `clear_preset_var2` attributes give the value that `variable1` and `variable2` have when `clear` and `preset` are both active at the same time. See [Table 2-6](#) for the valid variable values.

If the `clear` and `preset` attributes are both included in the group, either `clear_preset_var1`, `clear_preset_var2`, or both must be defined. Conversely, if either `clear_preset_var1`, or `clear_preset_var2`, or both are included, both `clear` and `preset` must be defined.

The flip-flop cell is activated whenever the value of `clear`, `preset`, `clocked_on`, or `clocked_on_also` changes.

[Example 2-8](#) is an `ff` group for a single-stage D flip-flop with rising-edge sampling, negative clear and preset, and output pins set to 0 when both clear and preset are active (low).

Example 2-8 Single-Stage D Flip-Flop

```
ff(IQ, IQN) {
    next_state : "D" ;
    clocked_on : "CP" ;
    clear : "CD'" ;
    preset : "PD'" ;
    clear_preset_var1 : L ;
    clear_preset_var2 : L ;
}
```

[Example 2-9](#) is an `ff` group for a single-stage, rising-edge-triggered JK flip-flop with scan input, negative clear and preset, and output pins set to 0 when clear and preset are both active.

Example 2-9 Single-Stage JK Flip-Flop

```
ff(IQ, IQN) {
    next_state :
        "(TE'*TI)+(TE'*J*K')+(TE'*J'*K'*IQ)+(TE'*J*K*IQ')" ;
    clocked_on : "CP" ;
    clear : "CD'" ;
    preset : "PD'" ;
    clear_preset_var1 : L ;
    clear_preset_var2 : L ;
```

[Example 2-10](#) is an `ff` group for a D flip-flop with synchronous negative clear.

Example 2-10 D Flip-Flop With Synchronous Negative Clear

```
ff (IQ, IQN) {
    next_state : "D * CLR'" ;
    clocked_on : "CP" ;
}
```

Master-Slave Flip-Flop

The syntax for a master-slave flip-flop is the same as for a single-stage device, except that it includes the `clocked_on_also` attribute. [Table 2-7](#) shows the functions of the attributes in the `ff` group for a master-slave flip-flop.

The `internal1` and `internal2` variables represent the output values of the master stage, and `variable1` and `variable2` represent the output values of the slave stage. The `variable1` and `variable2` variables have the same value as `internal1` and `internal2`, respectively, when `clear` and `preset` are both active at the same time.

Table 2-7 Function Table for a Master-Slave Flip-Flop

Variable	Functions				
clear	active	active	inactive	inactive	inactive
preset	active	inactive	active	inactive	inactive
internal1	clear_preset_var1	0	1	next_state	
internal2	clear_preset_var2	1	0	!next_state	
variable1	clear_preset_var1	0	1		internal1
variable2	clear_preset_var2	1	0		internal2
active edge				clocked_on	clocked_on_also

[Example 2-11](#) shows an `ff` group for a master-slave D flip-flop with rising-edge sampling, falling-edge data transfer, negative clear and preset, and output values set high when clear and preset are both active.

Example 2-11 Master-Slave D Flip-Flop

```
ff(IQ, IQN) {
    next_state : "D" ;
    clocked_on : "CLK" ;
    clocked_on_also : "CLKN' " ;
    clear : "CDN' " ;
    preset : "PDN' " ;
    clear_preset_var1 : H ;
    clear_preset_var2 : H ;
}
```

next_state Simple Attribute

Required in all `ff` groups, `next_state` is a logic equation written in terms of the cell's input pins or the first state variable, `variable1`. For single-stage storage elements, the `next_state` attribute equation determines the value of `variable1` at the next active transition of the `clocked_on` attribute.

For devices such as a master-slave flip-flop, the `next_state` equation determines the value of the master stage's output signals at the next active transition of the `clocked_on` attribute.

The type of pin that appears in the Boolean expression of a `next_state` attribute is defined in a `pin` group with the `nextstate_type` attribute.

ff_bank Group

An `ff_bank` group is defined within a `cell` or `test_cell` group, as shown in the following syntax, and in a `scaled_cell` group at the library level.

The `ff_bank` group describes a cell that is a collection of parallel, single-bit sequential parts. Each part can share control signals with the other parts and performs an identical function. The `ff_bank` group is typically used to represent multibit registers in `cell` and `test_cell` groups. For information about `ff_bank` in test cells, see ["test_cell Group"](#).

The syntax for the `ff_bank` group is similar to that of the `ff` group.

Syntax

```
library (name_string) {
    cell (name_string) {
        ff_bank (variable1_string, variable2_string,
                 bits_integer) {
            ... multibit flip-flop register description ...
        }
    }
}
```

Simple Attributes

```

clocked_on : "Boolean expression" ;
next_state : "Boolean expression" ;
clear : "Boolean expression" ;
preset : "Boolean expression" ;
clear_preset_var1 : L | H | N | T | X ;
clear_preset_var2 : L | H | N | T | X ;
clocked_on_also : "Boolean expression" ;

```

[Example 2-12](#) shows an `ff_bank` group for a multibit D flip-flop.

An input described in a `pin` group, such as the `clk` input, is fanned out to each flip-flop in the bank. Each primary output must be described in a `bus` or `bundle` group, whose function statement must include either `variable1` or `variable2`.

clocked_on and *clocked_on_also* Simple Attributes

Required in all `ff_bank` groups, the `clocked_on` and `clocked_on_also` attributes identify the active edge of the clock signal.

When describing flip-flops that require both a master and a slave clock, use the `clocked_on` attribute for the master clock and the `clocked_on_also` attribute for the slave clock.

Syntax

```

clocked_on : "Boolean expression" ;
clocked_on_also : "Boolean expression" ;

```

Boolean expression

Active edge of the edge-triggered device.

Examples

```

clocked_on : "CP" ; /* rising-edge-triggered device */

clocked_on_also : "CP'" ; /* falling-edge-triggered device */

```

next_state Simple Attribute

Required in all `ff_bank` groups, the `next_state` attribute is a logic equation written in terms of the cell's input pins or the first state variable, `variable1`. For single-stage flip-flops, the `next_state` attribute equation determines the value of `variable1` at the next active transition of the `clocked_on` attribute.

For devices such as master-slave flip-flops, the `next_state` equation determines the value of the master stage's output signals at the next active transition of the `clocked_on` attribute.

Syntax

```

next_state : "Boolean expression" ;

```

Boolean expression

Identifies the active edge of the clock signal.

Example

```

next_state : "D" ;

```

The type of a `next_state` attribute is defined in a `pin` group with the `nextstate_type` attribute.

clear Simple Attribute

The `clear` attribute gives the active value for the clear input.

Syntax

```

clear : "Boolean expression" ;

```

Example

```
clear : "CD' " ;
```

See ["Single-Stage Flip-Flop"](#) for more information about the `clear` attribute.

preset Simple Attribute

The `preset` attribute gives the active value for the preset input.

Syntax

```
preset : "Boolean expression" ;
```

Example

```
preset : "PD' " ;
```

See ["Single-Stage Flip-Flop"](#) for more information about the `preset` attribute.

clear_preset_var1 Simple Attribute

The `clear_preset_var1` attribute gives the value that variable1 has when `clear` and `preset` are both active at the same time.

Syntax

```
clear_preset_var1 : L | H | N | T | X ;
```

Example

```
clear_preset_var1 : L ;
```

See ["Single-Stage Flip-Flop"](#) for more information about the `clear_preset_var1` attribute, including its function and values.

[Table 2-8](#) shows the valid variable values for the `clear_preset_var1` attribute.

Table 2-8 Valid Values for the `clear_preset_var1` and `clear_preset_var2` Attributes

Variable values	Equivalence
L	0
H	1
N	No change ¹
T	Toggle the current value from 1 to 0, 0 to 1, or X to X ¹
X	Unknown ¹

¹ Use these values to generate VHDL models.

clear_preset_var2 Simple Attribute

The `clear_preset_var2` attribute gives the value that variable2 has when `clear` and `preset` are both active at the same time. [Table 2-8](#) shows the valid variable values for the `clear_preset_var2` attribute.

Syntax

```
clear_preset_var2 : L | H | N | T | X ;
```

Example

```
clear_preset_var2 : L ;
```

See ["Single-Stage Flip-Flop"](#) for more information about the `clear_preset_var1` attribute, including its function and values.

Multibit Flip-Flop


The *bits* value in the `ff_bank` definition is the number of bits in this multibit cell.

Syntax

```
library (name_string) {
    cell (name_string) {
        ff_bank (variable1_string, variable2_string,
            bits_integer) {
            ... multibit flip-flop register description ...
        }
    }
}
```

A multibit register containing four rising-edge-triggered D flip-flops with `clear` and `preset` is shown in [Figure 2-1](#) and [Example 2-12](#).

Figure 2-1 Multibit Register



Example 2-12 Multibit Register

```
cell (dff4) {
    area : 1 ;
    pin (CLK) {
        direction : input ;
        capacitance : 0 ;
        min_pulse_width_low : 3 ;
        min_pulse_width_high : 3 ;
    }
    bundle (D) {
        members(D1, D2, D3, D4);
        nextstate_type : data;
        direction : input ;
        capacitance : 0 ;
        timing() {
            related_pin   : "CLK" ;
            timing_type   : setup_rising ;
            intrinsic_rise : 1.0 ;
            intrinsic_fall : 1.0 ;
        }
        timing() {
            related_pin   : "CLK" ;
            timing_type   : hold_rising ;
            intrinsic_rise : 1.0 ;
            intrinsic_fall : 1.0 ;
        }
    }
    pin (CLR) {
```

```

direction : input ;
capacitance : 0 ;
timing() {
    related_pin : "CLK" ;
    timing_type : recovery_rising ;
    intrinsic_rise : 1.0 ;
    intrinsic_fall : 0.0 ;
}
}
pin(PRE) {
    direction : input ;
    capacitance : 0 ;
    timing() {
    related_pin : "CLK" ;
    timing_type : recovery_rising ;
    intrinsic_rise : 1.0 ;
    intrinsic_fall : 0.0 ;
}
}
ff_bank(IQ, IQN, 4) {
next_state : "D" ;
clocked_on : "CLK" ;
clear : "CLR'" ;
preset : "PRE'" ;
clear_preset_var1 : L ;
clear_preset_var2 : L ;
}
bundle(Q) {
members(Q1, Q2, Q3, Q4) ;
direction : output ;
function : "(IQ)" ;
timing() {
    related_pin : "CLK" ;
    timing_type : rising_edge ;
    intrinsic_rise : 2.0 ;
    intrinsic_fall : 2.0 ;
}
timing() {
    related_pin : "PRE" ;
    timing_type : preset ;
    timing_sense : negative_unate ;
    intrinsic_rise : 1.0 ;
}
timing() {
    related_pin : "CLR" ;
    timing_type : clear ;
    timing_sense : positive_unate ;
    intrinsic_fall : 1.0 ;
}
}
bundle(QN) {
members(Q1N, Q2N, Q3N, Q4N) ;
direction : output ;
function : "IQN" ;
timing() {
    related_pin : "CLK" ;
    timing_type : rising_edge ;
    intrinsic_rise : 2.0 ;
    intrinsic_fall : 2.0 ;
}
timing() {
    related_pin : "PRE" ;
    timing_type : clear ;
    timing_sense : positive_unate ;
    intrinsic_fall : 1.0 ;
}
timing() {
    related_pin : "CLR" ;
    timing_type : preset ;
    timing_sense : negative_unate ;
    intrinsic_rise : 1.0 ;
}
}
}
} /* end of cell dff4 */

```

fpga_condition Group

An fpga_condition group declares an fpga_condition group containing several fpga_condition_value groups.

Syntax

```
cell (nameid) {  
    fpga_condition (nameid) {  
        ...  
    }  
  
    name  
  
    Specifies the name of the fpga_condition group.
```

Group

fpga_condition_value

fpga_condition_value Group

The fpga_condition_value group specifies a condition.

Syntax

```
cell (nameid) {  
    fpga_condition (condition_group_nameid) {  
        fpga_condition_value (condition_nameid){  
            ...  
        }  
    }  
  
    condition_name  
  
    Specifies the name of a condition.
```

Simple Attribute

fpga_arc_condition

fpga_arc_condition Simple Attribute

The fpga_arc_condition attribute specifies a Boolean condition that enables the associated fpga_condition_value group.

Syntax

```
cell (namestring) {  
    fpga_condition (nameid) {  
        fpga_condition_value (condition_nameid){  
            fpga_arc_condition : conditionBoolean;  
        }  
    }  
  
    condition  
  
    Specifies a Boolean condition. Valid values are true and false.
```

Example

```
fpga_arc_condition : true ;
```

functional_yield_metric Group

To model yield information, use the functional_yield_metric group with the faults_lut_template group. For details on the faults_lut_template group, see ["faults_lut_template"](#).

Syntax

```
functional_yield_metric () {
    average_number_of_faults ( namefaults_lut_template ) {
        values ( "float, ..., float" );
    }
}
```

This group holds values for `average_number_of_faults`. The group name indicates that its values array is based on the specified `faults_lut_template` template. The `average_number_of_faults` group holds the array of fault values.

Example

```
library ( my_library_name ) {
    ...
    faults_lut_template ( my_faults_temp ) {
        variable_1 : fab_name;
        variable_2 : time_range;
        index_1 ( "fab1, fab2, fab3" );
        index_2 ( "2005.01, 2005.07, 2006.01, 2006.07" );
    }
    ...
    cell ( and2 ) {
        ...
        functional_yield_metric () {
            average_number_of_faults ( my_faults_temp ) {
                values ( "73.5, 78.8, 85.0, 92", \
                    "74.3, 78.7, 84.8, 92.2", \
                    "72.2, 78.1, 84.3, 91.0" );
            }
        }
        ...
    } /* end of cell */
} /* end of library */
```

This example specifies fault data for three fabs (fab1, fab2, and fab3).

For fab1:

- 73.5 is the average number of faults due to functional yield loss mechanisms (that is, random defects) for the time range 2005.01 to 2005.06
- 78.8 is the average number of faults due to functional yield loss mechanisms for the time range 2005.07 to 2005.12
- 85.0 is the average number of faults due to functional yield loss mechanisms for the time range 2006.01 to 2006.07
- 92.0 is the average number of faults due to functional yield loss mechanisms for the time range 2006.07 or later

For fab2:

- 74.3 is the average number of faults due to functional yield loss mechanisms for the time range 2005.01 to 2005.06
- 78.7 is the average number of faults due to functional yield loss mechanisms for the time range 2005.07 to 2005.12
- 84.8 is the average number of faults due to functional yield loss mechanisms for the time range 2006.01 to 2006.07
- 92.2 is the average number of faults due to functional yield loss mechanisms for the time range 2006.07 or later

And so on for fab3.

generated_clock Group

A `generated_clock` group is defined within a `cell` group or a `model` group to describe a new clock that is generated from a master clock by

- Clock frequency division
- Clock frequency multiplication
- Edge derivation

Syntax

```
cell ( namestring ) {
    generated_clock ( namestring ) {
        ...clock    data...
    }
}
```

Simple Attributes

```
clock_pin : "name1 [name2 name3 ... ]";  
master_pin : name;  
divided_by : integer;  
multiplied_by : integer;  
invert : Boolean;  
duty_cycle : float;
```

Complex Attributes

```
edges  
shifts
```

clock_pin Simple Attribute

The `clock_pin` attribute identifies a pin connected to a master clock signal.

Syntax

```
clock_pin : "name1 [name2 name3 ... ]";
```

Example

```
clock_pin : "clk1 clk2 clk3";
```

master_pin Simple Attribute

The `master_pin` attribute identifies a pin connected to an input clock signal.

Syntax

```
master_pin : name;
```

Example

```
master_pin : clk;
```

divided_by Simple Attribute

The `divided_by` attribute specifies the frequency division factor, which must be a power of 2.

Syntax

```
divided_by : integer;
```

Example

```
generated_clock(genclk1) {  
    clock_pin : clk1;  
    master_pin : clk;  
    divided_by : 2;  
    invert : true;  
}
```

This code fragment shows a clock pin (clk1) generated by dividing the original clock pin (clk) frequency by 2 and then inverting the result.

multiplied_by Simple Attribute

The `multiplied_by` attribute specifies the frequency multiplication factor, which must be a power of 2.

Syntax

```
multiplied_by : integer;
```

Example

```
generated_clock(genclk2) {  
    clock_pin : clk1;
```

```
    master_pin : clk;
    multiplied_by : 2;
    duty_cycle : 50.0;
}
```

This code fragment shows a clock pin (clk1) generated by multiplying the original clock pin (clk) frequency by 2, with a duty cycle of 50.

invert Simple Attribute

The `invert` attribute inverts the waveform generated by multiplication or division. Set this attribute to true to invert the waveform. Set it to false if you do not want to invert the waveform.

Syntax

```
invert : Boolean;
```

Example

```
invert : true;
```

duty_cycle Simple Attribute

The `duty_cycle` attribute specifies the duty cycle, in percentage, if frequency multiplication is used. This is a number between 0.0 and 100.0. The duty cycle is the high pulse width.

Syntax

```
duty_cycle : float;
```

Example

```
duty_cycle : 50.0;
```

edges Complex Attribute

The `edges` attribute specifies a list of three edges from the master clock that form the edges of the generated clock. Use this option when simple division or multiplication is insufficient to describe the generated clock waveform.

Syntax

```
edges (edge1,edge2,edge3);
```

Example

```
edges (1, 3, 5);
```

shifts Complex Attribute

The `shifts` attribute specifies the shifts (in time units) to be added to the edges specified in the edge list to generate the clock. The number of shifts must equal the number of edges (three). This shift modifies the ideal clock edges; it is not considered to be clock latency.

Syntax

```
shifts (shift1,shift2,shift3);
```

Example

```
shifts (5.0, -5.0, 0.0);
```

[Example 2-13](#) shows a generated clock description.

Example 2-13 Description of a Generated Clock

```
cell(acell) {
  ...
  generated_clock(genclk1) {
    clock_pin : clk1;
    master_pin : clk;
```

```

    divided_by : 2;
    invert : true;
}
generated_clock(genclk2) {
    clock_pin : clk1;
    master_pin : clk;
    multiplied_by : 2;
    duty_cycle : 50.0;
}
generated_clock(genclk3) {
    clock_pin : clk1;
    master_pin : clk;
    edges(1, 3, 5);
    shifts(5.0, -5.0, 0.0);
}

.....
pin(clk) {
    direction : input;
    clock : true;
    capacitance : 0.1;
}
pin(clk1) {
    direction : input;
    clock : true;
    capacitance : 0.1;
}
}

```

[intrinsic_parasitic Group](#)

The `intrinsic_parasitic` group specifies the state-dependent intrinsic capacitance and intrinsic resistance of a cell.

[Syntax](#)

```

cell (name_string) {
    intrinsic_parasitic (name_string) {
        when : <boolean expression>;
        intrinsic_resistance(<pg_pin_name>) {
            related_output : <output_pin_name>;
            value : <float>;
        }
        intrinsic_capacitance(<pg_pin_name>) {
            value : <float>;
        }
    }
}

```

[Simple Attribute](#)

`when`

[Groups](#)

`intrinsic_capacitance`
`intrinsic_resistance`
`total_capacitance`

[when Simple Attribute](#)

This attribute specifies the state-dependent condition that determines whether the intrinsic parameters are accessed.

An `intrinsic_parasitic` group without a `when` attribute is defined as a default state. This state is associated with a non-state-dependent parasitic model. If all the state conditions of a cell are specified, a default state is not required. If some of the state conditions of a cell are missing, the default state will be assigned. If some state conditions of a cell are missing and no default state is given, the value of `intrinsic_resistance` defaults to `+infinity` and the value of `intrinsic_capacitance` defaults to 0.

[Syntax](#)

`when : <boolean expression>;`

boolean expression

Specifies the state-dependent condition.

Example

```
when : "A B" ;
```

intrinsic_capacitance Group

Use this group to specify a cell's intrinsic capacitance.

Syntax

```
cell (name_string) {
    intrinsic_parasitic (name_string) {
        intrinsic_capacitance (<pg_pin_name>) {
            value : <float>;
        }
    }
}
```

The `pg_pin_name` specifies a power and ground pin where the capacitance is derived.

You can have more than one `intrinsic_capacitance` group. Groups can be placed in any order within an `intrinsic_parasitic` group.

value Simple Attribute

Specifies the value of the intrinsic capacitance. If some of an `intrinsic_capacitance` group is not defined, the value of the intrinsic capacitance defaults to 0.

Syntax

```
value : <float>;
```

Example

```
value : 5;
```

intrinsic_resistance Group

Use this group to specify a cell's intrinsic resistance between a power and ground pin and an output pin within the `intrinsic_parasitic` group in a cell.

Syntax

```
cell (name_string) {
    intrinsic_parasitic (name_string) {
        intrinsic_resistance (<pg_pin_name>) {
            related_output : <output_pin_name>;
            value : <float>;
        }
    }
}
```

The `pg_pin_name` specifies a power or ground pin. The `intrinsic_resistance` groups can be placed in any order within an `intrinsic_parasitic` group. If some of the `intrinsic_resistance` group is not defined, the value of resistance defaults to +infinity. The channel connection between the power and ground pin and the output pin is defined as a closed channel if the resistance value is greater than 1 megohm. Otherwise, the channel is opened.

The `intrinsic_resistance` group is not required if the channel is closed.

Simple Attributes

`related_output`
`value`

related_output Simple Attribute

Use this attribute to specify the output pin.

Syntax

```
related_output : "output_pin_nameid ;
```

output_pin_name

The name of the output pin.

Example

```
related_outputs : "A B" ;
```

value Simple Attribute

Specifies the value of the intrinsic resistance. If some of an `intrinsic_resistance` group is not defined, the value of the intrinsic resistance defaults to `+infinity`.

Syntax

```
value : <float>;
```

Example

```
value : 5;
```

total_capacitance Group

The `total_capacitance` group specifies the macro cell's total capacitance on a power or ground net within the `intrinsic_parasitic` group. The following applies to the `total_capacitance` group:

- The `total_capacitance` group can be placed in any order if there is more than one `total_capacitance` group within an `intrinsic_parasitic` group.
- The total capacitance parasitics modeling in macro cells is not state dependent, which means that there is no state condition specified in `intrinsic_parasitic`.

Syntax

```
cell (cell_name) {  
    ...  
    intrinsic_parasitic () {  
        total_capacitance (<pg_pin_name>) {  
            value : <float> ;  
        }  
        ...  
    }  
    ...  
}
```

Example

```
cell (my_cell) {  
    ...  
    intrinsic_parasitic () {  
        total_capacitance (VDD) {  
            value : 0.2 ;  
        }  
        ...  
    }  
    ...  
}
```

latch Group

A `latch` group is defined within a `cell`, `model`, or `test_cell` group to describe a level-sensitive memory device. The syntax for defining a `latch` group within a `cell` group is shown here. For information about test cells, see ["test_cell Group"](#).

```
library (namestring) {  
    cell (namestring) {  
        latch (variable1string, variable2string) {  
            ... latch description ...  
        }  
    }  
}
```

```
}
```

The variable1 value is the state of the noninverting output of the latch; the variable2 value is the state of the inverting output. The variable1 value is considered the 1-bit storage of the latch. You can name variable1 and variable2 anything except a pin name used in the cell being described. Both values are required, even if one of them is not connected to a primary output pin.

Simple Attributes

```
clear : "Boolean expression" ;
clear_preset_var1 : L | H | N | T | X ;
clear_preset_var2 : L | H | N | T | X ;
data_in : "Boolean expression" ;
enable : "Boolean expression" ;
enable_also : "Boolean expression" ;
preset : "Boolean expression" ;
```

clear Simple Attribute

The clear attribute gives the active value for the clear input.

Syntax

```
clear : valueBoolean ;
```

Example

The following example defines a low-active clear signal.

```
clear : "CD'" ;
```

clear_preset_var1 and clear_preset_var2 Simple Attributes

The clear_preset_var1 and clear_preset_var2 attributes give the value that variable1 and variable2 have when clear and preset are both active at the same time.

Syntax

```
clear_preset_var1 : L | H | N | T | X ;
clear_preset_var2 : L | H | N | T | X ;
```

Table 2-9 shows the valid values for the clear_preset_var1 and clear_preset_var2 attributes.

Table 2-9 Valid Values for the clear_preset_var1 and clear_preset_var2 Attributes

Variable values	Equivalence
L	0
H	1
N	No change ¹
T	Toggle the current value from 1 to 0, 0 to 1, or X to X ¹
X	Unknown ¹

¹ Use these values to generate VHDL models.

See “[Single-Stage Flip-Flop](#)” for more information about the clear_preset_var1 and clear_preset_var2 attributes, including their function and values.

If you include both clear and preset, you must use either clear_preset_var1, clear_preset_var2, or both. Conversely, if you include clear_preset_var1, clear_preset_var2, or both, you must use both clear and preset.

Example

```
latch(IQ, IQN) {
```

```
    clear : "S' " ;
    preset : "R' " ;
    clear_preset_var1 : L ;
    clear_preset_var2 : L ;
}
```

data_in Simple Attribute

The `data_in` attribute gives the state of the data input, and the `enable` attribute gives the state of the enable input. The `data_in` and `enable` attributes are optional, but if you use one of them, you must also use the other.

Syntax

```
data_in : valueBoolean ;
```

value

State of data input.

Example

```
data_in : "D" ;
```

enable Simple Attribute

The `enable` attribute gives the state of the enable input, and `data_in` attribute gives the state of the data input. The `enable` and `data_in` attributes are optional, but if you use one of them, you must also use the other.

Syntax

```
enable : valueBoolean ;
```

value

State of enable input.

Example

```
enable : "G" ;
```

enable_also Simple Attribute

The `enable_also` attribute gives the state of the `enable` input when you are describing master and slave cells. The `enable_also` attribute is optional. If you use `enable_also`, you must also use the `enable` and `data_in` attributes.

Syntax

```
enable_also : "valueBoolean" ;
```

Value

State of enable input for master-slave cells.

Example

```
enable_also : "G" ;
```

preset Simple Attribute

The `preset` attribute gives the active value for the preset input.

Syntax

```
preset : "valueBoolean" ;
```

Example

The following example defines a low-active clear signal.

```
preset : "PD'" ;
```

Attribute Functions in a latch Group

The latch cell is activated whenever `clear`, `preset`, `enable`, or `data_in` changes.

[Table 2-10](#) shows the functions of the attributes in the `latch` group.

Table 2-10 Function Table for a latch Group

enable	clear	preset	variable1	variable2
active	inactive	inactive	data_in	!data_in
--	active	inactive	0	1
--	inactive	active	1	0
--	active	active	clear_preset_var1	clear_preset_var2

[Example 2-14](#) shows a latch group for a D latch with active-high enable and negative clear.

Example 2-14 D Latch With Active-High Enable and Negative Clear

```
latch(IQ, IQN) {
    enable : "G" ;
    data_in : "D" ;
    clear : "CD'" ;
}
```

[Example 2-15](#) shows a latch group for an SR latch. The `enable` and `data_in` attributes are not required for an SR latch.

Example 2-15 SR Latch

```
latch(IQ, IQN) {
    clear : "S'" ;
    preset : "R'" ;
    clear_preset_var1 : L ;
    clear_preset_var2 : L ;
}
```

latch_bank Group

A `latch_bank` group is defined within a `cell`, `model`, or `test_cell` group and in a `scaled_cell` group at the library level to represent multibit latch registers. The syntax for a cell is shown here. For information about test cells, see ["test_cell Group"](#).

The `latch_bank` group describes a cell that is a collection of parallel, single-bit sequential parts. Each part shares control signals with the other parts and performs an identical function.

An input pin that is described in a `pin` group, such as the `clk` input, is fanned out to each latch in the bank. Each primary output must be described in a `bus` or `bundle` group, and its function statement must include either `variable1` or `variable2`.

The syntax of the `latch_bank` group is similar to that of the `latch` group (see ["latch Group"](#)).

Syntax

```
library (name_string) {
    cell (name_string) {
        latch_bank(variable1_string, variable2_string,
                   bits_integer){
            ... multibit latch register description ...
        }
    }
}
```

The bits value in the `latch_bank` definition is the number of bits in the multibit cell.

Simple Attributes

```
enable : "Boolean expression";
enable_also : "Boolean expression";
data_in : "Boolean expression";
clear : "Boolean expression";
preset : "Boolean expression";
clear_preset_var1 : L | H | N | T | X;
clear_preset_var2 : L | H | N | T | X;
```

[Example 2-16](#) shows a `latch_bank` group for a multibit register containing four rising-edge-triggered D latches.

Example 2-16 Multibit D Latch

```
cell (latch4) {
    area: 16;
    pin (G) { /* gate enable signal, active-high */
        direction : input;
        ...
    }
    bundle (D) { /* data input with four member pins */
        members(D1, D2, D3, D4); /*must be 1st bundle attribute*/
        direction : input;
        ...
    }
    bundle (Q) {
        members(Q1, Q2, Q3, Q4);
        direction : output;
        function : "IQ";
        ...
    }
    bundle (QN) {
        members (Q1N, Q2N, Q3N, Q4N);
        direction : output;
        function : "IQN";
        ...
    }
    latch_bank(IQ, IQN, 4) {
        enable : "G";
        data_in : "D";
    }
    ...
}
```

clear Simple Attribute

The `clear` attribute gives the active value for the clear input.

Syntax

```
clear : "Boolean expression";
```

The following example defines a low-active clear signal.

```
clear : "CD'";
```

clear_preset_var1 and clear_preset_var2 Simple Attributes

The `clear_preset_var1` and `clear_preset_var2` attributes give the values that `variable1` and `variable2` have when `clear` and `preset` are both active at the same time.

Syntax

```
clear_preset_var1 : L | H | N | T | X;
clear_preset_var2 : L | H | N | T | X;
```

Example

See [Table 2-9](#) for the valid values for the `clear_preset_var1` and `clear_preset_var2` attributes.

See ["Single-Stage Flip-Flop"](#) for more information about the `clear_preset_var1` and `clear_preset_var2` attributes, including their function and values.

If you include both `clear` and `preset`, you must use either `clear_preset_var1`, `clear_preset_var2`, or both. Conversely, if you include `clear_preset_var1`, `clear_preset_var2`, or both, you must use both `clear` and `preset`.

```
latch_bank(IQ, IQN) {  
    clear : "S'" ;  
    preset : "R'" ;  
    clear_preset_var1 : L ;  
    clear_preset_var2 : L ;  
}
```

data_in Simple Attribute

The `data_in` attribute gives the state of the data input, and the `enable` attribute gives the state of the enable input. The `enable` and `data_in` attributes are optional, but if you use one of them, you must also use the other.

Syntax

```
data_in : "Boolean expression" ;
```

Boolean expression

State of data input.

Example

```
data_in : "D" ;
```

enable Simple Attribute

The `enable` attribute gives the state of the enable input, and the `data_in` attribute gives the state of the data input. The `enable` and `data_in` attributes are optional, but if you use one of them, you must include the other.

Syntax

```
enable : "Boolean expression" ;
```

Boolean expression

State of enable input.

Example

```
enable : "G" ;
```

preset Simple Attribute

The `preset` attribute gives the active value for the preset input.

Syntax

```
preset : "Boolean expression" ;
```

The following example defines a low-active clear signal.


```
preset : "PD'" ;
```

Attribute Functions in a latch_bank Group

The `latch_bank` cell is activated whenever the value of `clear`, `preset`, `enable`, or `data_in` attribute changes.

[Figure 2-2](#) and [Example 2-17](#) show a multibit register containing four high-enable D latches with the `clear` attribute.

Figure 2-2 Multibit Register With Latches



Example 2-17 Multibit Register With Four D Latches

```

cell (DLT2) {
    /* note: 0 hold time */
    area : 1 ;
    single_bit_degenerate : FDB ;
    pin (EN) {
        direction : input ;
        capacitance : 0 ;
        min_pulse_width_low : 3 ;
        min_pulse_width_high : 3 ;
    }
    bundle (D) {
        members(DA, DB, DC, DD) ;
        direction : input ;
        capacitance : 0 ;
        timing() {
            related_pin : "EN" ;
            timing_type : setup_falling ;
            intrinsic_rise : 1.0 ;
            intrinsic_fall : 1.0 ;
        }
        timing() {
            related_pin : "EN" ;
            timing_type : hold_falling ;
            intrinsic_rise : 0.0 ;
            intrinsic_fall : 0.0 ;
        }
    }
    bundle (CLR) {
        members(CLRA, CLRB, CLRC, CLRD) ;
        direction : input ;
        capacitance : 0 ;
        timing() {
            related_pin : "EN" ;
            timing_type : recovery_falling ;
            intrinsic_rise : 1.0 ;
            intrinsic_fall : 0.0 ;
        }
    }
    bundle (PRE) {
        members(PREA, PREB, PREC, PRED) ;
        direction : input ;
        capacitance : 0 ;
        timing() {
            related_pin : "EN" ;
        }
    }
}

```

```

    timing_type : recovery_falling ;
    intrinsic_rise : 1.0 ;
    intrinsic_fall : 0.0 ;
}
}
latch_bank(IQ, IQN, 4) {
    data_in : "D" ;
    enable : "EN" ;
    clear : "CLR'" ;
    preset : "PRE'" ;
    clear_preset_var1 : H ;
    clear_preset_var2 : H ;
}
bundle (Q) {
    members(QA, QB, QC, QD) ;
    direction : output ;
    function : "IQ" ;
    timing() {
        related_pin : "D" ;
        intrinsic_rise : 2.0 ;
        intrinsic_fall : 2.0 ;
    }
    timing() {
        related_pin : "EN" ;
        timing_type : rising_edge ;
        intrinsic_rise : 2.0 ;
        intrinsic_fall : 2.0 ;
    }
    timing() {
        related_pin : "CLR" ;
        timing_type : clear ;
        timing_sense : positive_unate ;
        intrinsic_fall : 1.0 ;
    }
    timing() {
        related_pin : "PRE" ;
        timing_type : preset ;
        timing_sense : negative_unate ;
        intrinsic_rise : 1.0 ;
    }
}
bundle (QN) {
    members(QNA, QNB, QNC, QND) ;
    direction : output ;
    function : "IQN" ;
    timing() {
        related_pin : "D" ;
        intrinsic_rise : 2.0 ;
        intrinsic_fall : 2.0 ;
    }
    timing() {
        related_pin : "EN" ;
        timing_type : rising_edge ;
        intrinsic_rise : 2.0 ;
        intrinsic_fall : 2.0 ;
    }
    timing() {
        related_pin : "CLR" ;
        timing_type : preset ;
        timing_sense : negative_unate ;
        intrinsic_rise : 1.0 ;
    }
    timing() {
        related_pin : "PRE" ;
        timing_type : clear ;
        timing_sense : positive_unate ;
        intrinsic_fall : 1.0 ;
    }
}
} /* end of cell DLT2

```

leakage_current Group

A leakage_current group is defined within a cell group or a model group to specify leakage current values that are dependent on the state of the cell.

Syntax

```
library (name) {  
    cell(<cell_name>) {  
        ...  
        leakage_current() {  
            when : <boolean expression>;  
            pg_current(<pg_pin_name>) {  
                value : <float>;  
            }  
            ...  
        }  
    }  
}
```

Simple Attribute

```
when  
value
```

Group

```
pg_current
```

when Simple Attribute

This attribute specifies the state-dependent condition that determines whether the leakage current is accessed.

A `leakage_current` group without a `when` attribute is defined as a default state. The default state is associated with a leakage model that does not depend on the state condition. If all state conditions of a cell are specified, a default state is not required. If some state conditions of a cell are missing, the default state will be assigned. If no default state is given, the leakage current defaults to 0.0.

Syntax

```
when : "Boolean expression";
```

Boolean expression

Specifies the state-dependent condition.

value Simple Attribute

When a cell has only a single power and ground pin, you can omit the `pg_current` group and specify the leakage current value at this level. Otherwise, specify the value in the `pc_current` group as shown below. Current conservation is applied for each `leakage_current` group. The `value` attribute specifies the absolute value of leakage current on a single power and ground pin.

Syntax

```
value : value<float>;
```

value

A floating-point number representing the leakage current.

pg_current Group

Use this group to specify a power or ground pin where leakage current is to be measured.

Syntax

```
cell(<cell_name>) { ... leakage_current() { when : <boolean expression>; pg_current  
(<pg_pin_name>) { value : <float>; } }
```

pg_pin_name

Specifies the power or ground pin where the leakage current is to be measured.

Simple Attribute

```
value
```

Use this attribute in the `pg_current` group to specify the leakage current value when a cell has multiple power and ground pins. The leakage current is measured toward a cell. For power pins, the current is positive if it is dragged into a cell. For ground pins, the current is negative, indicating that current flows out of a cell. If all power and ground pins are specified within a `leakage_current` group, the sum of the leakage currents should be zero.

Syntax

```
value : valuefloat ;
```

```
value
```

A floating-point number representing the leakage current.

gate_leakage Group

The `gate_leakage` group specifies the cell's gate leakage current on input or inout pins within the `leakage_current` group in a cell. The following applies to `gate_leakage` groups:

- Groups can be placed in any order if there is more than one `gate_leakage` group within a `leakage_current` group. The leakage current of a cell is characterized with opened outputs, which means that modeling cell outputs do not drive any other cells. Outputs are assumed to have zero static current during the measurement. A missing `gate_leakage` group is allowed for certain pins. Current conservation is applicable if it can be applied to higher error tolerance.

Syntax

```
gate_leakage (<an input pin name>)
```

Example

```
cell (my_cell) {  
    ...  
    leakage_current {  
        ...  
        ...  
        gate_leakage (A) {  
            input_low_value : -0.5 ;  
            input_high_value : 0.6 ;  
        }  
    }  
}
```

Simple Attributes

```
input_low_value  
input_high_value
```

input_low_value Simple Attribute

The `input_low_value` attribute specifies gate leakage current on an input or inout pin when the pin is in a low state condition. The following applies to the `input_low_value` attribute:

- A negative floating-point number value is required.
- The gate leakage current flow is measured from the power pin of a cell to the ground pin of its driver cell.
- The input pin is pulled up to low.
- The `input_low_value` attribute is not required for a `gate_leakage` group.

Syntax

```
input_low_value : <float> ;
```

Example

```
}  
...  
gate_leakage (A) {  
    input_low_value : -0.5 ;  
    input_high_value : 0.6 ;  
}
```

input_high_value Simple Attribute

The `input_high_value` attribute specifies gate leakage current on an input or inout pin when the pin is in a high state condition.

- A positive floating-point number value is required.
- The gate leakage current flow is measured from the power pin of its driver cell to the ground pin of the cell itself.
- The input pin is pulled up to high.
- The `input_high_value` attribute is not required for a `gate_leakage` group.

Syntax

```
input_high_value : <float> ;
```

Example

```
}
```

...

```
gate_leakage (A) {  
    input_low_value : -0.5 ;  
    input_high_value : 0.6 ;  
}
```

leakage_power Group

A `leakage_power` group is defined within a `cell` group or a `model` group to specify leakage power values that are dependent on the state of the cell.

Note:

Cells with state-dependent leakage power also need the `cell_leakage_power` simple attribute.

Syntax

```
library (name) {  
    cell (name) {  
        leakage_power () {  
            ...  
        }  
    }  
}
```

Simple Attributes

```
power_level  
related_pg_pin  
when  
value
```

power_level Simple Attribute

Use this attribute to specify the power consumed by the cell.

Syntax

```
power_level : "name" ;
```

name

Name of the power rail defined in the power supply group.

Example

```
power_level : "VDD1" ;
```

related_pg_pin Simple Attribute

Use this optional attribute to associate a power and ground pin with leakage power and internal power tables. The leakage power and internal energy tables can be omitted when the voltage of a `primary_power` or `backup_ground_pg_pin` is at reference voltage zero, since the value of the corresponding leakage power and internal energy tables will always be zero.

In the absence of a `related_pg_pin` attribute, the `internal_power/leakage_power` specifications apply to the whole

cell (cell-specific power specification). Cell-specific and pg_pin-specific power specifications cannot be mixed; that is, when one leakage_power (internal_power) group has the related_pg_pin attribute, all the leakage_power (internal_power) groups must have the related_pg_pin attribute.

Syntax

related_pg_pin : pg_pin_id;

pg_pin

The related power and ground pin name.

Example

```
related_pg_pin : G2 ;
```

when Simple Attribute

This attribute specifies the state-dependent condition that determines whether the leakage power is accessed.

Syntax

```
when : "Boolean expression" ;
```

Boolean expression

Name of pin or pins in a cell for which leakage_power is different.

[Table 2-11](#) lists the Boolean operators valid in a when statement.

Table 2-11 Valid Boolean Operators

Operator	Description
'	invert previous expression
!	invert following expression
^	logical XOR
*	logical AND
&	logical AND
space	logical AND
+	logical OR
	logical OR
1	signal tied to logic 1
0	signal tied to logic 0

value Simple Attribute

Use this attribute to specify the leakage power for a given state of a cell.

Syntax

```
value : value_float ;
```

value

A floating-point number representing the leakage power value.

The following example defines the leakage_power group and the cell_leakage_power simple attribute in a cell:

Example

```
cell () {
```

```

...
leakage_power () {
    when : "A" ;
    value : 2.0 ;
}
cell_leakage_power : 3.0 ;
}

```

Iut Group

A lut group defines a single variable that is then used to represent the lookup table value in the `function` attribute of a pin group. The lut group applies only to FPGA libraries.

Syntax

```

library (namestring) {
    cell (namestring) {
        lut (name) {
            ...
        }
    }
}

```

Example

```

cell () {
...
lut(L) {
    input_pins : "A B C D" ;
}
pin (Z){
...
    function: "L" ;
}
}

```

input_pins Simple Attribute

```
input_pins : "name1 [name2 name3 ...]" ;
```

mode_definition Group

A mode_definition group declares a mode group that contains several timing mode values. Each timing arc can be enabled based on the current mode of the design, which results in different timing for different modes. You can optionally put a condition on a mode value. When the condition is true, the mode group takes that value.

Syntax

```

cell (namestring) {
    mode_definition (namestring) (
        ...
    )
}

```

Group Statement

```
mode_value (namestring) {}
```

mode_value Group

Use this group to specify a timing mode.

Simple Attributes

```
when
sdf_cond
```

when Simple Attribute

The `when` attribute specifies the condition that a timing arc depends on to activate a path. The valid value is a Boolean expression.

Syntax

```
when : Boolean expression ;
```

Example

```
when: !R;
```

sdf_cond Simple Attribute

The `sdf_cond` attribute supports Standard Delay Format (SDF) file generation and condition matching during back-annotation.

Syntax

```
sdf_cond : sdf_expressionstring ;
```

Example

```
sdf_cond: "R == 0";
```

[Example 2-18](#) shows a `mode_definition` description.

Example 2-18 mode_definition Description

```
cell(sample_cell) {
...
    mode_definition(rw) {
        mode_value(read) {
            when : "R";
            sdf_cond : "R == 1";
        }
        mode_value(write) {
            when : "!R";
            sdf_cond : "R == 0";
        }
    }
}
```

pg_pin Group

Use the `pg_pin` group to specify power and ground pins. The library cells can have multiple `pg_pin` groups. A `pg_pin` group is mandatory for each cell. A cell must have at least one `primary_power` pin specified in the `pg_type` attribute and at least one `primary_ground` pin specified in the `pg_type` attribute.

Syntax

```
cell (namestring){
    pg_pin (pg_pin_namestring){
        voltage_name : valueid;
        pg_type : valueenum;      } /* end pg_pin
    */
    ...
}/* end cell */
```

Simple Attributes

```
voltage_name
pg_type
user_pg_type
physical_connection
related_bias_pin
```

voltage_name Simple Attribute

Use the `voltage_name` attribute to specify an associated voltage.

Syntax

```
voltage_name : value_id;  
  
value  
  
A voltage defined in a library-level voltage_map attribute.
```

Example

```
voltage_name : VDD1 ;
```

pg_type Simple Attribute

Use the optional pg_type attribute to specify the type of power and ground pin. The pg_type attribute also supports back-bias modeling. The pg_type attribute can have the following values: primary_power, primary_ground, backup_power, backup_ground, internal_power, internal_ground, pwell, nwell, deepnwell, and deeppwell. The pwell and nwell values specify regular wells, and the deeppwell and deepnwell values specify isolation wells.

Syntax

```
pg_type : value_enum;
```

value

The valid values are primary_power, primary_ground, backup_power, backup_ground, internal_power, internal_ground, pwell, nwell, deepnwell, and deeppwell.

Example

```
pg_type : primary_power ;
```

Example of a two-input NAND Cell With Virtual Bias Pins

The following example shows a two-input NAND cell with virtual bias pins to support back-bias modeling.

```
library (sample_standard_cell_with_bias_pin) {  
...  
cell ( nand2 ) {  
    pg_pin ( vdd ) {  
        pg_type : primary_power ;  
        ...  
    }  
    pg_pin ( vss ) {  
        pg_type : primary_ground ;  
        ...  
    }  
    pg_pin ( vpw ) {  
        pg_type : pwell ;  
        ...  
    }  
    pg_pin ( vnw ) {  
        pg_type : nwell ;  
        ...  
    }  
    pin ( A ) {  
        direction : input;  
        related_power_pin : "vdd" ;  
        related_ground_pin : "vss" ;  
        related_bias_pin : "vpw vnw" ;  
        ...  
    }  
    pin ( B ) {  
        direction : input;  
        related_power_pin : "vdd" ;  
        related_ground_pin : "vss" ;  
        related_bias_pin : "vpw vnw" ;  
        ...  
    }  
    pin ( Z ) {  
        direction : output;  
        function : " !(A * B) " ;
```

```

related_power_pin : "vdd" ;
related_ground_pin : "vss" ;
related_bias_pin : "vpw vnw" ;
power_down_function : "vdd' + vss + vnw' + vpw" ;
...
}
} /* end of cell group */
} /* end of library group */

```

Example of a Level-Shifter Cell With Virtual Bias Pins

The following example shows a level-shifter cell with virtual bias pins and two nwell regular wells for back-bias modeling.

```

library (sample_multi_rail_with_bias_pins) {
...
cell ( level_shifter ) {
    pg_pin ( vdd1 ) {
        pg_type : primary_power ;
        ...
    }
    pg_pin ( vdd2 ) {
        pg_type : primary_power ;
        ...
    }
    pg_pin ( vss ) {
        pg_type : primary_ground ;
        ...
    }
    pg_pin ( vpw ) {
        pg_type : pwell ;
        ...
    }
    pg_pin ( vnwl ) {
        pg_type : nwell ;
        ...
    }
    pg_pin ( vnw2 ) {
        pg_type : nwell ;
        ...
    }
    pin ( I ) {
        direction : input;
        related_power_pin : vdd1
        related_ground_pin : vss
        related_bias_pin : "vnwl vpw"
        ...
    }
    pin ( Z ) {
        direction : output;
        function : "I";
        related_power_pin : "vdd2" ;
        related_ground_pin : "vss" ;
        related_bias_pin : "vnw2 vpw" ;
        power_down_function : "!vdd1 + !vdd2 + vss + !vnwl + !vnw2 + vpw" ;
        ...
    }
} /* End of cell group */
} /* End of library group */

```

user_pg_type Simple Attribute

The `user_pg_type` optional attribute allows you to customize the type of power and ground pin that is used in a library. It accepts any string value, as shown:

```

pg_pin (pg_pin_name) {
    voltage_name : voltage_name;
    pg_type : < primary_power | primary_ground |
               backup_power | backup_ground |
               internal_power | internal_ground >
    user_pg_type : user_pg_type_name;
}

```

Example

The following example shows a `pg_pin` library with the `user_pg_type` attribute specified.

```
pg_pin (A) {  
    voltage_name : VDD1;  
    pg_type : primary_power;  
    user_pg_type : my_pg_type;  
}
```

[physical_connection Simple Attribute](#)

The `physical_connection` attribute provides two possible values: `device_layer` and `routing_pin`. The `device_layer` value specifies that the bias connection is physically external to the cell. In this case, the library provides biasing tap cells that connect through the device layers. The `routing_pin` value specifies that the bias connection is inside a cell and is exported as a physical geometry and a routing pin. Macros with pin access generally use the `routing_pin` value if the cell has bias pins with geometry that is visible in the physical view.

[Example](#)

The following example shows virtual routing pin modeling, where the bias connection is physically external to the cell.

```
pg_pin(VDDS){  
    voltage_name : VDDS;  
    direction : input;  
    pg_type : <pwell | nwell | deepnwell | deeppwell>;  
    physical_connection : device_layer;  
}
```

[related_bias_pin](#)

The `related_bias_pin` attribute defines all bias pins associated with a power or ground pin within a cell.

The `related_bias_pin` attribute is required only when the attribute is declared in a pin group but it does not specify a complete relationship between the bias pin and power and ground pin for a library cell.

The `related_bias_pin` attribute also defines all bias pins associated with a signal pin. To associate back-bias pins to signal pins, use the `related_bias_pin` attribute to specify one of the following `pg_type` values: `pwell`, `nwell`, `deeppwell`, `deepnwell`.

[Example with a Power and Ground Pin](#)

The following example shows the association of a back-bias pin to a power and ground pin.

```
pg_pin(signal_pin){  
    related_power_pin : <pg_pin_name>;  
    related_ground_pin : <pg_pin_name>;  
    related_bias_pin : "<bias_pin_name> <bias_pin_name> ...";  
}
```

[Example with a Signal Pin](#)

The following example shows the association of a back-bias pin to a signal pin.

```
pg_pin(pg_pin_name){  
    related_bias_pin : "<bias_pin_name> <bias_pin_name> ...";  
}
```

[routing_track Group](#)

A `routing_track` group is defined at the `cell` group or `model` group level:

[Syntax](#)

```
library (name_string){  
    cell (name_string){  
        routing_track (routing_layer_name_string){  
            ... routing track description ...  
        }  
    }  
}
```

[Simple Attributes](#)

```
tracks : integer;  
total_track_area : float;
```

[Complex Attribute](#)

```
short /* for model group only */
```

tracks Simple Attribute

The `tracks` attribute indicates the number of tracks available for routing on any particular layer.

Syntax

```
tracks : valueint ;
```

`value`

A number larger than or equal to 0.

Example

```
tracks : 2 ;
```

total_track_area Simple Attribute

The `total_track_area` attribute specifies the total routing area of the routing tracks.

Syntax

```
total_track_area : valuefloat ;
```

`value`

A floating-point number larger than or equal to 0.0 and less than or equal to the area on the cell.

Example

```
total_track_area : 0.2 ;
```

statetable Group

The `statetable` group captures the function of more-complex sequential cells. It is defined in a `cell` group, `model` group, `scaled_cell` group, or `test_cell` group.

The purpose of this group is to define a state table. A state table is a sequential lookup table. It takes an arbitrary number of inputs and their delayed values and an arbitrary number of internal nodes and their delayed values to form an index to new internal node values.

Note:

In the `statetable` group, `table` is a keyword.

Syntax

```
statetable( "input node names", "internal node names" ) {
    table : " input node values : current internal values : \
              next internal values,\\
              input node values : current internal values : \
              next internal values";
}
```

The following example shows a state table for a JK flip-flop with an active-low, direct-clear, and negative-edge clock:

Example

```
statetable ( "J   K   CN   CD",    "IQ" ) {
    table:    "-   -   -   L   : - :  L,\ \
               -   -   ~F   H   : - :  N,\ \
               L   L   F   H   :L/H:  L/H,\ \
               H   L   F   H   : - :  H,\ \
               L   H   F   H   : - :  L,\ \
               H   H   F   H   :L/H:  H/L" ;
}
```

[test_cell Group](#)

The `test_cell` group is in a `cell` group or `model` group. It models only the nontest behavior of a scan cell, which is described by an `ff`, `ff_bank`, `latch`, `latch_bank` or `statetable` statement and `pin` function attributes.

[Syntax](#)

```
library (name_string) {
    cell (name_string) {
        test_cell () {
            ... test cell description ...
        }
    }
}
```

You do not need to give the test cell a name, because the test cell takes the name of the cell being defined.

[Groups](#)

```
ff (variable1_id,      variable2_id) { }
ff_bank (variable1_id,   variable2_string,     bits_int) { }
latch (variable1_id,      variable2_id) { }
latch_bank (variable1_id,   variable2_id,      bits_int){}
pin (name_id) { }
statetable ("input      node      names", "internal      node      names") { }
```

[ff Group](#)

For a discussion of the `ff` group syntax, see “[ff Group](#)”.

[ff_bank Group](#)

For a discussion of the `ff_bank` group syntax, see “[ff_bank Group](#)”.

[latch Group](#)

For a discussion of the `latch` group syntax, see “[latch Group](#)”.

[latch_bank Group](#)

For a discussion of the `latch_bank` group syntax, see “[latch_bank Group](#)”.

[pin Group in a test_cell Group](#)

Both test `pin` and nontest `pin` groups appear in `pin` groups within a `test_cell` group, as shown:

```
library (name_string) {
    cell (name_string) {
        test_cell (name_string) {
            pin (name_string | name_list_string) {
                ... pin description ...
            }
        }
    }
}
```

These groups are similar to `pin` groups in a `cell` group or `model` group but can contain only `direction`, `function`, `signal_type`, and `test_output_only` attributes. They cannot contain timing, capacitance, fanout, or load information.

[Simple Attributes](#)

```
direction : input | output | inout ;
function : Boolean expression ;
signal_type: test_scan_in | test_scan_in_inverted |
            test_scan_out | test_scan_out_inverted |
            test_scan_enable | test_scan_enable_inverted |
            test_scan_clock | test_scan_clock_a |
```

```
test_scan_clock_b | test_clock ;  
test_output_only : true | false ;
```

Group

```
statetable() { }
```

direction Attribute

The direction attribute states whether the pin being described is an input, output, or inout (bidirectional) pin. The default is input.

Syntax

```
direction : input | output | inout ;
```

Example

```
direction : input ;
```

function Attribute

The function attribute reflects only the nontest behavior of a cell.

An output pin must have either a function attribute or a signal_type attribute.

The function attribute in a pin group defines the value of an output pin or inout pin in terms of the input pins or inout pins in the cell group or model group. For more details about function, see the ["function Simple Attribute"](#).

Syntax

```
function : "Boolean expression" ;
```

Boolean expression

Identifies the replaced cell.

Example

```
function : "IQ" ;
```

signal_type Attribute

In a test_cell group, signal_type identifies the type of test pin.

Syntax

```
signal_type : "value";
```

Descriptions of the possible values for the signal_type attribute follow:

test_scan_in

Identifies the scan-in pin of a scan cell. The scanned value is the same as the value present on the scan-in pin. All scan cells must have a pin with either the test_scan_in or the test_scan_in_inverted attribute.

test_scan_in_inverted

Identifies the scan-in pin of a scan cell as being of inverted polarity. The scanned value is the inverse of the value present on the scan-in pin.

For multiplexed flip-flop scan cells, the polarity of the scan-in pin is inferred from the latch or ff declaration of the cell itself. For other types of scan cells, clocked-scan, level-sensitive scan design (LSSD), and multiplexed flip-flop latches, it is not possible to give the ff or latch declaration of the entire scan cell. For these cases, you can use the test_scan_in_inverted attribute in the cell where the scan-in pin appears in the latch or ff declarations for the entire cell.

test_scan_out

Identifies the scan-out pin of a scan cell. The value present on the scan-out pin is the same as the scanned value. All scan cells must have a pin with either a test_scan_out or a test_scan_out_inverted attribute.

The scan-out pin corresponds to the output of the slave latch in the LSSD methodologies.

`test_scan_out_inverted`

Identifies the scan-out of a test cell as having inverted polarity. The value on this pin is the inverse of the scanned value.

`test_scan_enable`

Identifies the pin of a scan cell that, when high, indicates that the cell is configured in scan-shift mode. In this mode, the clock transfers data from the scan-in input to the scan-out input.

`test_scan_enable_inverted`

Identifies the pin of a scan cell that, when low, indicates that the cell is configured in scan-shift mode. In this mode, the clock transfers data from the scan-in input to the scan-out input.

`test_scan_clock`

Identifies the test scan clock for the clocked-scan methodology. The signal is assumed to be edge-sensitive. The active edge transfers data from the scan-in pin to the scan-out pin of a cell. The sense of this clock is determined by the sense of the associated timing arcs.

`test_scan_clock_a`

Identifies the a clock pin in a cell that supports the single-latch LSSD, double-latch LSSD, clocked LSSD, or auxiliary clock LSSD methodologies. When the a clock is at the active level, the master latch of the scan cell can accept scan-in data. The sense of this clock is determined by the sense of the associated timing arcs.

`test_scan_clock_b`

Identifies the b clock pin in a cell that supports the single-latch LSSD, clocked LSSD, or auxiliary clock LSSD methodologies. When the b clock is at the active level, the slave latch of the scan-cell can accept the value of the master latch. The sense of this clock is determined by the sense of the associated timing arcs.

`test_clock`

Identifies an edge-sensitive clock pin that controls the capturing of data to fill scan-in test mode in the auxiliary clock LSSD methodology.

If an input pin is used in both test and nontest modes (such as the clock input in the multiplexed flip-flop methodology), do not include a `signal_type` statement for that pin in the `test_cell` pin definition.

If an input pin is used only in nontest mode and does not exist on the cell that it will scan and replace, you must include a `signal_type` statement for that pin in the `test_cell` pin definition.

If an output pin is used in nontest mode, it needs a `function` statement. The `signal_type` statement is used to identify an output pin as a scan-out pin. In a `test_cell` group, the `pin` group for an output pin can contain a `function` statement, a `signal_type` attribute, or both.

You do not have to define a `function` or `signal_type` attribute in the `pin` group if the pin is defined in a previous `test_cell` group for the same cell.

Example

```
signal_type : "test_scan_in" ;
```

`test_output_only` Attribute

This attribute is an optional Boolean attribute that you can set for any output port described in statetable format.

In ff/latch format, if a port is to be used for both function and test, you provide the functional description using the `function` attribute. If a port is to be used for test only, you omit the `function` attribute.

In statetable format, however, a port always has a functional description. Therefore, if you want to specify that a port is for test only, you set the `test_output_only` attribute to true.

Syntax

```
test_output_only : true | false ;
```

Example

```
test_output_only : true ;
```

[statetable Group](#)

For a discussion of the `statetable` group syntax, see “[statetable Group](#)”.

[type Group](#)

The `type` group, when defined within a cell, is a type definition local to the cell. It cannot be used outside of the cell.

[Syntax](#)

```
cell (namestring) {  
    type (namestring) {  
        ... type description ...  
    }  
}
```

[Simple Attributes](#)

```
base_type : array ;  
bit_from : integer ;  
bit_to : integer ;  
bit_width : integer ;  
data_type : bit ;  
downto : Boolean ;
```

[base_type Simple Attribute](#)

The only valid base type value is `array`.

[Example](#)

```
base_type : array ;
```

[bit_from Simple Attribute](#)

The `bit_from` attribute specifies the member number assigned to the most significant bit (MSB) of successive array members.

[Syntax](#)

```
bit_from : valueint ;
```

`value`

Indicates the member number assigned to the MSB of successive array members. The default is 0.

[Example](#)

```
bit_from : 0 ;
```

[bit_to Simple Attribute](#)

The `bit_to` attribute specifies the member number assigned to the least significant bit (LSB) of successive array members.

[Syntax](#)

```
bit_to : valueint ;
```

`value`

Indicates the member number assigned to the LSB of successive array members. The default is 0.

[Example](#)

```
bit_to : 3 ;
```

[bit_width Simple Attribute](#)

The `bit_width` attribute specifies the integer that designates the number of bus members.

Syntax

```
bit_width : valueint ;  
  
value
```

Designates the number of bus members. The default is 1.

Example

```
bit_width : 4 ;
```

`data_type Simple Attribute`

Only the bit data type is supported.

Example

```
data_type : bit ;
```

`downto Simple Attribute`

The `downto` attribute specifies a Boolean expression that indicates whether the MSB is high or low.

Syntax

```
downto : true | false ;  
  
true
```

Indicates that member number assignment is from high to low. The default is `false` (low to high).

[Example 2-19](#) illustrates a `type` group statement in a cell.

Example 2-19 type Group Within a Cell

```
cell (buscell4) {  
    type (BUS4) {  
        base_type : array ;  
        data_type : bit ;  
        bit_width : 4 ;  
        bit_from : 0 ;  
        bit_to : 3 ;  
        downto : true ;  
    }  
}
```

2.2 model Group

A `model` group is defined within a `library` group, as shown here:

Syntax

```
library (namestring) {  
    model (namestring) {  
        ... model description ...  
    }  
}
```

2.2.1 Attributes and Values

A `model` group can include all the attributes that are valid in a `cell` group, as well as the two additional attributes described in this section. For information about the `cell` group attributes, see ["Attributes and Values"](#).

Simple Attribute

```
cell_name
```

Complex Attribute

```
short
```

cell_name Simple Attribute

The `cell_name` attribute specifies the name of the cell within a `model` group.

Syntax

```
cell_name : "name_string";
```

Example

```
model(modelA) {  
    cell_name : "cellA";  
    ...  
}
```

short Complex Attribute

The `short` attribute lists the shorted ports that are connected together by a metal or poly trace. These ports are modeled within a `model` group.

The most common example of a shorted port is a feedthrough, where an input port is directly connected to an output port. Another example is two output ports that fan out from the same gate.

Syntax

```
short ("name_liststring");
```

Example

```
short(b, y);
```

[Example 2-20](#) shows how to use a `short` attribute in a `model` group.

Example 2-20 Using the short Attribute in a model Group

```
model(cellA) {  
    area : 0.4;  
    ...  
    short(b, y);  
    short(c, y);  
    short(b, c);  
    ...  
    pin(y) {  
        direction : output;  
        timing() {  
            related_pin : a;  
            ...  
        }  
    }  
    pin(a) {  
        direction : input;  
        capacitance : 0.1;  
    }  
    pin(b) {  
        direction : input;  
        capacitance : 0.1;  
    }  
    pin(c) {  
        direction : input;  
        capacitance : 0.1;  
        clock : true;  
    }  
}
```

3. pin Group Description and Syntax

You can define a `pin` group within a `cell`, `test_cell`, `scaled_cell`, or `bus` group.

This chapter contains

- An example of the `pin` group syntax showing the attribute and group statements that you can use within the `pin` group
- Descriptions of the attributes and groups you can use in a `pin` group

3.1 Syntax of a pin Group in a cell or bus Group

A `pin` group can include simple and complex attributes and group statements. In a `cell` or `bus` group, the syntax of a `pin` group is as follows:

```
library (name) {
    cell (name) {
        pin (name | name_list) {
            ... pin description ...
        }
    }
    cell (name) {
        bus (name) {
            pin (name | name_list) {
                ... pin description ...
            }
        }
    }
}
```

3.1.1 pin Group Example

[Example 3-1](#) shows `pin` groups with CMOS library attributes and a `timing` group.

Example 3-1 CMOS pin Group Example

```
library(example){
    date : "November 12, 2002" ;
    revision : 2.3 ;
    ...
    cell(AN2) {
        area : 2 ;
        pin(A) {
            direction : input ;
            dont_fault : true ;
            capacitance : 1.3 ;
            fanout_load : 2 ; /* internal fanout load */
            max_transition : 4.2 ;/* design-rule constraint */
        }
        pin(B) {
            direction : input ;
            capacitance : 1.3 ;
        }
        pin(Z) {
            direction : output ;
            function : "A * B" ;
            max_transition : 5.0 ;
            timing() {
                intrinsic_rise : 0.58 ;
                intrinsic_fall : 0.69 ;
                rise_resistance : 0.1378 ;
                fall_resistance : 0.0465 ;
                related_pin : "A B" ;
            }
        }
    }
}
```

3.1.2 Simple Attributes

[Example 3-2](#) lists alphabetically a sampling of the attributes and groups that you can define within a `pin` group.

Example 3-2 Attributes and Values in a pin Group

```

/* Simple Attributes in a pin Group */

bit_width : integer ; /* bus cells */
capacitance : float ;
clock : true | false ;
clock_gate_clock_pin : true | false ;
clock_gate_enable_pin : true | false ;
clock_gate_test_pin : true | false ;
clock_gate_obs_pin : true | false ;
clock_gate_out_pin : true | false ;
complementary_pin : "string" ;
connection_class : "name1 [name2 name3 ... ]" ;
direction : input | output | inout | internal ;
dont_fault : sa0 | sa1 | saol ;
drive_current : float ;
driver_type : pull_up | pull_down | open_drain | open_source | bus_hold | resistive

| resistive_0 | resistive_1 ;
fall_capacitance : float ;
fall_current_slope_after_threshold : float ;
fall_current_slope_before_threshold : float ;
fall_time_after_threshold : float ;
fall_time_before_threshold : float ;
fanout_load : float ;
fault_model : "two-value string" ;
function : "Boolean expression" ;
has_builtin_pad : Boolean expression ;
hysteresis : true | false ;
input_map : "name_string | name_list" ;
input_signal_level : string ;
input_voltage : string ;
internal_node : name_string ; /* Required in statetable cells */
inverted_output : true | false ;/* Required in statetable cells */
is_pad : true | false ;
max_capacitance : float ;
max_fanout : float ;
max_input_noise_width : float ;
max_transition : float ;
min_capacitance : float ;
min_fanout : float ;
min_input_noise_width : float ;
min_period : float ;
min_pulse_width_high : float ;
min_pulse_width_low : float ;
min_transition : float ;
multicell_pad_pin : true | false ;
nextstate_type : data | preset | clear | load | scan_in | scan_enable ;
output_signal_level : string ;
output_voltage : string ;
pin_func_type : clock_enable| active_high | active_low |
active_rising | active_falling ;
prefer_tied : "0" | "1" ;
primary_output : true | false ;
pulling_current : current value ;
pulling_resistance : resistance value ;
rise_capacitance : float ;
rise_current_slope_after_threshold : float ;
rise_current_slope_before_threshold : float ;
rise_time_after_threshold : float ;
rise_time_before_threshold : float ;
signal_type : test_scan_in | test_scan_in_inverted | test_scan_out |
test_scan_out_inverted | test_scan_enable |
test_scan_enable_inverted | test_scan_clock |
test_scan_clock_a | test_scan_clock_b | test_clock ;
slew_control : low | medium | high | none ;
state_function : "Boolean expression" ;
test_output_only : true | false ;
three_state : "Boolean expression" ;
vhdl_name : "string" ;
x_function : "Boolean expression" ;

/* Complex Attributes in a pin Group */

```

```

fall_capacitance_range ( float, float ) ;
rise_capacitance_range ( float, float ) ;

/* Group Statements in a pin Group */

electromigration () { }
hyperbolic_noise_above_high () { }
hyperbolic_noise_below_low () { }
hyperbolic_noise_high () { }
hyperbolic_noise_low () { }
internal_power () { }
max_trans () { }
min_pulse_width () { }
minimum_period () { }
timing () { }
tlatch () { }

```

always_on Simple Attribute

The `always_on` simple attribute models always-on cells or signal pins. Specify the attribute at the cell level to determine whether a cell is an always-on cell. Specify the attribute at the pin level to determine whether a pin is an always-on signal pin.

Syntax

`always_on : Boolean expression ;`

Boolean expression

Valid values are true and false.

Example

```
always_on : true ;
```

bit_width Simple Attribute

An integer that designates the number of bus members. The default is 1.

Syntax

`bit_width : integer ;`

Example

```
bit_width : 4 ;
```

capacitance Simple Attribute

The `capacitance` attribute defines the load of an input, output, inout, or internal pin.

Syntax

`capacitance : valuefloat ;`

value

A floating-point number in units consistent with other capacitance specifications throughout the library. Typical units of measure for capacitance include picofarads and standardized loads.

Example

The following example defines the A and B pins in an AND cell, each with a capacitance of one unit.

```

cell (AND) {
    area : 3 ;
    vhdl_name : "AND2" ;
    pin (A,B) {
        direction : input ;
        capacitance : 1 ;
    }
}

```

```
}
```

clock Simple Attribute

The `clock` attribute indicates whether an input pin is a clock pin.

Syntax

```
clock : true | false ;
```

A true value labels a pin as a clock pin. A false value labels a pin as not a clock pin, even though it may otherwise have such characteristics.

Example

The following example defines pin CLK2 as a clock pin.

```
pin(CLK2) {  
    direction : input ;  
    capacitance : 1.0 ;  
    clock : true ;  
}
```

clock_gate_clock_pin Simple Attribute

The `clock_gate_clock_pin` attribute identifies an input pin connected to a clock signal.

Syntax

```
clock_gate_clock_pin : true | false ;
```

A true value labels the pin as a clock pin. A false value labels the pin as not a clock pin.

Example

```
clock_gate_clock_pin : true ;
```

clock_gate_enable_pin Simple Attribute

The `clock_gate_enable_pin` attribute identifies an input port connected to an enable signal for nonintegrated clock-gating cells and integrated clock-gating cells.

Syntax

```
clock_gate_enable_pin : true | false ;
```

A true value labels the input port pin connected to an enable signal for nonintegrated and integrated clock-gating cells. A false value labels the input port pin connected to an enable signal as *not* for nonintegrated and integrated clock-gating cells.

Example

```
clock_gate_enable_pin : true ;
```

For nonintegrated clock-gating cells, you can set the `clock_gate_enable_pin` attribute to true on only one input port of a 2-input AND, NAND, OR, or NOR gate. If you do so, the other input port is the clock.

clock_gate_test_pin Simple Attribute

The `clock_gate_test_pin` attribute identifies an input pin connected to a test_mode or scan_enable signal.

Syntax

```
clock_gate_test_pin : true | false ;
```

A true value labels the pin as a test (test_mode or scan_enable) pin. A false value labels the pin as not a test pin.

Example

```
clock_gate_test_pin : true ;
```

clock_gate_obs_pin Simple Attribute

The `clock_gate_obs_pin` attribute identifies an output pin connected to an observability signal.

Syntax

```
clock_gate_obs_pin : true | false ;
```

A true value labels the pin as an observability pin. A false value labels the pin as not an observability pin.

Example

```
clock_gate_obs_pin : true ;
```

clock_gate_out_pin Simple Attribute

The `clock_gate_out_pin` attribute identifies an output port connected to an enable_clock signal.

Syntax

```
clock_gate_out_pin : true | false ;
```

A true value labels the pin as an out (enable_clock) pin. A false value labels the pin as not an out pin.

Example

```
clock_gate_out_pin : true ;
```

complementary_pin Simple Attribute

The `complementary_pin` attribute supports differential I/O. Differential I/O assumes the following:

- When the noninverting pin equals 1 and the inverting pin equals 0, the signal gets logic 1.
- When the noninverting pin equals 0 and the inverting pin equals 1, the signal gets logic 0.

Use the `complementary_pin` attribute to identify the differential input inverting pin with which the noninverting pin is associated and from which it inherits timing information and associated attributes.

For information on the `connection_class` attribute, see [“connection_class Simple Attribute”](#).

Syntax

```
complementary_pin : "value_string" ;
```

value

Identifies the differential input data inverting pin whose timing information and associated attributes the noninverting pin inherits. Only one input pin is modeled at the cell level. The associated differential inverting pin is defined in the same `pin` group as the noninverting pin.

For details on the `fault_model` attribute that you use to define the value when both the complementary pins are driven to the same value, see [“fault_model Simple Attribute”](#).

Example

```
cell (diff_buffer) {
    ...
    pin (A) { /* noninverting pin /
        direction : input ;
        complementary_pin : ("DiffA") /* inverting pin /
    }
}
```

connection_class Simple Attribute

The `connection_class` attribute defines design rules for connections between cells. Only pins with the same connection class can be legally connected.

Syntax

```
connection_class : "name1 [name2 name3 ... ]" ;
```

name

A name or names of your choice for the connection class. You can assign multiple connection classes to a pin by separating the connection class names with spaces.

Example

```
connection_class : "internal" ;
```

direction Simple Attribute

The `direction` attribute declares a pin as being an input, output, inout (bidirectional), or internal pin. The default is input.

Syntax

```
direction : input | output | inout | internal ;
```

Example

In the following example, both A and B in the AND cell are input pins; Y is an output pin.

```
cell (AND) {
    area : 3 ;
    vhdl_name : "AND2" ;
    pin (A,B) {
        direction : input ;
    }
    pin (Y) {
        direction : output ;
    }
}
```

dont_fault Simple Attribute

The `dont_fault` attribute is a string (“stuck at”) that you can set on a library cell or pin.

Syntax

```
dont_fault : sa0 | sa1 | sa01 ;
```

Example

```
dont_fault : sa0;
```

The `dont_fault` attribute can also be defined in the `cell` group.

drive_current Simple Attribute

The `drive_current` attribute defines the drive current strength for the pad pin.

Syntax

```
drive_current : valuefloat ;
```

value

A floating-point number that represents the drive current the pad supplies in the units defined with the `current_unit` library-level attribute.

Example

```
drive_current : 5.0 ;
```

driver_type Simple Attribute

The `driver_type` attribute tells the VHDL library generator to use a special pin-driving configuration for the pin during simulation.

To support pull-up and pull-down circuit structures, the Liberty models for I/O pad cells support pull-up and pull-down driver information using the `driver_type` attribute with the values `pull_up` or `pull_down`. Liberty syntax also supports conditional (programmable) pull-up and pull-down driver information for I/O pad cells. For more information about programmable driver types, see “[Programmable Driver Type Functions](#)”.

Syntax

```
driver_type : pull_up | pull_down | open_drain  
| open_source | bus_hold | resistive | resistive_0 | resistive_1 ;
```

pull_up

The pin is connected to power through a resistor. If it is a three-state output pin, it is in the Z state and its function is evaluated as a resistive 1 (H). If it is an input or inout pin and the node to which it is connected is in the Z state, it is considered an input pin at logic 1 (H). For a pull-up cell, the pin constantly stays at logic 1 (H).

pull_down

The pin is connected to ground through a resistor. If it is a three-state output pin, it is in the Z state and its function is evaluated as a resistive 0 (L). If it is an input or inout pin and the node to which it is connected is in the Z state, it is considered an input pin at logic 0 (L). For a pull-down cell, the pin constantly stays at logic 0 (L).

open_drain

The pin is an output pin without a pull-up transistor. Use this driver type only for off-chip output or inout pins representing pads. The pin goes to high impedance (Z) when its function is evaluated as logic 1.

open_source

The pin is an output pin without a pull-down transistor. Use this driver type only for off-chip output or inout pins representing pads. The pin goes to high impedance (Z) when its function is evaluated as logic 0.

bus_hold

The pin is a bidirectional pin on a bus holder cell. The pin holds the last logic value present at that pin when no other active drivers are on the associated net. Pins with this driver type cannot have `function` or `three_state` statements.

resistive

The pin is an output pin connected to a controlled pull-up or pull-down transistor with a control port EN. When EN is disabled, the pull-up or pull-down transistor is turned off and has no effect on the pin. When EN is enabled, a functional value of 0 evaluated at the pin is turned into a weak 0, and a functional value of 1 is turned into a weak 1, but a functional value of Z is not affected.

resistive_0

The pin is an output pin connected to power through a pull-up transistor that has a control port EN. When EN is disabled, the pull-up transistor is turned off and has no effect on the pin. When EN is enabled, a functional value of 1 evaluated at the pin turns into a weak 1, but a functional value of 0 or Z is not affected.

resistive_1

The pin is an output pin connected to ground through a pull-down transistor that has a control port EN. When EN is disabled, the pull-down transistor is turned off and has no effect on the pin. When EN is enabled, a functional value of 0 evaluated at the pin turns into a weak 0, but a functional value of 1 or Z is not affected.

[Table 3-1](#) lists the driver types, their signal mappings, and the applicable pin types.

Table 3-1 Pin Driver Types

Driver type	Signal mapping	Pin
pull_up	01Z->01H	in, out

pull_down	01Z->01L	in, out
open_drain	01Z->0ZZ	out
open_source	01Z->0Z1Z	out
bus_hold	01Z->01S	inout
resistive	01Z->LHZ	out
resistive_0	01Z->0HZ	out
resistive_1	01Z->L1Z	out

Keep the following concepts in mind when interpreting [Table 3-1](#).

- The signal modifications a `driver_type` attribute defines divide into two categories, transformation and resolution.
 - Transformation specifies an actual signal transition from 0/1 to L/H/Z. This signal transition performs a function on an input signal and requires only a straightforward mapping.
 - Resolution resolves the value Z on an existing circuit node without actually performing a function and implies a constant (0/1) signal source as part of the resolution.
- In [Table 3-1](#), the `pull_up`, `pull_down`, and `bus_hold` driver types define a resolution scheme. The remaining driver types define transformations.

[Example 3-3](#) describes an output pin with a pull-up resistor and the bidirectional pin on a `bus_hold` cell.

Example 3-3 Pin Driver Type Specifications

```
cell (bus) {
  pin(Y) {
    direction : output ;
    driver_type : pull_up ;
    pulling_resistance : 10000 ;
    function : "IO" ;
    three_state : "OE" ;
  }
}
cell (bus_hold) {
  pin(Y) {
    direction : inout ;
    driver_type : bus_hold ;
  }
}
```

Bidirectional pads often require one driver type for the output behavior and another driver type associated with the input behavior. In such a case, define multiple driver types in one `driver_type` attribute, as shown here:

```
driver_type : open_drain pull_up ;
```

Note:

An n-channel open-drain pad is flagged with `open_drain`, and a p-channel open-drain pad is flagged with `open_source`.

Programmable Driver Type Functions

Liberty syntax also supports conditional (programmable) pull-up and pull-down driver information for I/O pad cells. The programmable pin syntax has been extended to `driver_type` attribute values, such as `bus_hold`, `open_drain`, `open_source`, `resistive`, `resistive_0`, and `resistive_1`.

Syntax

The following syntax supports programmable driver types in I/O pad cell models. Unlike the nonprogrammable driver type support, the programmable driver type support allows you to specify more than one driver type within a pin.

```
pin (<pin_name>) { /* programmable driver type pin */
  ...
  pull_up_function : "<function string>" ;
  pull_down_function : "<function string>" ;
  bus_hold_function : "<function string>" ;
  open_drain_function : "<function string>" ;
```

```

open_source_function : "<function string>";
resistive_function : "<function string>";
resistive_0_function : "<function string>";
resistive_1_function : "<function string>";
...
}

```

The functions in [Table 3-2](#) have been introduced on top of (as an extension of) the existing `driver_type` attribute to support programmable pins. These driver type functions help model the programmable driver types. The same rules that apply to nonprogrammable driver types also apply to these functions.

Table 3-2 Programmable Driver Type Functions

Programmable Driver Type	Applicable on Pin Types
<code>pull_up_function</code>	Input, output and inout
<code>pull_down_function</code>	Input, output and inout
<code>bus_hold_function</code>	Inout
<code>open_drain_function</code>	Output and inout
<code>open_source_function</code>	Output and inout
<code>resistive_function</code>	Output and inout
<code>resistive_0_function</code>	Output and inout
<code>resistive_1_function</code>	Output and inout

Example

The following example models a programmable driver type in a I/O pad cell.

```

library(cond_pull_updown_example) {
delay_model : table_lookup;

time_unit : 1ns;
voltage_unit : 1V;
capacitive_load_unit (1.0, pf);
current_unit : 1mA;

cell(conditional_PU_PD) {
    dont_touch : true ;
    dont_use : true ;
    pad_cell : true ;
    pin(IO) {
        drive_current : 1 ;
        min_capacitance : 0.001 ;
        min_transition : 0.0008 ;
        is_pad : true ;
        direction : inout ;
        max_capacitance : 30 ;
        max_fanout : 2644 ;
        function : "(A*ETM)+(TA*ETM)" ;
        three_state : "(TEN*ETM)+(EN*ETM)" ;
        pull_up_function : "(!P1 * !P2)" ;
        pull_down_function : "( P1 * P2)" ;
        capacitance : 2.06649 ;
        timing() {
            related_pin : "IO A ETM TEN TA" ;
            cell_rise(scalar) {
                values("0" ) ;
            }
            rise_transition(scalar) {
                values("0" ) ;
            }
            cell_fall(scalar) {
                values("0" ) ;
            }
            fall_transition(scalar) {
                values("0" ) ;
            }
        }
    }
}

```

```

timing() {
    timing_type : three_state_Disable;
    related_pin : "EN ETM TEN";
    cell_rise(scalar) {
        values("0" );
    }
    rise_transition(scalar) {
        values("0" );
    }
    cell_fall(scalar) {
        values("0" );
    }
    fall_transition(scalar) {
        values("0" );
    }
}

pin(ZI) {
    direction : output;
    function   : "IO" ;
    timing() {
        related_pin : "IO" ;
        cell_rise(scalar) {
            values("0" );
        }
        rise_transition(scalar) {
            values("0" );
        }
        cell_fall(scalar) {
            values("0" );
        }
        fall_transition(scalar) {
            values("0" );
        }
    }
}
pin(A) {
    direction : input;
    capacitance : 1.0;
}
pin(EN) {
    direction : input;
    capacitance : 1.0;
}
pin(TA) {
    direction : input;
    capacitance : 1.0;
}
pin(TEN) {
    direction : input;
    capacitance : 1.0;
}
pin(ETM) {
    direction : input;
    capacitance : 1.0;
}
pin(P1) {
    direction : input;
    capacitance : 1.0;
}
pin(P2) {
    direction : input;
    capacitance : 1.0;
}
} /* End cell conditional_PU_PD */
} /* End Library */

```

driver_waveform Simple Attribute

The `driver_waveform` attribute specified at the pin level is the same as the `driver_waveform` attribute specified at the cell level. For more information, see “[driver_waveform Simple Attribute](#)”.

driver_waveform_rise and driver_waveform_fall Simple Attributes

The `driver_waveform_rise` and `driver_waveform_fall` attributes specified at the pin level are the same as the `driver_waveform_rise` and `driver_waveform_fall` attributes specified at the cell level. For more information, see “[driver waveform rise and driver waveform fall Simple Attributes](#)”.

`fall_capacitance` Simple Attribute

Defines the load for an input and inout pin when its signal is falling.

Setting a value for the `fall_capacitance` attribute requires that a value for `rise_capacitance` also be set, and setting a value for `rise_capacitance` attribute requires that a value for the `fall_capacitance` also be set.

Syntax

```
fall_capacitance : float;
```

float

A floating-point number that represents the internal fanout of the input pin. Typical units of measure for `fall_capacitance` include picofarads and standardized loads.

Example

The following example defines the A and B pins in an AND cell, each with a `fall_capacitance` of one unit, a `rise_capacitance` of two units, and a `capacitance` of two units.

```
cell (AND) {  
    area : 3 ;  
    vhdl_name : "AND2" ;  
    pin (A,B) {  
        direction : input ;  
        fall_capacitance : 1 ;  
        rise_capacitance : 2 ;  
        capacitance : 2 ;  
    }  
}
```

`fall_current_slope_after_threshold` Simple Attribute

The `fall_current_slope_after_threshold` attribute represents a linear approximation of the change in current with respect to time, from the point at which the rising transition reaches the threshold to the end of the transition.

Syntax

```
fall_current_slope_after_threshold : valuefloat;
```

value

A floating-point number that represents the change in current.

Example

```
fall_current_slope_after_threshold : 0.07 ;
```

`fall_current_slope_before_threshold` Simple Attribute

The `fall_current_slope_before_threshold` attribute represents a linear approximation of the change in current with respect to time from the beginning of the falling transition to the threshold point.

Syntax

```
fall_current_slope_before_threshold : valuefloat;
```

value

A floating-point number that represents the change in current.

Example

```
fall_current_slope_before_threshold : -0.14 ;
```

fall_time_after_threshold Simple Attribute

The `fall_time_after_threshold` attribute gives the time interval from the threshold point of the falling transition to the end of the transition.

Syntax

```
fall_time_after_threshold : valuefloat ;
```

value

A floating-point number that represents the time interval.

Example

```
fall_time_after_threshold : 1.8 ;
```

fall_time_before_threshold Simple Attribute

The `fall_time_before_threshold` attribute gives the time interval from the beginning of the falling transition to the point at which the threshold is reached.

Syntax

```
fall_time_before_threshold : valuefloat ;
```

value

A floating-point number that represents the time interval.

Example

```
fall_time_before_threshold : 0.55 ;
```

fanout_load Simple Attribute

The `fanout_load` attribute gives the internal fanout load for an input pin.

Syntax

```
fanout_load : valuefloat ;
```

value

A floating-point number that represents the internal fanout of the input pin. There are no fixed units for `fanout_load`. Typical units are standard loads or pin count.

Example

```
pin (B) {  
    direction : input ;  
    fanout_load : 2.0 ;  
}
```

fault_model Simple Attribute

The differential I/O feature enables an input noninverting pin to inherit the timing information and all associated attributes of an input inverting pin in the same `pin` group designated with the `complementary_pin` attribute.

The `fault_model` attribute defines a two-value string when both differential inputs are driven to the same value. The first value represents the value when both input pins are at logic 0, and the second value represents the value when both input pins are at logic 1.

For details on the `complementary_pin` attribute, see “[complementary_pin Simple Attribute](#)”.

Syntax

```
fault_model : "two-value string" ;
```

two-value string

Two values that define the value of the differential signals when both inputs are driven to the same value. The first value represents the value when both input pins are at logic 0; the second value represents the value when both input pins are at logic 1. Valid values for the two-value string are any two-value combinations made up of 0, 1, and x.

If you do not enter a `fault_model` attribute value, the signal pin value goes to x when both input pins are 0 or 1.

Example

```
cell (diff_buffer) {  
    ...  
    pin (A) { /* noninverting pin /  
        direction : input ;  
        complementary_pin : ("DiffA")  
        fault_model : "1x" ;  
    }  
}
```

function Simple Attribute

The `function` attribute describes the value of a pin or bus.

Pin Names as function Statement Arguments

The `function` attribute in a `pin` group defines the value of an output pin or inout pin in terms of the input pins or inout pins in the `cell` group.

Syntax

```
function : "Boolean expression" ;
```

[Table 3-3](#) lists the valid Boolean operators in a function statement. The precedence of the operators is left to right, with inversion performed first, then XOR, then AND, then OR.

Table 3-3 Valid Boolean Operators

Operator	Description
'	invert previous expression
!	invert following expression
^	logical XOR
*	logical AND
&	logical AND
space	logical AND
+	logical OR
	logical OR
1	signal tied to logic 1
0	signal tied to logic 0

The following example describes pin Q with the function A OR B.

Example

```
pin(Q) {  
    direction : output ;  
    function : "A + B" ;  
}
```

Note:

Pin names beginning with a number, and pin names containing special characters, must be enclosed in double quotation marks preceded by a backslash (\), as shown here:

```
function : " \\"1A\\" + \\"1B\\" " ;
```

The absence of a backslash causes the quotation marks to terminate the function statement.

The following `function` statements all describe 2-input multiplexers. The parentheses are optional. The operators and operands are separated by spaces.

```
function : "A S + B S' " ;
function : "A & S | B & !S" ;
function : "(A * S) + (B * S') " ;
```

Grouped Pins in a function Statement

Grouped pins can be used as variables in the `function` attribute statement.

In `function` attribute statements that use bus or bundle names, all the variables must be either buses or bundles of the same width, or a single bus pin.

Ranges of buses or bundles are valid as long as the range you define contains the same number of members (pins) as the other buses or bundles in the same expression. You can reverse the bus order by listing the member numbers in reverse (high:low) order.

When the `function` attribute of a cell with group input pins is a combinational logic function of grouped variables only, the logic function is expanded to apply to each set of output grouped pins independently. For example, if A, B, and Z are defined as buses of the same width and the function statement for output Z is

```
function : "(A & B) " ;
```

the function for Z[0] is interpreted as

```
function : "(A[ 0 ] & B[ 0 ]) " ;
```

and the function for Z[1] is interpreted as

```
function : "(A[ 1 ] & B[ 1 ]) " ;
```

If a bus and a single pin are in the same `function` attribute, the single pin is distributed across all members of the bus. For example, if A and Z are buses of the same width, B is a single pin, and the function statement for the Z output is

```
function : "(A & B) " ;
```

the function for Z[0] is interpreted as

```
function : "(A[ 0 ] & B) " ;
```

Likewise, the function for Z[1] is interpreted as

```
function : "(A[ 1 ] & B) " ;
```

has_builtin_pad Simple Attribute

Use this attribute in the case of an FPGA containing an ASIC core connected to the chip's port. When set to true, this attribute specifies that an output pin has a built-in pad, which prevents pads from being inserted on the net connecting the pin to the chip's port.

Syntax

```
has_builtin_pad : Boolean ;
```

Example

```
has_builtin_pad : true ;
```

has_pass_gate Simple Attribute

The `has_pass_gate` simple Boolean attribute can be defined in a pin group to indicate whether the pin is internally connected to at least one pass gate.

Syntax

```
has_pass_gate : Boolean expression ;
```

Boolean expression

Valid values are true and false.

hysteresis Simple Attribute

The `hysteresis` attribute allows the pad to accommodate longer transition times, which are more subject to noise problems.

Syntax

```
hysteresis : true | false ;
```

When the attribute is set to true, the vil and vol voltage ratings are actual transition points. When the `hysteresis` attribute is omitted, the value is assumed to be false and no hysteresis occurs.

Example

```
hysteresis : true ;
```

input_map Simple Attribute

The `input_map` attribute maps the input, internal, or output pin names to input and internal node names defined in the `statetable` group.

Syntax

```
input_map : nameid ;
```

name

A string representing a name or a list of port names, separated by spaces, that correspond to the input pin names, followed by the internal node names.

Example

```
input_map : " D G R Q " ;
```

input_signal_level Simple Attribute

The `input_signal_level` attribute describes the voltage levels in the `pin` group of a cell with multiple power supplies. If the `input_signal_level` or `output_signal_level` attribute is missing, you can apply the default power supply name to the cell.

Syntax

```
input_signal_level: nameid ;  
output_signal_level: nameid ;
```

name

A string representing the name of the power supply already defined at the library level. The `input_signal_level` attribute is used for an input or inout pin definition. The `output_signal_level` attribute is used for an output or inout pin definition.

Example

```
input_signal_level: VDD1 ;  
output_signal_level: VDD2 ;
```

`input_threshold_pct_fall` Simple Attribute

Use the `input_threshold_pct_fall` attribute to set the value of the threshold point on an input pin signal falling from 1 to 0. You can specify this attribute at the library-level to set a default value for all pins.

Syntax

```
input_threshold_pct_fall : trip_pointfloat ;
```

trip_point

A floating-point number between 0.0 and 100.0 that specifies the threshold point of an input pin signal falling from 1 to 0. The default value is 50.0.

Example

```
input_threshold_pct_fall : 60.0 ;
```

`input_threshold_pct_rise` Simple Attribute

Use the `input_threshold_pct_rise` attribute to set the value of the threshold point on an input pin signal rising from 0 to 1. You can specify this attribute at the library-level to set a default value for all pins.

Syntax

```
input_threshold_pct_rise : trip_pointfloat ;
```

trip_point

A floating-point number between 0.0 and 100.0 that specifies the threshold point of an input pin signal rising from 0 to 1. The default value is 50.0.

Example

```
input_threshold_pct_rise : 40.0 ;
```

`input_voltage` Simple Attribute

You can define a special set of voltage thresholds in the `library` group with the `input_voltage` or `output_voltage` attribute. You can then apply the default voltage ranges in the group to selected cells with the `input_voltage` or `output_voltage` attribute in the pin definition.

Syntax

```
input_voltage : nameid ;  
output_voltage : nameid ;
```

name

A string representing the name of the voltage range group defined at the library level. The `input_voltage` attribute is used for an input pin definition, and the `output_voltage` attribute is used for an output pin definition.

Example

```
input_voltage : CMOS_SCHMITT ;  
output_voltage : GENERAL ;
```

`internal_node` Simple Attribute

The `internal_node` attribute describes the sequential behavior of an internal pin or an output pin. It indicates the relationship between an internal node in the `statetable` group and a pin of a cell. Each output or internal pin with the `internal_node` attribute can also have the optional `input_map` attribute.

Syntax

```
internal_node : pin_name_id;
```

pin_name

Name of either an internal or output pin.

Example

```
internal_node : IQ ;
```

inverted_output Simple Attribute

Except in statetable cells, where it is required, the `inverted_output` attribute is an optional Boolean attribute that can be set for any output port. Set this attribute to true if the output from the pin is inverted. Set it to false if the output is not inverted.

Syntax

```
inverted_output : Boolean expression ;
```

Example

```
inverted_output : true
```

is_pad Simple Attribute

The `is_pad` attribute indicates which pin represents the pad.

Syntax

```
is_pad : Boolean expression ;
```

This attribute must be used on at least one pin with a `pad_cell` attribute.

Example

```
cell(INBUF) {
    ...
    pad_cell : true ;
    ...
    pin(PAD) {
        direction : input ;
        is_pad : true ;
    }
}
```

is_pll_reference_pin Attribute

The `is_pll_reference_pin` Boolean attribute tags a pin as a reference pin on the phase-locked loop. In a phase-locked loop cell group, the `is_pll_reference_pin` attribute should be set to true in only one input pin group.

Syntax

```
cell (cell_name) {
    is_pll_cell : true;
    pin (ref_pin_name) {
        is_pll_reference_pin : true;
        direction : output;
    }
    ...
}
```

Example

```
cell(my_pll) {
    is_pll_cell : true;
    pin( REFCLK ) {
        direction : input;
    }
}
```

```
    is_pll_reference_pin : true;
}
...
}
```

is_pll_feedback_pin Attribute

The `is_pll_feedback_pin` Boolean attribute tags a pin as a feedback pin on a phase-locked loop. In a phase-locked loop cell group, the `is_pll_feedback_pin` attribute should be set to true in only one input pin group.

Syntax

```
cell (cell_name) {
    is_pll_cell : true;
    pin (ref_pin_name) {
        is_pll_reference_pin : true;
        direction : output;
    }
    pin (feedback_pin_name) {
        is_pll_feedback_pin : true;
        direction : output;
    }
    ...
}
```

Example

```
cell(my_pll) {
    is_pll_cell : true;

    pin( REFCLK ) {
        direction : input;
        is_pll_reference_pin : true;
    }

    pin( FBKCLK ) {
        direction : input;
        is_pll_feedback_pin : true;
    }
    ...
}
```

is_pll_output_pin Attribute

The `is_pll_output_pin` Boolean attribute tags a pin as an output pin on a phase-locked loop. In a phase-locked loop cell group, the `is_pll_output_pin` attribute should be set to true in one or more output pin groups.

Syntax

```
cell (cell_name) {
    is_pll_cell : true;
    pin (ref_pin_name) {
        is_pll_reference_pin : true;
        direction : output;
    }
    ...
    pin (output_pin_name) {
        is_pll_output_pin : true;
        direction : output;
    }
    ...
}
```

Example

```
cell(my_pll) {
    is_pll_cell : true;

    pin( REFCLK ) {
        direction : input;
        is_pll_reference_pin : true;
    }

    pin (OUTCLK_1x) {
        direction : output;
        is_pll_output_pin : true;
    }
}
```

```

timing() { /* Timing Arc */
    related_pin: "REFCLK";
    timing_type: combinational_rise;
    timing_sense: positive_unate;
    ...
}

timing() { /* Timing Arc */
    related_pin: "REFCLK";
    timing_type: combinational_fall;
    timing_sense: positive_unate;
    ...
}

...
} /* End pin group */
} /* End cell group */

```

[is_unbuffered Simple Attribute](#)

The `is_unbuffered` simple Boolean attribute identifies whether the pin is unbuffered. This optional attribute can be specified on the pins of any library cell. The default value is false.

[Syntax](#)

`is_unbuffered : Boolean expression ;`

Boolean expression

Valid values are true and false.

[isolation_cell_enable_pin Simple Attribute](#)

The `isolation_cell_enable_pin` attribute specifies the enable input pin on an isolation cell. For more information about isolation cells, see [“is_isolation_cell Simple Attribute”](#).

[Syntax](#)

`isolation_cell_enable_pin : Boolean expression ;`

Boolean expression

Valid values are true and false.

[Example](#)

```
isolation_cell_enable_pin : true ;
```

[isolation_cell_data_pin Simple Attribute](#)

The `isolation_cell_data_pin` attribute identifies the data pin of any isolation cell. The valid values of this attribute are "true" or "false." If not specified, all the isolation cell's input pins default to a data pin.

[Syntax](#)

`isolation_cell_data_pin : Boolean expression ;`

Boolean expression

Valid values are true and false.

[Example](#)

```
isolation_cell_data_pin : true ;
```

[level_shifter_enable_pin Simple Attribute](#)

The `level_shifter_enable_pin` attribute specifies the enable input pin on a level shifter cell. For more information about level shifter cells, see [“is_level_shifter Simple Attribute”](#).

[Syntax](#)

`level_shifter_enable_pin : Boolean expression ;`

Boolean expression

Valid values are true and false.

Example

```
level_shifter_enable_pin : true ;
```

`map_to_logic` Simple Attribute

The `map_to_logic` attribute specifies which logic level to tie a pin to when a power gating cell functions as a normal cell. For more information about power gating cells, see [“power_gating_cell Simple Attribute”](#).

Syntax

`map_to_logic : Boolean expression ;`

Boolean expression

Valid values are 1 and 0.

Example

```
map_to_logic :1 ;
```

`max_capacitance` Simple Attribute

The `max_capacitance` attribute defines the maximum total capacitive load an output pin can drive. Define this attribute only for an output or inout pin.

Syntax

`max_capacitance : valuefloat ;`

value

A floating-point number that represents the capacitive load.

Example

```
max_capacitance : 1 ;
```

`max_fanout` Simple Attribute

The `max_fanout` attribute defines the maximum fanout load that an output pin can drive.

Syntax

`max_fanout : valuefloat ;`

value

A floating-point number that represents the number of fanouts the pin can drive. There are no fixed units for `max_fanout`. Typical units are standard loads or pin count.

Example

In the following example, pin X can drive a fanout load of no more than 11.0.

```
pin (X) {  
    direction : output ;  
    max_fanout : 11.0 ;  
}
```

`max_input_noise_width` Simple Attribute

The `max_input_noise_width` attribute allows you to specify a maximum value for the input noise width on an input pin or an output pin.

Note:

When you specify a `max_input_noise_width` value, you must also specify a `min_input_noise_width` value that is less than or equal to the `max_input_noise_width` value.

Syntax

```
max_input_noise_width : valuefloat ;
```

value

A floating-point number that represents the maximum input noise width.

Example

```
max_input_noise_width : 0.0 ;
```

max_transition Simple Attribute

The `max_transition` attribute defines a design rule constraint for the maximum acceptable transition time of an input or output pin.

Syntax

```
max_transition : valuefloat ;
```

value

A floating-point number in units consistent with other time values in the library.

Example

The following example shows a `max_transition` time of 4.2:

```
max_transition : 4.2 ;
```

min_capacitance Simple Attribute

The `min_capacitance` attribute defines the minimum total capacitive load an output pin should drive. Define this attribute only for an output or inout pin.

Syntax

```
min_capacitance : valuefloat ;
```

value

A floating-point number that represents the capacitive load.

Example

```
min_capacitance : 1 ;
```

min_fanout Simple Attribute

The `min_fanout` attribute defines the minimum fanout load that an output pin should drive.

Syntax

```
min_fanout : valuefloat ;
```

value

A floating-point number that represents the minimum number of fanouts the pin can drive. There are no fixed units

for `min_fanout`. Typical units are standard loads or pin count.

Example

In the following example, pin X can drive a fanout load of no less than 3.0.

```
pin (X) {  
    direction : output ;  
    min_fanout : 3.0 ;  
}
```

min_input_noise_width Simple Attribute

The `min_input_noise_width` attribute allows you to specify a minimum value for the input noise width on an input pin or an output pin.

Note:

When you specify a `min_input_noise_width` value, you must also specify a `max_input_noise_width` value that is equal to or greater than the `min_input_noise_width` value.

Syntax

```
min_input_noise_width : valuefloat ;
```

value

A floating-point number that represents the minimum input noise width.

Example

```
min_input_noise_width : 0.0 ;
```

min_period Simple Attribute

Placed on the clock pin of a flip-flop or latch, the `min_period` attribute specifies the minimum clock period required for the input pin.

Syntax

```
min_period : valuefloat ;
```

value

A floating-point number indicating a time unit.

Example

```
pin (CLK4) {  
    direction : input ;  
    capacitance : 1 ;  
    clock : true ;  
    min_period : 26.0 ;
```

min_pulse_width_high Simple Attribute

The VHDL library generator uses the optional `min_pulse_width_high` and `min_pulse_width_low` attributes for simulation.

Syntax

```
min_pulse_width_high : valuefloat ;
```

value

A floating-point number defined in units consistent with other time values in the library. It gives the minimum length of time the pin must remain at logic 1 (`min_pulse_width_high`) or logic 0 (`min_pulse_width_low`).

Example

The following example shows both attributes on a clock pin, indicating the minimum pulse width for a clock pin.

```
pin(CLK) {
    direction : input ;
    capacitance : 1 ;
    min_pulse_width_high : 3 ;
    min_pulse_width_low : 3 ;
}
```

min_pulse_width_low Simple Attribute

For information about using the `min_pulse_width_low` attribute, see the description of the [min_pulse_width_high Simple Attribute](#).

multicell_pad_pin Simple Attribute

The `multicell_pad_pin` attribute indicates which pin on a cell should be connected to another cell to create the correct configuration.

Syntax

```
multicell_pad_pin : true | false ;
```

Use this attribute for all pins on a pad cell or auxiliary pad cell that are connected to another cell.

Example

```
multicell_pad_pin : true ;
```

nextstate_type Simple Attribute

In a `pin` group, the `nextstate_type` attribute defines the type of the `next_state` attribute. You define a `next_state` attribute in an `ff` group or an `ff_bank` group.

Note:

Specify a `nextstate_type` attribute to ensure that the sync set (or sync reset) pin and the D pin of sequential cells are not swapped when the design is instantiated.

Syntax

```
nextstate_type : data | preset
| clear | load | scan_in | scan_enable ;
```

where

data

Identifies the pin as a synchronous data pin. This is the default value.

preset

Identifies the pin as a synchronous preset pin.

clear

Identifies the pin as a synchronous clear pin.

load

Identifies the pin as a synchronous load pin.

scan_in

Identifies the pin as a synchronous scan-in pin.

scan_enable

Identifies the pin as a synchronous scan-enable pin.

Any pin with the `nextstate_type` attribute must be in the `next_state` function. A consistency check is also made between the pin's `nextstate_type` attribute and the `next_state` function. [Format Example & Page not handled yet](#) shows a `nextstate_type` attribute in a bundle group.

`output_signal_level` Simple Attribute

See "[input_signal_level Simple Attribute](#)".

`output_voltage` Simple Attribute

See "[input_voltage Simple Attribute](#)".

`pg_function` Simple Attribute

The `pg_function` attribute is used for the coarse-grain switch cells' virtual VDD output pins to represent the propagated power level through the switch as a function of input `pg_pins`. This is normally a logical buffer and is useful in cases where the VDD and VSS connectivity may be erroneously reversed.

Syntax

```
pg_function : "<function_string>" ;
```

Example

```
pg_function : "VDD" ;
```

`pin_func_type` Simple Attribute

The `pin_func_type` attribute describes the functionality of a pin.

Syntax

```
pin_func_type : clock_enable | active_high | active_low |  
active_rising | active_falling ;
```

`clock_enable`

Enables the clocking mechanism.

`active_high and active_low`

Describes the clock active edge or the level of the enable pin of the latches.

`active_rising and active_falling`

Describes the clock active edge or level of the clock pin of the flip-flops.

Example

```
pin_func_type : clock_enable ;
```

`power_down_function` Simple Attribute

The `power_down_function` string attribute specifies the Boolean condition under which the cell's output pin is switched off by the state of the power and ground pins (when the cell is in off mode due to the external power pin states).

You specify the `power_down_function` attribute for combinational and sequential cells. For simple or complex sequential cells, `power_down_function` also determines the condition of the cell's internal state.

Syntax

```
power_down_function : function_string ;
```

Example

```
power_down_function : "!VDD + VSS";
```

`prefer_tied` Simple Attribute

The `prefer_tied` attribute describes an input pin of a flip-flop or latch. It indicates what the library developer wants this pin connected to.

Syntax

```
prefer_tied : "0" | "1" ;
```

You can have as many `prefer_tied` attributes as possible while it is still able to implement D functionality. However, not all will be honored.

For example, if the library developer specifies

```
prefer_tied : "0" ;
```

on all the inputs, as many as possible are honored and the rest are ignored. If they are ignored, a message indicating this fact is issued during execution of the `read_lib` command.

Example

The following example shows a `prefer_tied` attribute on a test-enable pin.

```
pin(TE) {  
    direction : input;  
    prefer_tied : "0" ;  
}
```

primary_output Simple Attribute

The `primary_output` attribute describes the primary output pin of a device that has more than one output pin for a particular phase of the output signal. When set to true, it indicates that one of the output pins is the primary output pin.

Syntax

```
primary_output : true | false ;
```

pulling_current Simple Attribute

The `pulling_current` attribute defines the current-drawing capability of a pull-up or pull-down device on a pin. This attribute can be used for pins with the `driver_type` attribute set to `pull_up` or `pull_down`.

Syntax

```
pulling_current : current value ;
```

current value

If you characterize your pull-up or pull-down devices in terms of the current drawn during nominal operating conditions, use `pulling_current` instead of `pulling_resistance`.

Example

```
pin(Y) {  
    direction : output ;  
    driver_type : pull_up ;  
    pulling_resistance : 1000 ;  
    ...  
}
```

pulling_resistance Simple Attribute

The `pulling_resistance` attribute defines the resistance strength of a pull-up or pull-down device on a pin. This attribute can be used for pins with the `driver_type` attribute set to `pull_up` or `pull_down`.

Syntax

```
pulling_resistance : resistance value ;
```

resistance value

The resistive strength of the pull-up or pull-down device.

Example

```
pin(Y) {
    direction : output ;
    driver_type : pull_up ;
    pulling_resistance : 1000 ;
    ...
}
```

pulse_clock Simple Attribute

Use the `pulse_clock` attribute to model edge-derived clocks at the pin level.

Syntax

```
pulse_clock : pulse_typeenum ;
```

pulse_type
The valid values are `rise_triggered_high_pulse`, `rise_triggered_low_pulse`, `fall_triggered_high_pulse`, and `fall_triggered_low_pulse`.

Example

```
pin(Y) {
    ...
    pulse_clock : rise_triggered_low_pulse ;
    ...
}
```

related_ground_pin Simple Attribute

The optional `related_power_pin` and `related_ground_pin` attributes, defined at the pin level for output pins and inout pins, replace the `output_signal_level` attribute. These attributes can also be defined at the pin level for input/inout pins to replace the `input_signal_level`, except when you have input overdrive models. In this case, you need to use the `input_signal_level` to capture the input overdrive voltage, which cannot be modeled with `related_power_pin`.

Syntax

```
related_ground_pin : pg_pin_nameid ;
```

pg_pin_name
Name of the related ground pin.

Example

```
pin(Y) {
    ...
    related_ground_pin : G1 ;
    ...
}
```

related_power_pin Simple Attribute

For details about the `related_ground_pin` attribute, see “[related_ground_pin Simple Attribute](#)”.

Syntax

```
related_power_pin : pg_pin_nameid ;
```

pg_pin_name
Name of the related power pin.

Example

```
pin(Y) {
```

```
...
related_power_pin : P1 ;
...
}
```

[rise_capacitance Simple Attribute](#)

Defines the load for an input or an inout pin when its signal is rising.

Setting a value for the `rise_capacitance` attribute requires that a value for `fall_capacitance` attribute also be set, and setting a value for `fall_capacitance` requires that a value for the `rise_capacitance` also be set.

[Syntax](#)

```
rise_capacitance : float;
```

float

A floating-point number in units consistent with other capacitance specifications throughout the library. Typical units of measure for `rise_capacitance` include picofarads and standardized loads.

[Example](#)

The following example defines the A and B pins in an AND cell, each with a `fall_capacitance` of one unit, a `rise_capacitance` of two units, and a `capacitance` of two units.

```
cell (AND) {
    area : 3 ;
    vhdl_name : "AND2" ;
    pin (A,B) {
        direction : input ;
        fall_capacitance : 1 ;
        rise_capacitance : 2 ;
        capacitance : 2 ;
    }
}
```

[rise_current_slope_after_threshold Simple Attribute](#)

The `rise_current_slope_after_threshold` attribute represents a linear approximation of the change in current over time from the point at which the rising transition reaches the threshold to the end of the transition.

[Syntax](#)

```
rise_current_slope_after_threshold : valuefloat ;
```

value

A negative floating-point number that represents the change in current.

[Example](#)

```
rise_current_slope_after_threshold : -0.09 ;
```

[rise_current_slope_before_threshold Simple Attribute](#)

The `rise_current_slope_before_threshold` attribute represents a linear approximation of the change in current over time, from the beginning of the rising transition to the threshold point.

[Syntax](#)

```
rise_current_slope_before_threshold : valuefloat ;
```

value

A positive floating-point number that represents the change in current.

[Example](#)

```
rise_current_slope_before_threshold : 0.18;
```

rise_time_after_threshold Simple Attribute

The `rise_time_after_threshold` attribute gives the time interval from the threshold point of the rising transition to the end of the transition.

Syntax

```
rise_time_after_threshold : valuefloat;
```

value

A floating-point number that represents the time interval for the rise transition from threshold to finish (after).

Example

```
rise_time_after_threshold : 2.4;
```

rise_time_before_threshold Simple Attribute

The `rise_time_before_threshold` attribute gives the time interval from the beginning of the rising transition to the point at which the threshold is reached.

Syntax

```
rise_time_before_threshold : valuefloat;
```

value

A floating-point number that represents the time interval for the rise transition from start to threshold (before).

Example

```
rise_time_before_threshold : 0.8 ;
```

signal_type Simple Attribute

In a `test_cell` group, `signal_type` identifies the type of test pin.

Syntax

```
signal_type : test_scan_in | test_scan_in_inverted  
|  
  test_scan_out | test_scan_out_inverted |  
  test_scan_enable |  
  test_scan_enable_inverted |  
  test_scan_clock | test_scan_clock_a |  
  test_scan_clock_b | test_clock ;
```

test_scan_in

Identifies the scan-in pin of a scan cell. The scanned value is the same as the value present on the scan-in pin. All scan cells must have a pin with either the `test_scan_in` or the `test_scan_in_inverted` attribute.

test_scan_in_inverted

Identifies the scan-in pin of a scan cell as having inverted polarity. The scanned value is the inverse of the value present on the scan-in pin.

For multiplexed flip-flop scan cells, the polarity of the scan-in pin is inferred from the latch or ff declaration of the cell itself. For other types of scan cells, clocked-scan, LSSD, and multiplexed flip-flop latches, it is not possible to give the ff or latch declaration of the entire scan cell. For these cases, you can use the `test_scan_in_inverted` attribute in the cell where the scan-in pin appears in the latch or ff declarations for the entire cell.

test_scan_out

Identifies the scan-out pin of a scan cell. The value present on the scan-out pin is the same as the scanned value. All scan cells must have a pin with either a `test_scan_out` or a `test_scan_out_inverted` attribute.

The scan-out pin corresponds to the output of the slave latch in the LSSD methodologies.

`test_scan_out_inverted`

Identifies the scan-out pin of a test cell as having inverted polarity. The value on this pin is the inverse of the scanned value.

`test_scan_enable`

Identifies the pin of a scan cell that, when high, indicates that the cell is configured in scan-shift mode. In this mode, the clock transfers data from the scan-in input to the scan-out input.

`test_scan_enable_inverted`

Identifies the pin of a scan cell that, when low, indicates that the cell is configured in scan-shift mode. In this mode, the clock transfers data from the scan-in input to the scan-out input.

`test_scan_clock`

Identifies the test scan clock for the clocked-scan methodology. The signal is assumed to be edge-sensitive. The active edge transfers data from the scan-in pin to the scan-out pin of a cell. The sense of this clock is determined by the sense of the associated timing arcs.

`test_scan_clock_a`

Identifies the a clock pin in a cell that supports a single-latch LSSD, double-latch LSSD, clocked LSSD, or auxiliary clock LSSD methodology. When the a clock is at the active level, the master latch of the scan cell can accept scan-in data. The sense of this clock is determined by the sense of the associated timing arcs.

`test_scan_clock_b`

Identifies the b clock pin in a cell that supports the single-latch LSSD, clocked LSSD, or auxiliary clock LSSD methodology. When the b clock is at the active level, the slave latch of the scan-cell can accept the value of the master latch. The sense of this clock is determined by the sense of the associated timing arcs.

`test_clock`

Identifies an edge-sensitive clock pin that controls the capturing of data to fill scan-in test mode in the auxiliary clock LSSD methodology.

If an input pin is used in both test and nontest modes (such as the clock input in the multiplexed flip-flop methodology), do not include a `signal_type` statement for that pin in the `test_cell` pin definition.

If an input pin is used only in test mode and does not exist on the cell that it will scan and replace, you must include a `signal_type` statement for that pin in the `test_cell` pin definition.

If an output pin is used in nontest mode, it needs a `function` statement. The `signal_type` statement is used to identify an output pin as a scan-out pin. In a `test_cell` group, the `pin` group for an output pin can contain a `function` statement, a `signal_type` attribute, or both.

Note:

You do not have to define a `function` or `signal_type` attribute in the `pin` group if the pin is defined in a previous `test_cell` group for the same cell.

Example

```
signal_type : test_scan_in ;
```

`slew_control Simple Attribute`

The `slew_control` attribute provides increasing levels of slew-rate control to slow down the transition rate. This attribute associates a coarse measurement of slew-rate control with the output pad cell.

Syntax

```
slew_control : low | medium | high | none ;
```

low, medium, high

Provides increasingly higher levels of slew-rate control.

none

Indicates that no slew-rate control is applied. If you do not use `slew_control`, none is the default.

This attribute limits peak noise by smoothing out fast output transitions, thus decreasing the possibility of a momentary disruption in the power or ground planes.

`slew_lower_threshold_pct_fall` Simple Attribute

Use the `slew_lower_threshold_pct_fall` attribute to set the value of the lower threshold point used in modeling the delay of a pin falling from 1 to 0. You can specify this attribute at the library-level to set a default value for all pins.

Syntax

```
slew_lower_threshold_pct_fall : trip_point_value ;
```

trip_point

A floating-point number between 0.0 and 100.0 that specifies the lower threshold point used to model the delay of a pin falling from 1 to 0. The default value is 20.0.

Example

```
slew_lower_threshold_pct_fall : 30.0 ;
```

`slew_lower_threshold_pct_rise` Simple Attribute

Use the `slew_lower_threshold_pct_rise` attribute to set the value of the lower threshold point used in modeling the delay of a pin rising from 0 to 1. You can specify this attribute at the library-level to set a default value for all pins.

Syntax

```
slew_lower_threshold_pct_rise : trip_point_value ;
```

trip_point

A floating-point number between 0.0 and 100.0 that specifies the lower threshold point used to model the delay of a pin rising from 0 to 1. The default value is 20.0.

Example

```
slew_lower_threshold_pct_rise : 30.0 ;
```

`slew_upper_threshold_pct_fall` Simple Attribute

Use the `slew_upper_threshold_pct_fall` attribute to set the value of the upper threshold point used in modeling the delay of a pin falling from 1 to 0. You can specify this attribute at the library-level to set a default value for all pins.

Syntax

```
slew_upper_threshold_pct_fall : trip_point_value ;
```

trip_point

A floating-point number between 0.0 and 100.0 that specifies the upper threshold point used to model the delay of a pin falling from 1 to 0. The default value is 80.0.

Example

```
slew_upper_threshold_pct_fall : 70.0 ;
```

`slew_upper_threshold_pct_rise` Simple Attribute

Use the `slew_upper_threshold_pct_rise` attribute to set the value of the upper threshold point used in modeling the delay of a pin rising from 0 to 1. You can specify this attribute at the library-level to set a default value for all pins.

Syntax

```
slew_upper_threshold_pct_rise : trip_pointvalue ;
```

trip_point

A floating-point number between 0.0 and 100.0 that specifies the upper threshold point used to model the delay of a pin rising from 0 to 1. The default value is 80.0.

Example

```
slew_upper_threshold_pct_rise : 70.0 ;
```

state_function Simple Attribute

The `state_function` attribute defines output logic. The attribute describes a function of input and inout ports that can be made three-state, or ports with an `internal_node` attribute. A port in the `state_function` expression refers only to the non-three-state functional behavior of that port. An inout port in the `state_function` expression is treated only as an input port.

Syntax

```
state_function : "Boolean expression" ;
```

Example

```
state_function : "QN'" ;
```

For a list of Boolean operators, see [Table 3-3](#).

std_cell_main_rail Simple Attribute

The `std_cell_main_rail` Boolean attribute is defined in a `primary_power` power pin. When the attribute is set to true, the power and ground pin is used to determine which side of the voltage boundary the power and ground pin is connected.

Syntax

```
std_cell_main_rail : true | false ;
```

Example

```
std_cell_main_rail : true ;
```

switch_function Simple Attribute

The `switch_function` string attribute identifies the condition when the attached design partition is turned off by the input `switch_pin`.

For a coarse-grain switch cell, the `switch_function` attribute can be defined at both controlled power and ground pins (virtual VDD and virtual VSS for `pg_pin`) and the output pins.

When the `switch_function` attribute is defined in the controlled power and ground pin, it is used to specify the Boolean condition under which the cell switches off (or drives a Z to) the controlled design partitions, including the traditional signal input pins only (with no related power pins to this output).

Syntax

```
switch_function : function_string ;
```

Example

```
switch_function : "CTL";
```

switch_pin Simple Attribute

The `switch_pin` attribute is a pin-level Boolean attribute. When it is set to true, it is used to identify the pin as the switch pin of a coarse-grain switch cell.

Syntax

```
switch_pin : valueBoolean ;
```

Example

```
switch_pin : true ;

test_output_only Simple Attribute
```

This attribute can be set for any output port described in statetable format.

In ff/latch format, if a port is to be used for both function and test, you provide the functional description using the `function` attribute. If a port is to be used for test only, you omit the `function` attribute.

In statetable format, however, a port always has a functional description. Therefore, if you want to specify that a port is for test only, you set the `test_output_only` attribute to true.

Syntax

```
test_output_only : true | false ;
```

Example

```
pin (scout) {
    direction : output ;
    signal_type : test_scan_out ;
    test_output_only : true ;
}
```

three_state Simple Attribute

The `three_state` attribute defines a three-state output pin in a cell.

Syntax

```
three_state : "Boolean expression" ;

Boolean expression
```

An equation defining the condition that causes the pin to go to the high-impedance state. The syntax of this equation is the same as the syntax of the `function` attribute statement described in [“function Simple Attribute”](#). The `three_state` attribute can be used in both combinational and sequential `pin` groups, with `bus` or `bundle` variables.

Example

```
three_state : "!E" ;
```

For a list of Boolean operators, see [Table 3-3](#).

vhdl_name Simple Attribute

The `vhdl_name` attribute defines valid VHDL object names. In `cell` and `pin` groups, use `vhdl_name` to resolve conflicts of invalid object names when porting from .db to VHDL. Some .db object names might violate the more restrictive VHDL rules for identifiers.

Syntax

```
vhdl_name : "name_string" ;

name
```

A string that represents a valid VHDL object name.

Example

```
vhdl_name : "INb" ;
```

[Example 3-4](#) shows a `vhdl_name` attribute in a `cell` group.

Example 3-4 Use of the `vhdl_name` Attribute in a Cell Description

```

cell (INV) {
    area : 1;
    pin(IN) {
        vhdl_name : "INb";
        direction : input;
        capacitance : 1;
    }
    pin(Z) {
        direction : output;
        function : "IN'";
        timing () {
            intrinsic_rise : 0.23;
            intrinsic_fall : 0.28;
            rise_resistance : 0.13;
            fall_resistance : 0.07;
            related_pin : "IN";
        }
    }
}

```

[x_function Simple Attribute](#)

The `x_function` attribute describes the X behavior of an output or inout pin. X is a state other than 0, 1, or Z.

[Syntax](#)

```
x_function : "Boolean expression";
```

[Example](#)

```
x_function : "!an * ap";
```

[3.1.3 Complex Attributes](#)

This section describes the complex attributes you can use in a `pin` group.

[fall_capacitance_range Complex Attribute](#)

The `fall_capacitance_range` attribute specifies a range of values for pin capacitance during fall transitions.

[Syntax](#)

```
fall_capacitance_range (value_1float, value_2float);
```

`value_1, value_2`

Positive floating-point numbers that specify the range of values.

[Example](#)

```
fall_capacitance_range (0.0, 0.0);
```

[power_gating_pin Complex Attribute](#)

Note:

The `power_gating_pin` attribute has been replaced by the `retention_pin` attribute. See ["retention_pin Complex Attribute"](#).

The `power_gating_pin` attribute specifies a pair of pin values for a power gating cell. The first value represents the power gating pin class. The second value specifies which logic level (default) the power gating cell is tied to when the power gating cell is functioning in normal mode. For more information about specifying power gating cells, see ["power_gating_cell Simple Attribute"](#).

[Syntax](#)

```
power_gating_pin ("power_pin_<1-5>", <enumerated_type>);
```

`value_1`

A string that represents one of five predefined classes of power gating pins: power_pin_[1-5].

value_2

An integer that specifies the default logic level for the pin when the power gating cell functions as a normal cell.

Example

```
power_gating_pin ( "power_pin_1" , 0 ) ;
```

retention_pin Complex Attribute

The retention_pin complex attribute identifies the retention pins of a retention cell. The attribute defines the following information:

- pin class
 - restore
Restores the state of the cell.
 - save
Saves the state of the cell.
 - save_restore
Saves and restores the state of the cell.

- disable value

Defines the value of the retention pin when the cell works in normal mode. The valid values are 0 and 1.

Syntax

```
retention_pin (pin_class, disable_value) ;
```

Example

```
retention_pin (save/restore/save_restore, <enumerated_type>) ;
```

rise_capacitance_range Complex Attribute

The rise_capacitance_range attribute specifies a range of values for pin capacitance during rise transitions.

Syntax

```
rise_capacitance_range (value_1float, value_2float) ;
```

value_1, value_2

Positive floating-point numbers that specify the range of values.

Example

```
rise_capacitance_range (0.0, 0.0) ;
```

3.2 Group Statements

You can use the following group statements in a pin group:

```
ccsn_first_stage () {}  
ccsn_last_stage () {}  
dc_current () {}  
electromigration () {}  
hyperbolic_noise_above_high () {}  
hyperbolic_noise_below_low () {}  
hyperbolic_noise_high () {}  
hyperbolic_noise_low () {}  
input_signal_swing () {}  
internal_power () {}  
max_capacitance () {}  
max_transition () {}
```

```

min_pulse_width () { }
minimum_period () { }
output_signal_swing () {}
pin_capacitance() { }
timing () { }
tLatch () { }

```

3.2.1 ccsn_first_stage Group

Use the `ccsn_first_stage` group to specify CCS noise for the first stage of the channel-connected block (CCB).

A `ccsn_first_stage` or `ccsn_last_stage` group contains the following information:

- A set of CCB parameters: `is_needed`, `is_inverting`, `stage_type`, `miller_cap_rise`, and `miller_cap_fall`
- A two-dimensional DC current table: `dc_current` group
- Two timing tables for rising and falling transitions: `output_current_rise` group, `output_current_fall` group
- Two noise tables for low and high propagated noise: `propagated_noise_low` group, `propagated_noise_high` group

Note that if the `ccsn_first_stage` and `ccsn_last_stage` groups are defined inside pin-level groups, then the `ccsn_first_stage` group can only be defined in an input pin or an inout pin, and the `ccsn_last_stage` group can only be defined in an output pin or an inout pin.

Syntax

```

library (name) {
...
cell (name) {
  pin (name) {
    ...
      ccsn_first_stage () {
        is_needed : <boolean>;
        is_inverting : <boolean>;
        stage_type : <stage_type_value>;
        miller_cap_rise : <float>;
        miller_cap_fall : <float>;
        dc_current (<dc_current_template>)
          index_1("<float>, ...");
          index_2("<float>, ...");
          values("<float>, ...");
      }
      output_voltage_rise ( )
        vector (<output_voltage_template_name>)
          index_1(<float>);
          index_2(<float>);
          index_3("<float>, ...");
          values("<float>, ...");
      }
      ...
    }
    ...
  }
  output_voltage_fall ( )
    vector (<output_voltage_template_name>)
      index_1(<float>);
      index_2(<float>);
      index_3("<float>, ...");
      values("<float>, ...");
  }
  ...
}

propagated_noise_low ( ) {
  vector (<propagated_noise_template_name>)
    index_1(<float>);
    index_2(<float>);
    index_3(<float>);
    index_4("<float>, ...");
    values("<float>, ...");
}
...
propagated_noise_high ( )
  vector (<propagated_noise_template_name>)

```

```

        index_1(<float>);
        index_2(<float>);
        index_3(<float>);
        index_4("<float>, ...");
        values("<float>, ...");
    }
    ...
}
when : <boolean expression>;
}
}
}

```

Simple Attributes

is_inverting
 is_needed
 is_pass_gate
 miller_cap_fall
 miller_cap_rise
 stage_type
 when

Group Statements

dc_current
 output_voltage_fall
 output_voltage_rise
 propagated_noise_low
 propagated_noise_rise

is_inverting Simple Attribute

Use the `is_inverting` attribute to specify whether the channel-connecting block is inverting. This attribute is mandatory if the `is_needed` attribute value is true. If the channel-connecting block is inverting, set the attribute to true. Otherwise, set the attribute to false. Note that this attribute is different from the “invertness” (or `timing_sense`) of a timing arc, which may consist of multiple channel-connecting blocks.

Syntax

`is_inverting : valueBoolean;`

`value`

Valid values are `true` and `false`. Set the value to true when the channel-connecting block is inverting.

Example

`is_inverting : true ;`

is_needed Simple Attribute

Use the `is_needed` attribute to specify whether composite current source (CCS) noise modeling data is required.

Syntax

`is_needed : valueBoolean;`

`value`

Valid values are `true` and `false`. The default is true. Set the value to false for cells such as diodes, antennas, and cloud cells that do not need current-based data.

Example

`is_needed : true ;`

is_pass_gate Simple Attribute

The `is_pass_gate` Boolean attribute is defined in a `ccsn_*_stage` group (such as `ccsn_first_stage`) to indicate whether the `ccsn_*_stage` information is modeled for a pass gate. The attribute is optional and its default value is false.

Syntax

```
is_pass_gate : Boolean expression ;
```

Boolean expression

Valid values are true and false.

miller_cap_fall Simple Attribute

Use the `miller_cap_fall` attribute to specify the Miller capacitance value for the channel-connecting block.

Syntax

```
miller_cap_fall : valuefloat ;
```

value

A floating-point number representing the Miller capacitance value. The value must be greater or equal to zero.

Example

```
miller_cap_fall : 0.00084 ;
```

miller_cap_rise Simple Attribute

Use the `miller_cap_rise` attribute to specify the Miller capacitance value for the channel-connecting block.

Syntax

```
miller_cap_rise : valuefloat ;
```

value

A floating-point number representing the Miller capacitance value. The value must be greater or equal to zero.

Example

```
miller_cap_rise : 0.00055 ;
```

mode Attribute

The pin-based `mode` attribute is provided in the `ccsn_first_stage` and `ccsn_last_stage` groups for conditional data modeling. If the `mode` attribute is specified, `mode_name` and `mode_value` must be predefined in the `mode_definition` group at the cell level.

stage_type Simple Attribute

Use the `stage_type` attribute to specify the stage type of the channel-connecting block output voltage.

Syntax

```
stage_type : valueenum ;
```

value

The valid values are `pull_up`, in which the output voltage of the channel-connecting block is always pulled up (rising); `pull_down`, in which the output voltage of the channel-connecting block is always pulled down (falling); and `both`, in which the output voltage of the channel-connecting block is pulled up or down.

Example

```
stage_type : pull_up ;
```

when Simple Attribute

The `when` attribute is defined in both the pin-level and the timing-level `ccsn_first_stage` and `ccsn_last_stage` groups. Use this attribute to specify the condition under which the channel-connecting block data is applied.

Syntax

```
when : valueboolean ;  
  
value  
  
Result of a Boolean expression.
```

dc_current Group

Use the dc_current group to specify the input and output voltage values of a two-dimensional current table for a channel-connecting block.

Syntax

```
dc_current( dc_current_templateid ) {}  
index_1 ("float, ... , float") ;  
index_2 ("float, ... , float") ;  
values ("float, ... , float") ;
```

dc_current_template

The name of the dc current lookup table.

Use index_1 to represent the input voltage and index_2 to represent the output voltage. The values attribute of the group lists the relative channel-connecting block DC current values in library units measured at the channel-connecting block output node.

output_voltage_fall Group

Use the output_voltage_fall group to specify vector groups that describe three-dimensional output_voltage tables of the channel-connecting block whose output node's voltage values are falling.

```
output_voltage_fall () {  
  
vector <output_voltage_template_name> {  
    index_1(float);  
    index_2(float);  
    index_3("float, ...");  
    values("float, ...");
```

Complex Attributes

```
index_1  
index_2  
index_3  
values
```

Specify the following attributes in the vector group: The index_1 attribute lists the input_net_transition (slew) values in library time units. The index_2 attribute lists the total_output_net_capacitance (load) values in library capacitance units. The index_3 attribute lists the sampling time values in library time units. The values attribute lists the voltage values, in library voltage units, that are measured at the channel-connecting block output node.

output_voltage_rise Group

Use the output_voltage_rise group to specify vector groups that describe three-dimensional output_voltage tables of the channel-connecting block whose output node's voltage values are rising.

For details, see the output_voltage_fall group description.

propogated_noise_high Group

The propogated_noise_high group uses vector groups to specify the three-dimensional output_voltage tables of the channel-connecting block whose output node's voltage values are rising.

```
propogated_noise_high () {  
  
vector <output_voltage_template_name> {  
    index_1(float);  
    index_2(float);  
    index_3(float);  
    index_4("float, ...");  
    values("float, ...");
```

Complex Attributes

```
index_1
index_2
index_3
index_4
values
```

Specify the following attributes in the `vector` group: The `index_1` attribute lists the `input_noise_height` values in library voltage units. The `index_2` attribute lists the `input_noise_width` values in library time units. The `index_3` attribute lists the `total_output_net_capacitance` values in library capacitance units. The `index_4` attribute lists the sampling time values in library time units. The `values` attribute lists the voltage values, in library voltage units, that are measured at the channel-connecting block output node.

propogated_noise_low Group

Use the `propogated_noise_low` group to specify the three-dimensional `output_voltage` tables of the channel-connecting block whose output node's voltage values are falling.

For details, see the [“propogated_noise_high Group”](#).

3.2.2 ccsn_last_stage Group

Use the `ccsn_last_stage` group to specify composite current source (CCS) noise for the last stage of the channel-connecting block.

For details, see [“ccsn_first_stage Group”](#).

3.2.3 electromigration Group

An `electromigration` group is defined in a `pin` group, as shown here:

```
library (name) {
  cell (name) {
    pin (name) {
      electromigration () {
        ... electromigration   description ...
      }
    }
  }
}
```

Simple Attributes

```
related_pin : "name | name_list" /* path dependency */
related_bus_pins : "list of pins" /* list of pin names */
when : Boolean expression;
```

Complex Attributes

```
index_1 ("float, ..., float") ; /* optional */
index_2 ("float, ..., float") ; /* optional */
values ("float, ..., float") ;
```

Group Statement

```
em_max_toggle_rate (em_template_name) {}
```

related_pin Simple Attribute

The `related_pin` attribute associates the `electromigration` group with a specific input pin. The input pin's input transition time is used as a variable in the `electromigration` lookup table.

If more than one input pin is specified in this attribute, the weighted input transition time of all input pins specified is used to index the `electromigration` table.

The pin or pins in the `related_pin` attribute denote the path dependency for the `electromigration` group. A particular `electromigration` group is accessed if the input pin or pins named in the `related_pin` attribute cause the corresponding output pin named in the `pin` group to toggle. All functionally related pins must be specified in a

`related_pin` attribute if you specify two-dimensional tables.

Syntax

```
related_pin : "name | name_list"
```

name | name_list

Name of input pin or pins.

Example

```
related_pin : "A B" ;
```

related_bus_pins Simple Attribute

The `related_bus_pins` attribute associates the `electromigration` group with the input pin or pins of a specific `bus` group. The input pin's input transition time is used as a variable in the electromigration lookup table.

If more than one input pin is specified in this attribute, the weighted input transition time of all input pins specified is used to index the electromigration table.

Syntax

```
related_bus_pins : "name1 [name2 name3 ... ]" ;
```

Example

```
related_bus_pins : "A" ;
```

The pin or pins in the `related_bus_pins` attribute denote the path dependency for the `electromigration` group. A particular `electromigration` group is accessed if the input pin or pins named in the `related_bus_pins` attribute cause the corresponding output pin named in the `pin` group to toggle. All functionally related pins must be specified in a `related_bus_pins` attribute if two-dimensional tables are being used.

when Simple Attribute

The `when` attribute defines the enabling condition for the check in Synopsys logic expression format.

Syntax

```
when : "Boolean expression" ;
```

Boolean expression

A Synopsys logic expression.

For a list of Boolean operators, see [Table 3-4](#).

Example

```
when : "SE" ;
```

index_1 and index_2 Complex Attributes

You can use the `index_1` optional attribute to specify the breakpoints of the first dimension of an electromigration table used to characterize cells for electromigration within the library. You can use the `index_2` optional attribute to specify breakpoints of the second dimension of an electromigration table used to characterize cells for electromigration within the library.

You can overwrite the values entered for the `em_lut_template` group's `index_1` by entering a value for the `em_max_toggle_rate` group's `index_1`. You can overwrite the value entered for the `em_lut_template` group's `index_2` by entering a value for the `em_max_toggle_rate` group's `index_2`.

Syntax

```
index_1 ("float, ..., float") ; /* optional */  
index_2 ("float, ..., float") ; /* optional */
```

float

For `index_1`, the floating-point numbers that specify the breakpoints of the first dimension of the electromigration table used to characterize cells for electromigration within the library. For `index_2`, the floating-point numbers that specify the breakpoints for the second dimension of the electromigration table used to characterize cells for electromigration within the library.

Example

```
index_1 ("0.0, 5.0, 20.0");
index_2 ("0.0, 1.0, 2.0");
```

values Complex Attribute

You use this complex attribute to specify the nets' maximum toggle rates.

Syntax

```
values : ("float, ..., float");
```

float

Floating-point numbers that specify the net's maximum toggle rates. The number can be a list of `nindex_1` positive floating-point numbers if the table is one-dimensional and can be `nindex_1` X `nindex_2` positive floating-point numbers if the table is two-dimensional, where `nindex_1` is the size of `index_1` and `nindex_2` is the size of `index_2`, specified for these two indexes in the `em_max_toggle_rate` group or in the `em_lut_template` group.

Example (One-Dimensional Table)

```
values : ("1.5, 1.0, 0.5");
```

Example (Two-Dimensional Table)

```
values : ("2.0, 1.0, 0.5", "1.5, 0.75, 0.33", "1.0, 0.5, 0.15",);
```

em_max_toggle_rate Group

The `em_max_toggle_rate` group is a pin-level group that is defined within the `electromigration` group.

```
library (name) {
  cell (name) {
    pin (name) {
      electromigration () {
        em_max_toggle_rate(em_template_name) {
          ... em_max_toggle_rate  description...
        }
      }
    }
  }
}
```

3.2.4 hyperbolic_noise_above_high Group

This optional group describes a noise immunity region as a hyperbolic curve when the input is high and the noise is over the high voltage rail.

You specify a `hyperbolic_noise_above_high` group in a `pin` group, as shown here:

```
library (name) {
  cell (name) {
    pin (name) {
      direction : input | inout ;
      hyperbolic_noise_above_high () {
        ... hyperbola  form  description ...
      }
    }
  }
}
```

Simple Attributes

```
area_coefficient  
height_coefficient  
width_coefficient
```

area_coefficient Simple Attribute

The `area_coefficient` attribute specifies the area coefficient used to describe a noise immunity curve in hyperbola form.

Syntax

```
area_coefficient: valuefloat;
```

value

A positive floating-point number. The unit is calculated as the library unit of voltage times the library unit of time.

Example

```
area_coefficient : 1.1 ;
```

height_coefficient Simple Attribute

The `height_coefficient` attribute specifies the height coefficient used to describe a noise immunity curve in hyperbola form.

Syntax

```
height_coefficient: valuefloat;
```

value

A positive floating-point number. The unit is the library unit of voltage.

Example

```
height_coefficient : 0.4 ;
```

width_coefficient Simple Attribute

The `width_coefficient` attribute specifies the width coefficient used to describe a noise immunity curve in hyperbola form.

Syntax

```
width_coefficient: valuefloat;
```

value

A positive floating-point number. The unit is the library unit of time.

Example

```
width_coefficient : 0.01 ;
```

Example

```
hyperbolic_noise_above_high () {  
    area_coefficient : 1.1 ;  
    height_coefficient : 0.4 ;  
    width_coefficient : 0.01 ;  
}
```

3.2.5 hyperbolic_noise_below_low Group

This optional group describes a noise immunity region as a hyperbolic curve when the input is low and the noise is below the low voltage rail.

For information about the group syntax and attributes, see "["hyperbolic_noise_above_high Group"](#)".

3.2.6 hyperbolic_noise_high Group

This optional group describes a noise immunity region as a hyperbolic curve when the input is high and the noise is below the high voltage rail.

For information about the group syntax and attributes, see "["hyperbolic_noise_above_high Group"](#)".

3.2.7 *hyperbolic_noise_low* Group

This optional group describes a noise immunity region as a hyperbolic curve when the input is low and the noise is over the low voltage rail.

For information about the group syntax and attributes, see "["hyperbolic_noise_above_high Group"](#)".

3.2.8 *internal_power* Group

An *internal_power* group is defined in a *pin* group, as shown here:

```
library (name) {
  cell (name) {
    pin (name) {
      internal_power () {
        ... internal power description ...
      }
    }
  }
}
```

Note:

Either braces {} or quotation marks " " are valid syntax for values specified in internal power tables.

Simple Attributes

```
equal_or_opposite_output
falling_together_group
power_level
related_pin
rising_together_group
switching_interval
switching_together_group
when
```

Group Statements

```
domain
fall_power (template name) {}
power (template name) {}
rise_power (template name) {}
```

Syntax for One-Dimensional, Two-Dimensional, and Three-Dimensional Tables

You can define a one-, two-, or three-dimensional table in the *internal_power* group in either of the following ways:

- Using the *power* group
- Using a combination of the *related_pin* attribute, the *fall_power* group, and the *rise_power* group
- Using a combination of the *related_pin* attribute, the *power* group, and the *equal_or_opposite* attribute.

Note:

Either braces {} or quotation marks " " are valid syntax for values specified in internal power tables.

This is the syntax for a one-dimensional table using the *power* group:

```
internal_power() {
  power (template name) {
    values ("float, ..., float");
  }
}
```

This is the syntax for a one-dimensional table using *fall_power*, and *rise_power*:

```

internal_power() {
    fall_power (template name) {
        values ("float, ..., float");
    }
    rise_power (template name) {
        values ("float, ..., float");
    }
}

```

This is the syntax for a two-dimensional table using the `power` group:

```

internal_power() {
    power (template name) {
        values ("float, ..., float");
    }
}

```

This is the syntax for a two-dimensional table using the `related_pin` attribute and the `fall_power` and `rise_power` groups:

```

internal_power() {
    related_pin : "name | name_list";
    fall_power (template name) {
        values ("float, ..., float");
    }
    rise_power (template name) {
        values ("float, ..., float");
    }
}

```

This is the syntax for a three-dimensional table using the `power` group:

```

internal_power() {
    power (template name) {
        values ("float, ..., float");
    }
}

```

This is the syntax for a three-dimensional table using the `related_pin` attribute, `power` group, and the `equal_or_opposite` attribute:

```

internal_power() {
    related_pin : "name | name_list";
    power (template name) {
        values ("float, ..., float");
    }
    equal_or_opposite_output : "name | name_list";
}

```

`equal_or_opposite_output` Simple Attribute

The `equal_or_opposite_output` attribute designates optional output pin or pins whose capacitance is used to access a three-dimensional table in the `internal_power` group.

Syntax

`equal_or_opposite_output : "name | name_list";`

`name | name_list`

The name of the output pin or pins.

Note:

This pin (or pins) has to be functionally equal to or opposite of the pin named in this `pin` group.

Example

`equal_or_opposite_output : "Q" ;`

Note:

The output capacitance of this pin (or pins) is used as the total `output2_net_capacitance` variable in the internal power

lookup table.

[falling_together_group Simple Attribute](#)

The `falling_together_group` attribute identifies the list of two or more input or output pins that share logic and are falling together during the same time period. This time period is set with the `switching_interval` attribute; see ["switching_interval Simple Attribute"](#) for details.

Together, the `falling_together_group` and `switching_interval` attribute settings determine the level of power consumption.

[Syntax](#)

```
falling_together_group : "list of pins" ;
```

list of pins

The names of the input or output pins that share logic and are falling during the same time period.

[Example](#)

```
cell (foo) {
    pin (A) {
        internal_power () {
            falling_together_group : "B C D" ;
            rising_together_group : "E F G" ;
            switching_interval : 10.0 ;
            rise_power () {
                ...
            }
            fall_power () {
                ...
            }
        }
    }
}
```

[power_level Simple Attribute](#)

This optional attribute is used for multiple power supply modeling. In the `internal_power` group at the pin level, you can specify the power level used to characterize the lookup table.

[Syntax](#)

```
power_level : "name" ;
```

name

Name of the power rail defined in the power supply group.

[Example](#)

```
power_level : "VDD1" ;
```

[related_pin Simple Attribute](#)

This attribute is used only in three-dimensional tables. It associates the `internal_power` group with a specific input or output pin. If `related_pin` is an output pin, it must be functionally equal to or opposite of the pin in that `pin` group.

If `related_pin` is an input pin, the pin's input transition time is used as a variable in the internal power lookup table.

If `related_pin` is an output pin, the pin's capacitance is used as a variable in the internal power lookup table.

[Syntax](#)

```
related_pin : "name | name_list" ;
```

name | name_list

The name of the input or output pin or pins.

Example

```
related_pin : "A B" ;
```

The pin or pins in the `related_pin` attribute denote the path dependency for the `internal_power` group. A particular `internal_power` group is accessed if the input pin or pins named in the `related_pin` attribute cause the corresponding output pin named in the `pin` group to toggle. All functionally related pins must be specified in a `related_pin` attribute if two-dimensional tables are being used.

rising_together_group Simple Attribute

The `rising_together_group` attribute identifies the list of two or more input or output pins that share logic and are rising during the same time period. This time period is defined with the `switching_interval` attribute; see [“switching_interval Simple Attribute”](#) for details.

Together, the `rising_together_group` attribute and `switching_interval` attribute settings determine the level of power consumption.

Syntax

```
rising_together_group : "list of pins" ;
```

list of pins

The names of the input or output pins that share logic and are rising during the same time period.

Example

```
cell (foo) {
    pin (A) {
        internal_power () {
            falling_together_group : "B C D" ;
            rising_together_group : "E F G" ;
            switching_interval : 10.0 ;
            rise_power () {
                ...
            }
            fall_power () {
                ...
            }
        }
    }
}
```

switching_interval Simple Attribute

The `switching_interval` attribute defines the time interval during which two or more pins that share logic are falling, rising, or switching (either falling or rising) during the same time period.

This attribute is set together with the `falling_together_group`, `rising_together_group`, or `switching_together_group` attribute. Together with one of these attributes, the `switching_interval` attribute defines a level of power consumption.

For details about the attributes that are set together with the `switching_interval` attribute, see [“falling_together_group Simple Attribute”](#), [“rising_together_group Simple Attribute”](#), and [“switching_together_group Simple Attribute”](#).

Syntax

```
switching_interval : valuefloat ;
```

value

A floating-point number that represents the time interval during which two or more pins that share logic are transitioning together.

Example

```
pin (Z) {
    direction : output;
```

```

internal_power () {
    switching_together_group : "A B";
    /*if pins A, B, and Z switch*/ ;
    switching_interval : 5.0;

        /* switching within 5 time units */
    power () {
        ...
    }
}

```

[switching_together_group Simple Attribute](#)

The `switching_together_group` attribute identifies a list of two or more input or output pins that share logic, are either falling or rising during the same time period, and are not affecting the power consumption.

The time period is defined with the `switching_interval` attribute. See "[switching_interval Simple Attribute](#)" for details.

[Syntax](#)

`switching_together_group : "list of pins";`

list of pins

The names of the input or output pins that share logic, are either falling or rising during the same time period, and are not affecting power consumption.

[when Simple Attribute](#)

The `when` attribute specifies the state-dependent condition that determines whether this power table is accessed.

You can use the `when` attribute to define one-, two-, or three-dimensional tables in the `internal_power` group. You can also use the `when` attribute in the `power`, `fall_power`, and `rise_power` groups.

Note:

If you want to use the same Boolean expression for multiple `when` statements in an `internal_power` group, you must specify a different power rail for each `internal_power` group.

[Syntax](#)

`when : "Boolean expression";`

Boolean expression

The name or names of the input and output pins with corresponding Boolean operators.

[Table 3-4](#) lists the Boolean operators valid in a `when` statement.

Table 3-4 Valid Boolean Operators

Operator	Description
'	invert previous expression
!	invert following expression
^	logical XOR
*	logical AND
&	logical AND
space	logical AND
+	logical OR
	logical OR
1	signal tied to logic 1
0	signal tied to logic 0

The order of precedence of the operators is left to right, with inversion performed first, then XOR, then AND, then OR.

Example

```
when : "A B" ;
```

fall_power Group

The `fall_power` group defines the power associated with a fall transition on a pin. You specify a `fall_power` group in an `internal_power` group in a `pin` group, as shown here.

```
cell (name_string) {
    pin (name_string) {
        internal_power () {
            fall_power (template name) {
                ... fall power description ...
            }
        }
    }
}
```

Complex Attributes

```
index_1 ("float, ..., float") ; /* lookup table */
index_2 ("float, ..., float") ; /* lookup table */
index_3 ("float, ..., float") ; /* lookup table */
values ("float, ..., float") ; /* lookup table */
orders("integer, ..., integer") ; /* polynomial */
coefs("float, ..., float") ; /* polynomial */
```

float

Floating-point numbers that identify the amount of energy per fall transition the cell consumes internally.

You convert the `values` attribute to power consumption by multiplying the unit by the factor transition or per-unit time, as follows:

- `nindex_1` floating-point numbers if the table is one-dimensional
- `nindex_1 × nindex_2` floating-point numbers if the table is two-dimensional
- `nindex_1 × nindex_2 × nindex_3` floating-point numbers if the table is three-dimensional

`nindex_1`, `nindex_2`, and `nindex_3` are the size of `index_1`, `index_2`, and `index_3` in this group or in the `power_lut_template` group it inherits. Quotation marks (" ") enclose a group. Each group represents a row in the table.

This power is accessed when the pin has a fall transition. If you have a `fall_power` group, you must have a `rise_power` group.

[Example 3-5](#) shows cells that contain internal power information in the `pin` group.

Group Statement

```
domain (name) {}
```

name

References a domain group defined in the `power_poly_template` group or the `power_lut_template` group.

power Group

Use the `power` group to define power when the rise power equals the fall power for a particular pin. You specify a `power` group within an `internal_power` group in a `pin` group at the cell level, as shown here:

Syntax

```
library (name) {
    cell (name) {
        pin (name) {
            internal_power () {
                power (template name) {
                    ... power template description ...
                }
            }
        }
    }
}
```

```

        }
    }
}
}
```

Complex Attributes

```

index_1 ("float, ..., float");
index_2 ("float, ..., float");
index_3 ("float, ..., float");
values ("float, ..., float");
orders ("integer, ..., integer"); /* polynomial */
coefs ("float, ..., float"); /* polynomial */
```

float

Floating-point numbers that identify the amount of energy per transition, either rise or fall, the cell consumes internally.

You convert the `values` attribute to power consumption by multiplying the unit by the factor transition or per-unit time, as follows:

- `nindex_1` floating-point numbers if the table is one-dimensional
- `nindex_1 × nindex_2` floating-point numbers if the table is two-dimensional
- `nindex_1 × nindex_2 × nindex_3` floating-point numbers if the table is three-dimensional

`nindex_1`, `nindex_2`, and `nindex_3` are the size of `index_1`, `index_2`, and `index_3` in this group or in the `power_lut_template` group it inherits. Quotation marks (" ") enclose a group. Each group represents a row in the table.

This power is accessed when the pin has a rise transition or fall transition. The values in the table specify the average power per transition.

[Example 3-5](#) shows cells that contain power information in the `internal_power` group in a `pin` group.

Group

```
domain (name) {}
```

name

References a domain group defined in the `power_poly_template` group or the `power_lut_template` group.

rise_power Group

The `rise_power` group defines the power associated with a rise transition on a pin. You specify a `rise_power` group in an `internal_power` group in a `pin` group, as shown here:

Syntax

```

cell (name) {
    pin (name) {
        internal_power () {
            rise_power (template name) {
                ... rise power description ...
            }
        }
    }
}
```

Complex Attributes

```

index_1 ("float, ..., float");
index_2 ("float, ..., float");
index_3 ("float, ..., float");
values ("float, ..., float");
orders ("integer, ..., integer"); /* polynomial */
coefs ("float, ..., float"); /* polynomial */
```

float

Floating-point numbers that identify the amount of energy per rise transition the cell consumes internally.

You convert the `values` attribute to power consumption by multiplying the unit by the factor transition or per-unit time, as follows:

- `nindex_1` floating-point numbers if the table is one-dimensional
- `nindex_1 × nindex_2` floating-point numbers if the table is two-dimensional
- `nindex_1 × nindex_2 × nindex_3` floating-point numbers if the table is three-dimensional

`nindex_1`, `nindex_2`, and `nindex_3` are the size of `index_1`, `index_2`, and `index_3` in this group or in the `power_lut_template` group it inherits. Quotation marks (" ") enclose a group. Each group represents a row in the table.

This power is accessed when the pin has a rise transition.

[Example 3-5](#) shows cells that contain internal power information in the `pin` group.

Group

```
domain (name) {}
```

`name`

References a domain group defined in either the `power_poly_template` group or the `power_lut_template` group.

[Example 3-5 A Library With Internal Power](#)

```
library(internal_power_example) {  
...  
power_lut_template(output_by_cap1_cap2_and_trans) {  
    variable_1 : total_output1_net_capacitance ;  
    variable_2 : equal_or_opposite_output_net_capacitance ;  
    variable_3 : input_transition_time ;  
    index_1 ("0.0, 5.0, 20.0") ;  
    index_2 ("0.0, 5.0, 20.0") ;  
    index_3 ("0.0, 1.0, 2.0") ;  
}  
  
power_lut_template(output_by_cap_and_trans) {  
    variable_1 : total_output_net_capacitance ;  
    variable_2 : input_transition_time ;  
    index_1 ("0.0, 5.0, 20.0") ;  
    index_2 ("0.0, 1.0, 2.0") ;  
}  
...  
power_lut_template(input_by_trans) {  
    variable_1 : input_transition_time ;  
    index_1 ("0.0, 1.0, 2.0") ;  
}  
  
cell(AN2) {  
    pin(Z) {  
        direction : output;  
        internal_power() {  
            power (output_by_cap_and_trans) {  
                values ("2.2, 3.7, 4.3", "1.7, 2.1, 3.5", "1.0, 1.5, 2.8");  
            }  
            related_pin : "A B" ;  
        }  
    }  
...  
    pin(A) {  
        direction : input ;  
        ...  
    }  
    pin(B) {  
        direction : input ;  
        ...  
    }  
}  
cell(FLOP1) {  
    pin(CP) {  
        direction : input ;  
        internal_power() {  
            power (input_by_trans) {  
                values ("1.5, 2.5, 4.7") ;  
            }  
        }  
    }  
}
```

```

    }
    pin(D) {
        direction : input ;
        ...
    }
    pin(S) {
        direction : input ;
        ...
    }
    pin(R) {
        direction : input ;
        ...
    }
    pin(Q) {
        direction : output ;
        internal_power() {
            power (output_by_cap1_cap2_and_trans) {
                values ("2.2, 3.7, 4.3", "1.7, 2.1, 3.5", "1.0, 1.5, 2.8", \
                    "2.1, 3.6, 4.2", "1.6, 2.0, 3.4", "0.9, 1.5, 2.7", \
                    "2.0, 3.5, 4.1", "1.5, 1.9, 3.3", "0.8, 1.4, 2.6");
            }
            when : "S' + R'" ;
            equal_or_opposite_output : "QN" ;
            related_pin : "CP" ;
        }
    }
    internal_power() {
        power (output_by_cap_and_trans) {
            values ("1.8, 3.4, 4.0", "1.5, 1.9, 3.3", "0.8, 1.3, 2.5");
        }
        related_pin : "S R" ;
    }
    ...
}
pin(QN) {
    direction : output ;
    internal_power() {
        rise_power (output_by_cap_and_trans) {
            values ("0.5, 0.9, 1.3", "0.3, 0.7, 1.1", "0.2, 0.5, 0.9");
        }
        fall_power (output_by_cap_and_trans) {
            values ("0.1, 0.7, 0.9", "-0.1, 0.2, 0.4", "-0.2, 0.2, 0.3");
        }
        related_pin : "S R" ;
    }
    ...
}
...
}

```

3.2.9 max_cap Group

The `max_cap` group defines the frequency-based maximum capacitance information for the output and inout pins.

Syntax

```

library (name) {
    cell (name) {
        pin (name) {
            max_cap (template name) {
                ... capacitance description ...
            }
        }
    }
}

```

template_name

A value representing the name of a `maxcap_lut_template` group. You need to specify or remove an attribute from the group according to the template. The supported attributes for the template are `frequency` and `input_transition_time`. Because `input_transition_time` is the second index attribute, a `related_pin` attribute is required to inform the transition of the corresponding input pin. The template can be one-dimensional or two-dimensional. A one-dimensional template does not allow the `related_pin` attribute. A two-dimensional template requires the `related_pin` attribute.

Example

```
max_cap ( ) {
    maxcap_lut_template(maxcap_table) {
        variable_1 : frequency ;
        variable_2 : input_transition_time ;
        index_1("0.01, 0.1, 1.0");
        index_2("0, 0.5, 1.5, 2.0");
    }
    ...
    pin(Y) {
        direction : output ;
        max_fanout : 7 ;
        function : "(A+B)" ;
        max_cap(maxcap_table) {
            values("1.1, 1.2, 1.3, 1.4", \
                "1.2, 1.3, 1.4, 1.5", \
                "1.3, 1.4, 1.5, 1.6") ;
            related_pin : A ;
        }
    }
    ...
}
```

3.2.10 max_trans Group

Use the `max_trans` group to describe the maximum transition information for output and inout pins.

Syntax

```
library (name) {
    cell (name) {
        pin (name) {
            max_trans ( template_nameid ) {
                ... transition description ...
            }
        }
    }
}

template_name
```

A value representing the name of a `maxtrans_lut_template` group.

Complex Attributes

```
variable_1_range
variable_2_range
variable_n_range
orders
coefs
```

Example

```
max_trans ( ) {
    ...
}
```

3.2.11 min_pulse_width Group

In a `pin`, `bus`, or `bundle` group, the `min_pulse_width` group models the enabling conditional minimum pulse width check. In the case of a pin, the timing check is performed on the pin itself, so the related pin must be the same.

Syntax

```
pin() {
    ...
    min_pulse_width() {
        constraint_high : value ;
        constraint_low : value ;
        when : "Boolean expression" ;
        /* enabling condition */
    }
}
```

```
    sdf_cond : "Boolean expression" ;
    /* in SDF syntax */
}
}
```

Example

```
pin(A) {
    ...
    min_pulse_width() {
        constraint_high : 3.0 ;
        constraint_low : 3.5 ;
        when : "SE" ;
        sdf_cond : "SE == 1'B1" ;
    }
}
```

Simple Attributes

constraint_high
constraint_low
when
sdf_cond

constraint_high Simple Attribute

The `constraint_high` attribute defines the minimum length of time the pin must remain at logic 1. You define a value for either `constraint_high`, `constraint_low`, or both in the `min_pulse_width` group.

Syntax

```
constraint_high : valuefloat ;
```

value

A nonnegative number.

Example

```
constraint_high : 3.0 ; /* min_pulse_width_high */
```

when Simple Attribute

The `when` attribute defines the enabling condition for the check in Synopsys logic expression format.

Syntax

```
when : "Boolean expression" ;
```

Boolean expression

A logic expression.

For a list of Boolean operators, see [Table 3-4](#).

Example

```
when : "SE" ;
```

constraint_low Simple Attribute

The `constraint_low` attribute defines the minimum length of time the pin must remain at logic 0. You define a value for either `constraint_low`, `constraint_high`, or both in the `min_pulse_width` group.

Syntax

```
constraint_low : valuefloat ;
```

value

A nonnegative number.

Example

```
constraint_low : 3.5 ; /* min_pulse_width_low */
```

sdf_cond Simple Attribute

The `sdf_cond` attribute defines the enabling condition for the check in Open Verilog International (OVI) Standard Delay Format (SDF) 2.1 syntax.

Syntax

```
sdf_cond : "Boolean expression" ;
```

Boolean expression

An SDF condition expression.

Example

```
sdf_cond : "SE == 1'B1" ;
```

3.2.12 minimum_period Group

In a `pin`, `bus`, or `bundle` group, the `minimum_period` group models the enabling conditional minimum period check. In the case of a pin, the check is performed on the pin itself, so the related pin must be the same.

If the `pin` group contains a `minimum_period` group and a `min_period` attribute, the `min_period` attribute is ignored.

Syntax

```
minimum_period() {  
    constraint : value;  
    when : "Boolean expression";  
    sdf_cond : "Boolean expression";  
}
```

Simple Attributes

```
constraint  
when  
sdf_cond
```

constraint Simple Attribute

This required attribute defines the minimum clock period for the pin.

Syntax

```
constraint : valuefloat ;
```

value

A nonnegative number.

Example

```
constraint : 9.5 ;
```

when Simple Attribute

This required attribute defines the enabling condition for the check in Synopsys logic expression format.

Syntax

```
when : "Boolean expression" ;
```

Boolean expression

A logic expression.

For a list of Boolean operators, see [Table 3-4](#).

Example

```
when : "SE" ;
```

sdf_cond Simple Attribute

This required attribute defines the enabling condition for the check in OVI SDF 2.1 syntax.

Syntax

```
sdf_cond : "Boolean expression" ;
```

Boolean expression

An SDF condition expression.

Example

```
sdf_cond : "SE == 1'b1" ;
```

3.2.13 pin_capacitance Group

In a `pin` group, the `pin_capacitance` group supports polynomial equation modeling to represent capacitance, rise_capacitance, fall_capacitance, rise_capacitance_range, and fall_capacitance_range.

The existing single value capacitance, rise_capacitance, fall_capacitance, rise_capacitance_range and fall_capacitance_range attributes and the new `pin_capacitance` group can co-exist on one pin. The syntax for the `pin_capacitance` group is the same used for the delay model, except that the variables used in the format are temperature and voltage (including power rails).

The `pin_capacitance` group supports only the scalable polynomial delay model.

Note:

The capacitance group is required in the `pin_capacitance` group.

Group Statements

```
capacitance  
rise_capacitance  
fall_capacitance  
fall_capacitance_range  
rise_capacitance _range
```

Syntax

```
pin_capacitance() {...pin_capacitance description ...}  
}
```

capacitance Group

Use the `capacitance` group to define the load of an input, output, inout, or internal pin. This group is required in the `pin_capacitance` group.

Syntax

```
capacitance() {...capacitance description ...}
```

Example

```
capacitance(cap) {  
    orders ("1 , 1");  
    coeffs ("1, 2, 3, 4");  
}
```

[fall_capacitance Group](#)

Use the `fall_capacitance` group to define the load of an input, output, inout, or internal pin when its signal is falling. You must set a value for both the `rise_capacitance` and `fall_capacitance` groups.

The value you set for a `fall_capacitance` group overrides the value you set for a `fall_capacitance simple` attribute.

[Syntax](#)

```
fall_capacitance() {...capacitance description ...}
```

[Example](#)

```
fall_capacitance(fall_cap) {  
    orders ("1 , 1");  
    coefs ("1, 2, 3, 4");  
}
```

[rise_capacitance Group](#)

Use the `rise_capacitance` group to define the load of an input, output, inout, or internal pin when its signal is rising. For more information, see [“fall_capacitance Group”](#).

[fall_capacitance_range Group](#)

This group describes the range for temperature and voltage (including voltage rails) during fall transitions. Only one `fall_capacitance_range` or `rise_capacitance_range` group is allowed inside the `pin_capacitance` group. The rise and fall capacitance range groups are optional.

[Syntax](#)

```
fall_capacitance_range() {... values description ...}
```

[Groups](#)

lower upper

[lower Group](#)

For `pin_capacitance`, use this group to specify a range of minimum and maximum float values or polynomials as a function of temperature and voltage (including power rails).

You must define both the `lower` and `upper` groups in a `rise_capacitance_range` or `fall_capacitance_range` group.

[Syntax](#)

```
lower (poly_template_name_id) {... values description ...}
```

[Example](#)

```
lower(cap) {  
    ...  
    orders ("1 , 1");  
    coefs ("1, 2, 3, 4");  
}
```

[Complex Attributes](#)

```
variable_1_range  
variable_2_range  
variable_n_range  
orders  
coefs
```

[variable_n_range Complex Attribute](#)

Use the `variable_n_range` attribute to specify the range of the value for the n th variable in the `variables` attribute.

Syntax

```
variable_n_range(min_1float, max_2float);
```

`min, max`

Floating-point number pairs that specify the value range.

Example

```
fall_capacitance_range () {
    lower(cap) {
        ...
        orders ("1 , 1");
        coefs ("1, 2, 3, 4");
    }
    upper(cap) {
        ...
        orders ("1 , 1");
        coefs ("1, 2, 3, 4");
    }
}
```

coefs Complex Attribute

Use the `coefs` attribute to specify a list of the coefficients you use in a polynomial. For more information, see "["coefs Complex Attribute"](#)".

orders Complex Attribute

Use the `orders` attribute to specify the order for the variables for the polynomial. For more information, see "["orders Complex Attribute"](#)".

upper Group

For `pin_capacitance`, use this group to specify a range of minimum and maximum float values or polynomials as a function of temperature and voltage (including power rails). For more information, see "["lower Group"](#)".

rise_capacitance_group Group

This group describes the range of pin capacitance as a function of temperature and voltage (including voltage rails) during rise transitions for the signal. For more information, see "["fall_capacitance_group Group"](#)".

Example

[Example 3-6](#) shows a sample library with extended `rise_capacitance_range` and `fall_capacitance_range` syntax.

Example 3-6 Sample Library With pin_capacitance Group Values

```
library(new_lib) {
    ...
    poly_template (PPT) {
        variables ("temperature", "voltage");
        variable_1_range (-40.0, 100.0);
        variable_2_range (0.5, 3.5);
        domain (D1) {
            calc_mode : best ;
        }
        domain (D2) {
            calc_mode : worst ;
        }
    }
    ...
    cell(AN2){
        pin(Y) {
            ...
            pin_capacitance() {
                /* default poly capacitance */
                capacitance(PPT) {

```

```

orders ("1, 1");
coefs ("0.11, 0.12, 0.13, 0.14");
domain (D1) {
    orders ("1, 1");
    coefs ("0.21, 0.22, 0.23, 0.24");
}
domain (D2) {
    orders ("1, 1");
    coefs ("0.31, 0.32, 0.33, 0.34");
}
rise_capacitance(PPT) {
    orders ("1, 1");
    coefs ("0.11, 0.12, 0.13, 0.14");
    domain (D1) {
        orders ("1, 1");
        coefs ("0.21, 0.22, 0.23, 0.24");
    }
    domain (D2) {
        orders ("1, 1");
        coefs ("0.31, 0.32, 0.33, 0.34");
    }
}
fall_capacitance(PPT) {
    orders ("1, 1");
    coefs ("0.11, 0.12, 0.13, 0.14");
    domain (D1) {
        orders ("1, 1");
        coefs ("0.21, 0.22, 0.23, 0.24");
    }
    domain (D2) {
        orders ("1, 1");
        coefs ("0.31, 0.32, 0.33, 0.34");
    }
}
rise_capacitance_range() {
    lower(PPT) {
        orders ("1, 1");
        coefs ("0.01, 0.02, 0.03, 0.04");
        domain (D1) {
            orders ("1, 1");
            coefs ("0.11, 0.12, 0.13, 0.14");
        }
        domain (D2) {
            orders ("1, 1");
            coefs ("0.21, 0.22, 0.23, 0.24");
        }
    }
    upper(PPT) {
        orders ("1, 1");
        coefs ("0.21, 0.22, 0.23, 0.24");
        domain (D1) {
            orders ("1, 1");
            coefs ("0.31, 0.32, 0.33, 0.34");
        }
        domain (D2) {
            orders ("1, 1");
            coefs ("0.41, 0.42, 0.43, 0.44");
        }
    }
}
fall_capacitance_range() {
    lower(PPT) {
        orders ("1, 1");
        coefs ("0.01, 0.02, 0.03, 0.04");
        domain (D1) {
            orders ("1, 1");
            coefs ("0.11, 0.12, 0.13, 0.14");
        }
        domain (D2) {
            orders ("1, 1");
            coefs ("0.21, 0.22, 0.23, 0.24");
        }
    }
    upper(PPT) {
        orders ("1, 1");
    }
}

```

3.2.14 receiver_capacitance Group

Use the `receiver_capacitance` group to specify capacitance values for composite current source (CCS) receiver modeling at the pin level.

Syntax

```
library (namestring) {  
    cell (namestring) {  
        pin (namestring) {  
            receiver_capacitance (){  
                ... description ...  
            }  
        }  
    }  
}
```

Groups

```
receiver_capacitance1_fall  
receiver_capacitance1_rise  
receiver_capacitance2_fall  
receiver_capacitance2_rise
```

receiver_capacitance1_fall Group

You can define the `receiver_capacitance1_fall` group at the pin level and the timing level. Define the `receiver_capacitance1_fall` group at the pin level to reference a composite current source (CCS) template. For information about using the group at the timing level, see “[“receiver_capacitance1_fall Group”](#)”.

Syntax

```
receiver_capacitance1_fall (lu_template_nameid) {
```

lu_template_name

The name of a template.

Complex Attribute

values

Example

```
    receiver_capacitance () {
        receiver_capacitance1_rise (LTT1) {
            values (0.0, 0.0, 0.0, 0.0);
        }
        receiver_capacitance1_fall (LTT1) {
            ...
        }
        ...
    }
}
```

receiver_capacitance1_rise Group

For information about using the receiver_capacitance1_rise group, see the description of the .”

receiver_capacitance2_fall Group

For information about using the receiver_capacitance2_fall group, see the description of .”

receiver_capacitance2_rise Group

For information about using the receiver_capacitance2_rise group, see the description of .”

when Attribute

The when string attribute is provided in the pin-based receiver_capacitance group to support conditional data modeling.

mode Attribute

The complex mode attribute is provided in the pin-based receiver_capacitance group to support conditional data modeling. If the mode attribute is specified, mode_name and mode_value must be predefined in the mode_definition group at the cell level.

3.2.15 timing Group in a pin Group

A timing group is defined within a pin group, as shown here. Note that the syntax presents the attributes in alphabetical order by type of attribute.

Entering the names in the timing group attribute to identify timing arcs is optional.

Syntax

```
library (name_string) {
  cell (name_string) {
    pin (name_string) {
      timing (name_string){
        ... timing description ...
      }
    }
  }
}
```

Simple Attributes

```
clock_gating_flag : true|false ;
default_timing : true|false ;
fall_resistance : float ;
fpga_arc_condition : "Boolean   expression" ;
fpga_domain_style : name ;
interdependence_id : integer ;
intrinsic_fall : float ;
intrinsic_rise : float ;
related_bus_equivalent : " name1 [name2 name3 ... ] " ;
related_bus_pins : " name1 [name2 name3 ... ] " ;
related_output_pin : name ;
related_pin: " name1 [name2 name3 ... ] " ;
rise_resistance : float ;
sdf_cond : "SDF   expression" ;
sdf_cond_end : "SDF   expression" ;
sdf_cond_start : "SDF   expression" ;
sdf_edges : SDF   edge   type ;
slope_fall : float ;
slope_rise : float ;
steady_state_resistance_above_high : float ;
steady_state_resistance_below_low : float ;
steady_state_resistance_high : float ;
steady_state_resistance_low : float ;
tied_off: Boolean ;
timing_sense : positive_unate| negative_unate| non_unate;
timing_type : combinational | combinational_rise |
  combinational_fall | three_state_disable |
```

```

three_state_disable_rise | three_state_disable_fall |
three_state_enable | three_state_enable_rise |
three_state_enable_fall | rising_edge | falling_edge |
preset | clear | hold_rising | hold_falling |
setup_rising | setup_falling | recovery_rising |
recovery_falling | skew_rising | skew_falling |
removal_rising | removal_falling | min_pulse_width |
minimum_period | max_clock_tree_path |
min_clock_tree_path | non_seq_setup_rising |
non_seq_setup_falling | non_seq_hold_rising |
non_seq_hold_falling | nochange_high_high |
nochange_high_low | nochange_low_high |
nochange_low_low ;
when : "Boolean expression" ;
when_end : "Boolean expression" ;
when_start : "Boolean expression" ;

```

Complex Attributes

```

fall_delay_intercept (integer, float) ; /* piecewise model only */
fall_pin_resistance (integer, float) ; /* piecewise model only */
mode
rise_delay_intercept (integer, float) ; /* piecewise model only */
rise_pin_resistance (integer, float) ; /* piecewise model only */

```

Group Statements

```

cell_degradation () { }
cell_fall () { }
cell_rise () { }
fall_constraint () { }
fall_propagation () { }
fall_transition () { }
noise_immunity_above_high () { }
noise_immunity_below_low () { }
noise_immunity_high () { }
noise_immunity_low () { }
output_current_fall () { }
output_current_rise () { }
propogated_noise_height_above_high () { }
propogated_noise_height_below_low () { }
propogated_noise_height_high () { }
propogated_noise_height_low () { }
propogated_noise_peak_time_ratio_above_high () { }
propogated_noise_peak_time_ratio_below_low () { }
propogated_noise_peak_time_ratio_high () { }
propogated_noise_peak_time_ratio_low () { }
propogated_noise_width_above_high () { }
propogated_noise_width_below_low () { }
propogated_noise_width_high () { }
propogated_noise_width_low () { }
receiver_capacitance1_fall () { }
receiver_capacitance1_rise () { }
receiver_capacitance2_fall () { }
receiver_capacitance2_rise () { }
retaining_fall () { }
retaining_rise () { }
retain_fall_slew () { }
retain_rise_slew () { }
rise_constraint () { }
rise_propagation () { }
rise_transition () { }
steady_state_current_high () { }
steady_state_current_low () { }
steady_state_current_tristate () { }

```

clock_gating_flag Simple Attribute

Use this attribute to indicate that a constraint arc is for a clock gating relation between the data and clock pin, instead of a constraint found in standard sequential devices, such as registers and latches.

Syntax

```
clock_gating_flag : Boolean ;
```

Boolean

Valid values are true and false. The value true is applicable only when the value of the timing_type attribute is setup, hold, or nochange. When not defined for a timing arc, the value false is assumed, indicating the timing arc is part of a standard sequential device.

Example

```
clock_gating_flag : true ;
```

default_timing Simple Attribute

The default_timing attribute allows you to specify one timing arc as the default in the case of multiple timing arcs with when statements.

Syntax

```
default_timing : Boolean expression ;
```

Example

```
default_timing : true ;
```

fall_resistance Simple Attribute

The fall_resistance attribute represents the load-dependent output resistance, or drive capability, for a logic 1-to-0 transition.

Note:

You cannot specify a resistance unit in the library. Instead, the resistance unit is derived from the ratio of the time_unit value to the capacitive_load_unit value.

Syntax

```
fall_resistance : value_float ;
```

value

A positive floating-point number in terms of delay time per load unit.

Example

```
fall_resistance : 0.18 ;
```

fpga_arc_condition Simple Attribute

The fpga_arc_condition attribute specifies a Boolean condition that enables a timing arc.

Syntax

```
fpga_arc_condition : conditionBoolean ) ;
```

condition

Specifies a Boolean condition. Valid values are true and false.

Example

```
fpga_arc_condition : ;
```

fpga_domain_style Simple Attribute

Use this attribute to reference a calc_mode value in a domain group in a polynomial table.

Syntax

```
fpga_domain_style : "name_id" ;
```

name

The calc_mode value.

Example

```
fpga_domain_style : "speed" ;
```

interdependence_id Simple Attribute

Use pairs of interdependence_id attributes to identify interdependent pairs of setup and hold constraint tables. Interdependence data is supported in conditional constraint checking; the interdependence_id attribute increases independently for each condition. Interdependence data can be specified in pin, bus, and bundle groups.

Syntax

```
interdependence_id : "name_enum" ;
```

name

Valid values are 1, 2, 3, and so on.

Examples

```
timing()
  related_pin : CLK ;
  timing_type: setup_rising ;
  interdependence_id : 1 ;
  ...
timing()
  related_pin : CLK ;
  timing_type: setup_rising ;
  interdependence_id : 2 ;

...
pin (D_IN) {
  ...
/* original non-conditional setup/hold constraints */
setup/hold constraints
/* new interdependence data for non-conditional constraint
checking */
setup/hold, interdependent_id = 1
setup/hold, interdependent_id = 2
setup/hold, interdependent_id = 3

/* original setup/hold constraints for conditional
<condition_a> */
setup/hold when <condition_a>
/* new interdependence data for <condition_a> constraint
checking */
setup/hold when <condition_a>, interdependent_id = 1
setup/hold when <condition_a>, interdependent_id = 2
setup/hold when <condition_a>, interdependent_id = 3

/* original setup/hold constraints for conditional
<condition_b> */
setup/hold when <condition_b>
/* new interdependence data for <condition_b> constraint
checking */
setup/hold when <condition_b>, interdependent_id = 1
setup/hold when <condition_b>, interdependent_id = 2
setup/hold when <condition_b>, interdependent_id = 3
}
```

Guidelines:

- To prevent potential backward-compatibility issues, interdependence data cannot be the first timing arc in the pin group.
- The `interdependence_id` attribute only supports the following timing types: `setup_rising`, `setup_falling`, `hold_rising`, and `hold_falling`. If you set this attribute on other timing types, an error is reported.
- You must specify setup and hold interdependence data in pairs; otherwise an error is reported. If you define one `setup_rising` timing arc with `interdependence_id: 1`; on a pin, you must also define a `hold_rising` timing arc with `interdependence_id: 1`; for that pin. The `interdependence_id` could be a random integer, but it must be found in a pair of timing arcs. These timing types are considered as pairs: `setup_rising` with `hold_rising` and `setup_falling` with `hold_falling`.
- For each set of conditional constraints (non-conditional categorized as a special condition), a timing arc with a specific `interdependence_id` should be unique in a pin group.
- For each set of conditional constraints, the `interdependence_id` must start from 1, and if there is multiple interdependence data defined, the values for the `interdependence_id` should be in consecutive order. That is, 1, 2, 3 is allowed, but 1, 2, 4 is not.

`intrinsic_fall` Simple Attribute

On an output pin, `intrinsic_fall` defines the 1-to-Z propagation time for a three-state-disable timing type and the Z-to-0 propagation time for a three-state-enable timing type.

On an input pin, `intrinsic_fall` defines a setup, hold, or recovery timing requirement for a logic 1-to-0 transition.

With `intrinsic_rise`, `intrinsic_fall` defines timing checks (rising and falling transitions).

Syntax

```
intrinsic_fall : valuefloat ;  
  
value  
A floating-point number that represents a timing requirement.
```

Example

```
intrinsic_fall : 0.75 ;
```

`intrinsic_rise` Simple Attribute

On an output pin, `intrinsic_rise` defines the 0-to-Z propagation time for a three-state-disable timing type and a Z-to-1 propagation time for a three-state-enable timing type.

On an input pin, `intrinsic_rise` defines a setup, hold, or recovery timing requirement for a logic 0-to-1 transition.

With `intrinsic_fall`, `intrinsic_rise` defines timing checks (rising and falling transitions).

Syntax

```
intrinsic_rise : valuefloat ;  
  
value  
A floating-point number that represents a timing requirement.
```

Example

```
intrinsic_rise : 0.17 ;
```

`related_bus_equivalent` Simple Attribute

The `related_bus_equivalent` attribute generates a single timing arc for all paths from points in a group through an internal pin (I) to given endpoints.

Syntax

```
related_bus_equivalent : " name1 [name2 name3 ... ] " ;
```

Example

```
related_bus_equivalent : a ;
```

[Example 3-7](#) shows an example using equivalent bus pins.

Example 3-7 Equivalent Bus Pins

```
cell(acell) {
  ...
  bus(y) {
    bus_type : bus4;
    direction : output;
    timing() {
      related_bus_equivalent : a;
      ...
    }
  }
  bus(a) {
    bus_type : bus4;
    direction : input;
    ...
  }
}
```

related_bus_pins Simple Attribute

The `related_bus_pins` attribute defines the pin or pins that are the startpoint of the timing arc. The primary use of `related_bus_pins` is for module generators.

Note:

When a `related_bus_pins` attribute is within a `timing` group, the `timing` group must be within a `bus` or `bundle` group.

Syntax

```
related_bus_pins : "name1 [name2 name3 ...]" ;
```

Example

```
related_bus_pins : "A" ;
```

related_output_pin Simple Attribute

The `related_output_pin` attribute specifies the output or inout pin used to describe a load-dependent constraint. This is an attribute in the `timing` group of the output or inout pin. The pin defined must be a pin in the same cell, and its direction must be either output or inout.

Syntax

```
related_output_pin : name ;
```

Example

```
related_output_pin : z ;
```

related_pin Simple Attribute

The `related_pin` attribute defines the pin or pins representing the beginning point of the timing arc. It is required in all `timing` groups.

Syntax

```
related_pin : "name1 [name2 name3 ...]" ;
```

In a cell with input pin A and output pin B, define A and its relationship to B in the `related_pin` attribute statement in the `timing` group that describes pin B.

Example

```

pin (B){
    direction : output ;
    function : "A'";
    timing () {
        related_pin : "A" ;
        ... timing information ...
    }
}

```

The `related_pin` attribute statement can also serve as a shortcut for two identical timing arcs for a cell. For example, in a 2-input NAND gate with identical delays from both input pins to the output pin, it is necessary to define only one timing arc with two related pins.

Example

```

pin (Z) {
    direction : output;
    function : "(A * B)'";
    timing () {
        related_pin : "A B" ;
        ... timing information ...
    }
}

```

When a bus name appears in a `related_pin` attribute, the bus members or range of members is distributed across all members of the parent bus. The width of the bus or the range must be the same as the width of the parent bus.

Pin names used in a `related_pin` statement can start with a nonalphabetic character.

Example

```
related_pin : "A 1B 2C" ;
```

Note:

It is not necessary to use the escape character, \ (backslash), with nonalphabetic characters.

rise_resistance Simple Attribute

The `rise_resistance` attribute represents the load-dependent output resistance, or drive capability, for a logic 0-to-1 transition.

Note:

You cannot specify a resistance unit in the library. Instead, the resistance unit is derived from the ratio of the `time_unit` value to the `capacitive_load_unit` value.

Syntax

```
rise_resistance : valuefloat ;
```

value

A positive floating-point number in terms of delay time per load unit.

Example

```
rise_resistance : 0.15 ;
```

sdf_cond Simple Attribute

The `sdf_cond` attribute is defined in the state-dependent `timing` group to support SDF file generation and condition matching during back-annotation.

Syntax

```
sdf_cond : "SDF expression" ;
```

SDF expression

A string that represents a Boolean description of the state dependency of the delay. Use a Boolean description that conforms to the valid syntax defined in the OVI SDF, which is different from the Synopsys Boolean expression syntax. For a complete description of the valid syntax for these expressions, refer to the OVI specification for SDF, v1.0.

Example

```
sdf_cond : "b == 1'b1" ;
```

sdf_cond_end Simple Attribute

The `sdf_cond_end` attribute defines a timing-check condition specific to the end event in VHDL models. The expression must conform to OVI SDF 2.1 timing-check condition syntax.

Syntax

```
sdf_cond_end : "SDF expression" ;
```

SDF expression

An SDF expression containing names of input, output, inout, and internal pins.

Example

```
sdf_cond_end : "SIG_0 == 1'b1" ;
```

sdf_cond_start Simple Attribute

The `sdf_cond_start` attribute defines a timing-check condition specific to the start event in full-timing gate-level simulation (FTGS) models. The expression must conform to OVI SDF 2.1 timing-check condition syntax.

Syntax

```
sdf_cond_start : "SDF expression" ;
```

SDF expression

An SDF expression containing names of input, output, inout, and internal pins.

Example

```
sdf_cond_start : "SIG_2 == 1'b1" ;
```

sdf_edges Simple Attribute

The `sdf_edges` attribute defines the edge specification on both the start pin and the end pin. The default is noedge.

Syntax

```
sdf_edges : sdf_edge_type;
```

sdf_edge_type

One of these four edge types: noedge, start_edge, end_edge, or both_edges. The default is noedge.

Example

```
sdf_edges : both_edges;
sdf_edges : start_edge; /* edge specification on starting pin */
sdf_edges : end_edge; /* edge specification on end pin */
```

sensitization_master Simple Attribute

The `sensitization_master` attribute defines the sensitization group specific to the current timing group to generate stimulus for characterization. The attribute is optional when the sensitization master used for the timing arc is the same as that defined in the current cell. It is required when they are different. Any sensitization group name predefined

in the current library is a valid attribute value.

Syntax

```
sensitization_master : sensitization_group_name;
```

sensitization_group_name

A string identifying the `sensitization` group name predefined in the current library.

Example

```
sensitization_master : sensi_2in_1out;
```

slope_fall Simple Attribute

The `slope_fall` attribute represents the incremental delay to add to the slope of the input waveform for a logic 1-to-0 transition.

Syntax

```
slope_fall : valuefloat;
```

value

A positive floating-point number multiplied by the transition delay resulting in slope delay.

Example

```
slope_fall : 0.8 ;
```

slope_rise Simple Attribute

The `slope_rise` attribute represents the incremental delay to add to the slope of the input waveform for a logic 0-to-1 transition.

Syntax

```
slope_rise : valuefloat;
```

value

A positive floating-point number multiplied by the transition delay resulting in slope delay.

Example

```
slope_rise : 1.0 ;
```

steady_state_resistance_above_high Simple Attribute

The `steady_state_resistance_above_high` attribute specifies a steady-state resistance value for a region of a current-voltage (I-V) curve when the output is high and the noise is over the high voltage rail.

Syntax

```
steady_state_resistance_above_high : valuefloat;
```

value

A positive floating-point number that represents the resistance. The resistance unit is a function of the unit of time divided by the library unit of capacitance.

Example

```
steady_state_resistance_above_high : 200 ;
```

steady_state_resistance_below_low Simple Attribute

The `steady_state_resistance_below_low` attribute specifies a steady-state resistance value for a region of a

current-voltage (I-V) curve when the output is low and the noise is below the low voltage rail.

Syntax

```
steady_state_resistance_below_low : valuefloat ;
```

value

A positive floating-point number that represents the resistance. The resistance unit is a function of the unit of time divided by the library unit of capacitance.

Example

```
steady_state_resistance_below_low : 100 ;
```

steady_state_resistance_high Simple Attribute

The `steady_state_resistance_high` attribute specifies a steady-state resistance value for a region of a current-voltage (I-V) curve when the output is high and the noise is below the high voltage rail.

Syntax

```
steady_state_resistance_high : valuefloat ;
```

value

A positive floating-point number that represents the resistance. The resistance unit is a function of the unit of time divided by the library unit of capacitance.

Example

```
steady_state_resistance_high : 1500 ;
```

steady_state_resistance_low Simple Attribute

The `steady_state_resistance_low` attribute specifies a steady-state resistance value for a region of a current-voltage (I-V) curve when the output is low and the noise is over the low voltage rail.

Syntax

```
steady_state_resistance_low : valuefloat ;
```

value

A positive floating-point number that represents the resistance. The resistance unit is a function of the unit of time divided by the library unit of capacitance.

Example

```
steady_state_resistance_low : 1100 ;
```

tied_off Simple Attribute

Used for noise modeling, the `tied_off` attribute allows you to specify the I-V characteristics and steady-state resistance values on tied-off cells.

Syntax

```
tied_off : Boolean ;
```

Boolean

Valid values are true and false.

Example

```
tied_off : true ;
```

timing_sense Simple Attribute

The `timing_sense` attribute describes the way an input pin logically affects an output pin.

Syntax

```
timing_sense : positive_unate | negative_unate  
| non_unate ;
```

positive_unate

Combines incoming rise delays with local rise delays and compares incoming fall delays with local fall delays.

negative_unate

Combines incoming rise delays with local fall delays and compares incoming fall delays with local rise delays.

non_unate

Combines local delays with the worst-case incoming delay value. The non-unate timing sense represents a function whose output value change cannot be determined from the direction of the change in the input value.

Timing sense is derived from the logic function of a pin. For example, the value derived for an AND gate is `positive_unate`, the value for a NAND gate is `negative_unate`, and the value for an XOR gate is `non_unate`.

A function is *unate* if a rising (or falling) change on a positive unate input variable causes the output function variable to rise (or fall) or not change. A rising (or falling) change on a negative unate input variable causes the output function variable to fall (or rise) or not change. For a nonunate variable, further state information is required to determine the effects of a particular state transition.

You can specify half-unate sequential timing arcs if the `timing_type` value is either `rising_edge` or `falling_edge` and the `timing_sense` value is either `positive_unate` or `negative_unate`.

- In the case of `rising_edge` and `positive_unate` values, only the `cell_rise` and `rise_transition` information is required.
- In the case of `rising_edge` and `negative_unate` values, only the `cell_fall` and `fall_transition` information is required.
- In the case of `falling_edge` and `positive_unate` values, only the `cell_rise` and `rise_transition` information is required.
- In the case of `falling_edge` and `negative_unate` values, only the `cell_fall` and `fall_transition` information is required.

Do not define the `timing_sense` value of a pin, except when you need to override the derived value or when you are characterizing a noncombinational gate such as a three-state component. For example, you might want to define the timing sense manually when you model multiple paths between an input pin and an output pin, such as in an XOR gate.

It is possible that one path is positive unate while another is negative unate. In this case, the first timing arc is given a `positive_unate` designation and the second is given a `negative_unate` designation.

Timing arcs with a timing type of clear or preset require a `timing_sense` attribute.

If `related_pin` is an output pin, you must define a `timing_sense` attribute for that pin.

timing_type Simple Attribute

The `timing_type` attribute distinguishes between combinational and sequential cells by defining the type of timing arc. If this attribute is not assigned, the cell is considered combinational.

Syntax

```
timing_type : combinational | combinational_rise  
|  
  combinational_fall | three_state_disable |  
  three_state_disable_rise | three_state_disable_fall |  
  three_state_enable | three_state_enable_rise |  
  three_state_enable_fall | rising_edge | falling_edge |  
  preset | clear | hold_rising | hold_falling |  
  setup_rising | setup_falling | recovery_rising |  
  recovery_falling | skew_rising | skew_falling |  
  removal_rising | removal_falling | min_pulse_width |  
  minimum_period | max_clock_tree_path |  
  min_clock_tree_path | non_seq_setup_rising |  
  non_seq_setup_falling | non_seq_hold_rising |  
  non_seq_hold_falling | nochange_high_high |  
  nochange_high_low | nochange_low_high |  
  nochange_low_low ;
```

Combinational Timing Arcs

The timing type and timing sense define the signal propagation pattern. The default timing type is combinational.

Timing type	Timing sense		
	Positive_Unate	Negative_Unate	Non_Unate
combinational	R->R,F->F	R->F,F->R	{R,F}->{R,F}
combinational_rise	R->R	F->R	{R,F}->R
combinational_fall	F->F	R->F	{R,F}->F
three_state_disable	R->{0Z,1Z}	F->{0Z,1Z}	{R,F}->{0Z,1Z}
three_state_enable	R->{Z0,Z1}	F->{Z0,Z1}	{R,F}->{Z0,Z1}
three_state_disable_rise	R->0Z	F->0Z	{R,F}->0Z
three_state_disable_fall	R->1Z	F->1Z	{R,F}->1Z
three_state_enable_rise	R->Z1	F->Z1	{R,F}->Z1
three_state_enable_fall	R->Z0	F->Z0	{R,F}->Z0

Sequential Timing Arcs

rising_edge

Identifies a timing arc whose output pin is sensitive to a rising signal at the input pin.

falling_edge

Identifies a timing arc whose output pin is sensitive to a falling signal at the input pin.

preset

Preset arcs affect only the rise arrival time of the arc's endpoint pin. A preset arc implies that you are asserting a logic 1 on the output pin when the designated related_pin is asserted.

clear

Clear arcs affect only the fall arrival time of the arc's endpoint pin. A clear arc implies that you are asserting a logic 0 on the output pin when the designated related_pin is asserted.

hold_rising

Designates the rising edge of the related pin for the hold check.

hold_falling

Designates the falling edge of the related pin for the hold check.

setup_rising

Designates the rising edge of the related pin for the setup check on clocked elements.

setup_falling

Designates the falling edge of the related pin for the setup check on clocked elements.

recovery_rising

Uses the rising edge of the related pin for the recovery time check. The clock is rising-edge-triggered.

recovery_falling

Uses the falling edge of the related pin for the recovery time check. The clock is falling-edge-triggered.

skew_rising

The timing constraint interval is measured from the rising edge of the reference pin (specified in related_pin) to a transition edge of the parent pin of the timing group. The intrinsic_rise value is the maximum skew time between the reference pin rising and the parent pin rising. The intrinsic_fall value is the maximum skew time between the reference pin rising and the parent pin falling.

skew_falling

The timing constraint interval is measured from the falling edge of the reference pin (specified in `related_pin`) to a transition edge of the parent pin of the timing group. The `intrinsic_rise` value is the maximum skew time between the reference pin falling and the parent pin rising. The `intrinsic_fall` value is the maximum skew time between the reference pin falling and the parent pin falling.

removal_rising

Used when the cell is a low-enable latch or a rising-edge-triggered flip-flop. For active-low asynchronous control signals, define the removal time with the `intrinsic_rise` attribute. For active-high asynchronous control signals, define the removal time with the `intrinsic_fall` attribute.

removal_falling

Used when the cell is a high-enable latch or a falling-edge-triggered flip-flop. For active-low asynchronous control signals, define the removal time with the `intrinsic_rise` attribute. For active-high asynchronous control signals, define the removal time with the `intrinsic_fall` attribute.

minimum_pulse_width

This value lets you specify the minimum pulse width for a clock pin. The timing check is performed on the pin itself, so the related pin should be the same. You need to specify both rise and fall constraints to calculate the high and low pulse widths.

minimum_period

This value lets you specify the minimum period for a clock pin. The timing check is performed on the pin itself, so the related pin should be the same. You need to specify both rise and fall constraints to calculate the minimum clock period. Rise constraint is characterization data when the clock waveform has a rising start edge. Fall constraint is characterization data when the start edge of a waveform is falling.

max_clock_tree_path

Used in `timing` groups under a clock pin. Defines the maximum clock tree path constraint.

min_clock_tree_path

Used in `timing` groups under a clock pin. Defines the minimum clock tree path constraint.

Example

[Example 3-8](#) shows a sample library with the `timing_type` attribute and `minimum_pulse_width` and `minimum_period` values.

Example 3-8 Sample Library with `timing_type` Statements

```
library(ASIC) {
    ...
    delay_model : table_lookup;
    ...
    lu_table_template(pulse_width_template) {
        variable_1 : related_pin_transition;
        index_1 ("1.0, 2.0, 3.0");
    }
    cell(flop) {
        ...

        pin(CK) {
            direction : input;
            capacitance : 0.00707171;
            timing() {
                timing_type : "min_pulse_width";
                related_pin : "CK";
                ...
                rise_constraint("pulse_width_template") {
                    index_1("0.000000, 1.000000, 2.00000");
                    values ("6.000000, 6.250000, 7.250000" );
                }
                fall_constraint("pulse_width_template") {
                    index_1("0.000000, 1.000000, 2.00000");
                    values ("6.000000, 6.250000, 7.250000" );
                }
            }
            timing() {
                timing_type : "minimum_period";
                related_pin : "CK";
            }
        }
    }
}
```

```

        rise_constraint("pulse_width_template") {
            index_1(".000000, 1.000000, 2.00000");
            values ("6.000000, 6.250000, 7.250000" );
        }
        fall_constraint("pulse_width_template") {
            index_1("0.000000, 1.000000, 2.00000");
            values ("6.000000, 6.250000, 7.250000" );
        }
    }
}
...
} /* end cell */
} /* end library */

```

[Nonsequential Timing Arcs](#)

In some nonsequential cells, the setup and hold timing constraints are specified on the data pin with a nonclock pin as the related pin. It requires the signal of a pin to be stable for a specified period of time before and after another pin of the same cell range state so that the cell can function as expected.

non_seq_setup_rising

Defines (with `non_seq_setup_falling`) the timing arcs used for setup checks between pins with nonsequential behavior. The related pin in a timing arc is used for the timing check.

non_seq_setup_falling

Defines (with `non_seq_setup_rising`) the timing arcs used for setup checks between pins with nonsequential behavior. The related pin in a timing arc is used for the timing check. .

non_seq_hold_rising

Defines (with `non_seq_hold_falling`) the timing arcs used for hold checks between pins with nonsequential behavior. The related pin in a timing arc is used for the timing check.

non_seq_hold_falling

Defines (with `non_seq_hold_rising`) the timing arcs used for hold checks between pins with nonsequential behavior. The related pin in a timing arc is used for the timing check.

[No-Change Timing Arcs](#)

This feature models the timing requirement of latch devices with latch-enable signals. The four no-change timing types define the pulse waveforms of both the constrained signal and the related signal in standard CMOS and nonlinear CMOS delay models. The information is used in static timing verification during synthesis.

nochange_high_high (positive/positive)

Indicates a positive pulse on the constrained pin and a positive pulse on the related pin.

nochange_high_low (positive/negative)

Indicates a positive pulse on the constrained pin and a negative pulse on the related pin.

nochange_low_high (negative/positive)

Indicates a negative pulse on the constrained pin and a positive pulse on the related pin.

nochange_low_low (negative/negative)

Indicates a negative pulse on the constrained pin and a negative pulse on the related pin.

[wave_rise_sampling_index and wave_fall_sampling_index Attributes](#)

The `wave_rise_sampling_index` and `wave_fall_sampling_index` simple attributes override the default behavior of the `wave_rise` and `wave_fall` attributes (which select the first and the last vectors to define the sensitization patterns of the input to the output pin transition that are predefined inside the sensitization template specified at the library level).

[Syntax](#)

```

wave_rise_sampling_index : integer ;
wave_fall_sampling_index : integer ;

```

[Example](#)

```
wave_rise (2, 5, 7, 6); /* wave_rise ( wave_rise[0],  
wave_rise[1], wave_rise[2], wave_rise[3] );*/
```

In the previous example, the wave rise vector delay is measured from the last transition (vector 7 changing to vector 6) to the output transition. The default `wave_rise_sampling_index` value is the last entry in the vector, which is 3 in this case (because the numbering begins at 0).

To override this default, set the `wave_rise_sampling_index` attribute, as shown:

```
wave_rise_sampling_index : 2 ;
```

When you do this, the delay is measured from the second last transition of the sensitization vector to the final output transition, in other words from the transition of vector 5 to vector 7.

Note:

You will get an error if you specify a value of 0 for the `wave_rise_sampling_index` attribute.

when Simple Attribute

The `when` attribute is used in state-dependent timing and conditional timing checks.

Note:

The `when` attribute also appears in the `min_pulse_width` group and the `minimum_period` group (described on [and](#), respectively). Both groups can be placed in `pin`, `bus`, and `bundle` groups. The `when` attribute also appears in the `power`, `fall_power`, and `rise_power` groups.

Syntax

```
when : "Boolean expression" ;
```

Boolean expression

A Boolean expression containing names of input, output, inout, and internal pins.

Example

```
when : "CD * SD" ;
```

State-Dependent Timing

In the `timing` group of a technology library, you can specify state-dependent delays that correspond to entries in OVI SDF 2.1 syntax. In state-dependent timing, the `when` attribute defines a conditional expression on which a timing arc is dependent to activate a path.

Conditional Timing Check

In a conditional timing check, the `when` attribute defines check-enabling conditions for timing checks such as setup, hold, and recovery.

Conditional Timing Check in VITAL Models

The `when` attribute is used in modeling timing check conditions for VITAL models, where, if you define `when`, you must also define `sdf_cond`.

Syntax

```
when : "Boolean expression" ;
```

Boolean expression

A valid logic expression as defined in [Table 3-4](#).

Example

```
when : "CLR & PRE" ;  
sdf_cond : "CLR & PRE" ;
```

`when_end` Simple Attribute

The `when_end` attribute defines a timing-check condition specific to the end event in VHDL models.

Syntax

```
when_end : "Boolean expression" ;
```

Boolean expression

A Boolean expression containing names of input, output, inout, and internal pins.

Example

```
when_end : "CD * SD * Q'" ;
```

`when_start` Simple Attribute

The `when_start` attribute defines a timing-check condition specific to the start event in VHDL models.

Syntax

```
when_start : "Boolean expression" ;
```

Boolean expression

A Boolean expression containing the names of input, output, inout, and internal pins.

Example

```
when_start : "CD * SD" ;
```

`fall_delay_intercept` Complex Attribute

For piecewise models only, the `fall_delay_intercept` attribute defines the intercept for vendors using slope- or intercept-type timing equations. The value of the attribute is added to the falling edge in the delay equation.

Syntax

```
fall_delay_intercept ("integer, float") ;
```

Examples from a CMOS library:

```
fall_delay_intercept (0,"1.0") ; /* piece 0 */
fall_delay_intercept (1,"0.0") ; /* piece 1 */
fall_delay_intercept (2,"-1.0") ; /* piece 2 */
```

`fall_pin_resistance` Complex Attribute

For piecewise models only, the `fall_pin_resistance` attribute defines the drive resistance applied to pin loads in the falling edge in the transition delay equation.

Syntax

```
fall_pin_resistance (integer, float) ;
```

Examples From a CMOS library:

```
fall_pin_resistance (0,"0.25") ; /* piece 0 */
fall_pin_resistance (1,"0.50") ; /* piece 1 */
fall_pin_resistance (2,"1.00") ; /* piece 2 */
```

`mode` Complex Attribute

You define the `mode` attribute within a `timing` group. A `mode` attribute pertains to an individual timing arc. The timing arc is active when `mode` is instantiated with a name and a value. You can specify multiple instances of the `mode` attribute, but only one instance for each timing arc.

Syntax

```
mode (mode_name, mode_value);
```

Example

```
timing() {
    mode(rw, read);
}
```

[Example 3-9](#) shows a mode description.

Example 3-9 A mode Description

```
pin(my_outpin) {
    direction : output;
    timing() {
        related_pin : b;
        timing_sense : non_unate;
        mode(rw, read);
        cell_rise(delay3x3) {
            values("1.1, 1.2, 1.3", "2.0, 3.0, 4.0", "2.5, 3.5, 4.5");
        }
        rise_transition(delay3x3) {
            values("1.0, 1.1, 1.2", "1.5, 1.8, 2.0", "2.5, 3.0, 3.5");
        }
        cell_fall(delay3x3) {
            values("1.1, 1.2, 1.3", "2.0, 3.0, 4.0", "2.5, 3.5, 4.5");
        }
        fall_transition(delay3x3) {
            values("1.0, 1.1, 1.2", "1.5, 1.8, 2.0", "2.5, 3.0, 3.5");
        }
    }
}
```

[Example 3-10](#) shows multiple mode descriptions.

Example 3-10 Multiple mode Descriptions

```
library (MODE_EXAMPLE) {
    delay_model          : "table_lookup";
    time_unit           : "lns";
    voltage_unit        : "1V";
    current_unit        : "1mA";
    pulling_resistance_unit : "1kohm";
    leakage_power_unit   : "1nW";
    capacitive_load_unit (1, pf);
    nom_process         : 1.0;
    nom_voltage         : 1.0;
    nom_temperature     : 125.0;
    slew_lower_threshold_pct_rise : 10 ;
    slew_upper_threshold_pct_rise : 90 ;
    input_threshold_pct_fall   : 50 ;
    output_threshold_pct_fall  : 50 ;
    input_threshold_pct_rise   : 50 ;
    output_threshold_pct_rise  : 50 ;
    slew_lower_threshold_pct_fall : 10 ;
    slew_upper_threshold_pct_fall : 90 ;
    slew_derate_from_library   : 1.0 ;
    cell (mode_example) {
        mode_definition(RAM_MODE) {
            mode_value(MODE_1) {
            }
            mode_value(MODE_2) {
            }
            mode_value(MODE_3) {
            }
            mode_value(MODE_4) {
            }
        }
        interface_timing : true;
        dont_use       : true;
        dont_touch      : true;
    }
}
```

```

pin(Q) {
    direction      : output;
    max_capacitance   : 2.0;
    three_state      : "!OE";
    timing() {
        related_pin    : "CK";
        timing_sense   : non_unate;
        timing_type    : rising_edge;
        mode(RAM_MODE,"MODE_1 MODE_2");
        cell_rise(scalar) {
            values( " 0.0 ");
        }
        cell_fall(scalar) {
            values( " 0.0 ");
        }
        rise_transition(scalar) {
            values( " 0.0 ");
        }
        fall_transition(scalar) {
            values( " 0.0 ");
        }
    }
    timing() {
        related_pin    : "OE";
        timing_sense   : positive_unate;
        timing_type    : three_state_enable;
        mode(RAM_MODE, " MODE_2 MODE_3");
        cell_rise(scalar) {
            values( " 0.0 ");
        }
        cell_fall(scalar) {
            values( " 0.0 ");
        }
        rise_transition(scalar) {
            values( " 0.0 ");
        }
        fall_transition(scalar) {
            values( " 0.0 ");
        }
    }
    timing() {
        related_pin    : "OE";
        timing_sense   : negative_unate;
        timing_type    : three_state_disable;
        mode(RAM_MODE, MODE_3);
        cell_rise(scalar) {
            values( " 0.0 ");
        }
        cell_fall(scalar) {
            values( " 0.0 ");
        }
        rise_transition(scalar) {
            values( " 0.0 ");
        }
        fall_transition(scalar) {
            values( " 0.0 ");
        }
    }
}
pin(A) {
    direction      : input;
    capacitance    : 1.0;
    max_transition  : 2.0;
    timing() {
        timing_type    : setup_rising;
        related_pin    : "CK";
        mode(RAM_MODE, MODE_2);
        rise_constraint(scalar) {
            values( " 0.0 ");
        }
        fall_constraint(scalar) {
            values( " 0.0 ");
        }
    }
    timing() {
        timing_type    : hold_rising;
    }
}

```

```

        related_pin      : "CK";
        mode(RAM_MODE, MODE_2);
        rise_constraint(scalar) {
            values( " 0.0 ");
        }
        fall_constraint(scalar) {
            values( " 0.0 ");
        }
    }
}
pin(OE) {
    direction      : input;
    capacitance   : 1.0;
    max_transition : 2.0;
}
pin(CS) {
    direction      : input;
    capacitance   : 1.0;
    max_transition : 2.0;
    timing() {
        timing_type    : setup_rising;
        related_pin    : "CK";
        mode(RAM_MODE, MODE_1);
        rise_constraint(scalar) {
            values( " 0.0 ");
        }
        fall_constraint(scalar) {
            values( " 0.0 ");
        }
    }
    timing() {
        timing_type    : hold_rising;
        related_pin    : "CK";
        mode(RAM_MODE, MODE_1);
        rise_constraint(scalar) {
            values( " 0.0 ");
        }
        fall_constraint(scalar) {
            values( " 0.0 ");
        }
    }
}
pin(CK) {
    timing() {
        timing_type : "min_pulse_width";
        related_pin : "CK";
        mode(RAM_MODE , MODE_4);
        fall_constraint(scalar) {
            values( " 0.0 ");
        }
        rise_constraint(scalar) {
            values( " 0.0 ");
        }
    }
    timing() {
        timing_type : "minimum_period";
        related_pin : "CK";
        mode(RAM_MODE , MODE_4);
        rise_constraint(scalar) {
            values( " 0.0 ");
        }
        fall_constraint(scalar) {
            values( " 0.0 ");
        }
    }
    clock       : true;
    direction   : input;
    capacitance : 1.0;
    max_transition : 1.0;
}
cell_leakage_power : 0.0;
}
}

```

[pin_name_map Complex Attribute](#)

Similar to the `pin_name_map` attribute defined in the cell level, the timing-arc `pin_name_map` attribute defines pin names used to generate stimulus for the current timing arc. The attribute is optional when `pin_name_map` pin names are the same as (listed in order of priority)

1. pin names in the `sensitization_master` of the current timing arc.
2. pin names in the `pin_name_map` attribute of the current cell group.
3. pin names in the `sensitization_master` of the current cell group.

The `pin_name_map` attribute is required when `pin_name_map` pin names are different from all of the pin names in the previous list.

Syntax

```
pin_name_map (string..., string);
```

Example

```
pin_name_map (CIN0, CIN1, CK, Z);
```

`rise_delay_intercept` Complex Attribute

For piecewise models only, the `rise_delay_intercept` attribute defines the intercept for vendors using slope- or intercept-type timing equations. The value of the attribute is added to the rising edge in the delay equation.

Syntax

```
rise_delay_intercept (integer, "float");
```

Examples from a CMOS library:

```
rise_delay_intercept (0,"1.0") ; /* piece 0 */  
rise_delay_intercept (1,"0.0") ; /* piece 1 */
```

`rise_pin_resistance` Complex Attribute

For piecewise models only, the `rise_pin_resistance` attribute defines the drive resistance applied to pin loads in the rising edge in the transition delay equation.

Syntax

```
rise_pin_resistance (integer, "float");
```

Examples from a CMOS library:

```
rise_pin_resistance (0,"0.25") ; /* piece 0 */  
rise_pin_resistance (1,"0.50") ; /* piece 1 */  
rise_pin_resistance (2,"1.00") ; /* piece 2 */
```

`wave_rise` and `wave_fall` Complex Attributes

The `wave_rise` and `wave_fall` attributes represent the two stimuli used in characterization. The value for both attributes is a list of integer values, and each value is a vector ID predefined in the library sensitization group. The following example describes the `wave_rise` and `wave_fall` attributes:

```
wave_rise (vector_id[m]..., vector_id[n]);  
wave_fall (vector_id[j]..., vector_id[k]);
```

Syntax

```
wave_rise (integer..., integer);  
wave_fall (integer..., integer);
```

Example

```
library(my_library) {  
...  
sensitization(sensi_2in_lout) {  
    pin_names (IN1, IN2, OUT);  
    vector (0, "0 0 0");
```

```

vector (1, "0 0 1");
vector (2, "0 1 0");
vector (3, "0 1 1");
vector (4, "1 0 0");
vector (5, "1 0 1");
vector (6, "1 1 0");
vector (7, "1 1 1");
}
cell (my_nand2) {
    sensitization_master : sensi_2in_lout;
    pin_name_map (A, B, Z); /* these are pin names for the sensitization
in this
    cell. */
    ...
    pin(A) {
        ...
    }
    Pin(B) {
        ...
    }
    pin(Z) {
        ...
        timing() {
            related_pin : "A";
            wave_rise (6, 3); /* 6, 3 - vector id in sensi_2in_lout
sensitization
            group. Wave form interpretation of the wave_rise is (for
"A,
    B, Z" pins): 10 1 01 */
            wave_fall (3, 6);
            ...
        }
        timing() {
            related_pin : "B";
            wave_rise (7, 4); /* 7, 4 - vector id in sensi_2in_lout
sensitization
            group. */
            wave_fall (4, 7);
            ...
        }
    } /* end pin(Z)*/
} /* end cell(my_nand2) */
...
} /* end library */

```

wave_rise_time_interval and wave_fall_time_interval Complex Attributes

The `wave_rise_time_interval` and `wave_fall_time_interval` complex attributes control the time interval between transitions. By default, the stimuli (specified in `wave_rise` and `wave_fall`) are widely spaced apart during characterization (for example, 10 ns from one vector to the next) to allow all output transition to stabilize. The attributes allow you to specify a short duration between one vector to the next in order to characterize special purpose cells and pessimistic timing characterization.

The `wave_rise_time_interval` and `wave_fall_time_interval` attributes are optional when the default time interval is used for all transitions, and they are required when you need to define special time intervals between transitions. Usually, the special time interval is smaller than the default time interval.

The `wave_rise_time_interval` and `wave_fall_time_interval` attributes can have an argument count from 1 to $n - 1$, where n is the number of arguments in corresponding `wave_rise` or `wave_fall`. Use 0 to imply the default time interval used between vectors.

Syntax

```

wave_rise_time_interval (float..., float);
wave_fall_time_interval (float..., float);

```

Example

```

wave_rise (2, 5, 7, 6); /* wave_rise ( wave_rise[0],
wave_rise[1], wave_rise[2], wave_rise[3] );*/
wave_rise_time_interval (0.0, 0.3);

```

The previous example suggests the following:

- Use the default time interval between `wave_rise[0]` and `wave_rise[1]` (in other words, vector 2 and vector 5).
- Use 0.3 between `wave_rise[1]` and `wave_rise[2]` (in other words, vector 5 and vector 7).
- Use the default time interval between `wave_rise[2]` and `wave_rise[3]` (in other words, vector 7 and vector 6).

`ccs_retain_rise` and `ccs_retain_fall` Groups

The `ccs_retain_rise` and `ccs_retain_fall` groups are provided in the timing group for expanded CCS retain arcs.

Syntax

```
cell(namestring) {
    pin (namestring) {
        timing() {
            ccs_retain_rise() {
                vector(template_namestring) {
                    reference_time : float;
                    index_1("float");
                    index_2("float");
                    index_3("float, ..., float");
                    values("float, ..., float");
                }
            }
        }
    }
}
```

`cell_degradation` Group

The `cell_degradation` group describes a cell performance degradation design rule for compiling a design. A cell degradation design rule specifies the maximum capacitive load a cell can drive without causing cell performance degradation during the fall transition.

Syntax

```
pin (output pin name) {
    timing () {
        cell_degradation (template name) {
            ...cell_degradation description...
        }
        ...
    }
    ...
}
```

Complex Attributes

```
coefs /* polynomial model */
orders /* polynomial model */
index_1 /* lookup table */
values /* lookup table */
variable_n_range /* polynomial model */
```

Group

`domain`

`coefs` Complex Attribute

Use the `coefs` attribute to specify a list of the coefficients you use in a polynomial to characterize timing information. This attribute is required when you specify a scalable polynomial delay model. The coefficients are represented in the .lib file and saved in the database in column-first order. If any term missing in the polynomial, you must insert a 0 (zero) in the corresponding position in the `coefs` attribute to ensure correct processing of the coefficients.

Note:

For a piecewise polynomial, define the `coefs` attribute inside the `domain` group inside the `timing` group that defines the range of coefficients.

Syntax

```
pin (output_pin_name) {
    timing () {
        ...
        coefs("float, ..., float")
        ...
    }
}
```

```
    }  
    ...  
}
```

Example

```
timing () {  
    coefs ("1.0, 2.0, 3.0, 4.0, 5.0, 6.0, 7.0, 8.0, 9.0,  
           10.0, 11.0, 12.0") ;  
}
```

orders Complex Attribute

Use the `orders` attribute to specify the order of the variables you use in a polynomial to characterize timing information. This attribute is required in the `timing` group when you specify a scalable polynomial delay model. The `timing` group can be any timing group using polynomial delay modeling.

Note:

For a piecewise polynomial, define the `orders` attribute inside the `domain` group inside the `timing` group.

Syntax

```
pin (output_pin_name) {  
    timing () {  
        orders("integer, ..., integer")  
        ...  
    }  
    ...  
}
```

Example

```
timing () {  
    orders("2, 1, 1") ;  
    ...  
}
```

variable_n_range Complex Attribute

Use the `variable_n_range` attribute to specify the order of the variables for the polynomial to characterize timing information. This attribute is required in the `timing` group when you specify a scalable polynomial delay model. The `timing` group can be any timing group using polynomial delay modeling.

Note:

For a piecewise polynomial, define the `orders` attribute inside the `domain` group inside the `timing` group.

Syntax

```
pin (output_pin_name) {  
    timing () {  
        ...  
        variable_n_range(float, float) ;  
    }  
    ...  
}
```

Example

```
timing () {  
    variable_n_range () ;  
}
```

domain Group

In the case of a piecewise polynomial and multiple tables defined by the `calc_mode` attribute, use one or more `domain` groups in the `timing` group to specify subsets of the polynomial template and tables of the lookup table templates.

Note:

For a piecewise polynomial, define the `orders` and `coefs` attributes inside the `domain` group inside the `timing` group.

If the table is specified by `calc_mode`, the `values` attribute must be used inside the `timing` group. You can also use the `calc_mode` and `values` attributes inside the `timing` group to override the template values.

Note:

A domain name is required.

Syntax

```
library (name_string) {
    cell (name_string) {
        pin (name_string) {
            timing () {
                domain (name_string){
                    ... domain description...
                }
            }
        }
    }
}
```

Simple Attribute

```
calc_mode
```

Complex Attributes

```
coefs
orders
variable_n_range
```

For information about the syntax and usage of the above attributes see the [“cell_degradation Group”](#).

Example 3-11 Specifying cell_degradation in a Lookup Table

```
pin (Z) {
    timing () {
        cell_degradation (constraint) {
            index_1 ("1.0, 1.5, 2.0");
            values ("1.0, 1.5, 2.0");
        }
    ...
}
...
}
```

Example 3-12 Specifying cell_degradation in a Polynomial

```
domain (D1) {
    orders ("2, 1, 1");
    coefs ("1.000, 2.000, 3.000, 4.000, 5.000, 6.000, 7.000,
            8.000, 9.000, 10.000, 11.000, 12.000");
    variable_1_range (0.01, 3.00);
    variable_2_range (0.01, 3.00);
}
```

cell_fall Group

The `cell_fall` group defines cell delay lookup tables (independently of transition delay) in CMOS nonlinear timing models.

Note:

The same k-factors that scale the `cell_fall` and `cell_rise` values also scale the `retaining_fall` and `retaining_rise` values. There are no separate k-factors for the `retaining_fall` and `retaining_rise` values.

The `cell_fall` group is defined at the `timing` group level, as shown here:

Syntax

```
library (name_string) {
    cell (name_string) {
        pin (name_string) {
            timing () {
                cell_fall (name_string){
                    ... cell fall description...
                }
            }
        }
    }
}
```

Complex Attributes

```
index_1 ("float", ..., float");
index_2 ("float", ..., float");
index_3 ("float", ..., float");
values ("float", ..., float", ..., "float, ..., float");
```

Group

domain

domain Group

For information about the `domain` group syntax and usage, see the description in the ["domain Group"](#).

Examples from a CMOS library:

```
cell_fall (cell_template) {
    values ("0.00, 0.24", "0.15, 0.26") ;
}

cell_fall (cell_template) {
    values ("0.00, 0.33", "0.11, 0.38") ;
}
```

Each lookup table has an associated string name to indicate which `lu_table_template` in the `library` group it is to use. The name must be the same as the string name you previously defined in the `library lu_table_template`. For information about the `lu_table_template` syntax, see the description in ["lu_table_template Group"](#).

You can overwrite `index_1`, `index_2`, or `index_3` in a lookup table, but the overwrite must occur before the actual definition of values. The number of floating-point numbers for `index_1`, `index_2`, or `index_3` must be the same as the number you used in the `lu_table_template`.

The delay value of the table is stored in the `values` complex attribute. It is a list of `nindex_1` floating-point numbers for a one-dimensional table, `nindex_1 × nindex_2` floating-point numbers for a two-dimensional table, or `nindex_1 × nindex_2 × nindex_3` floating-point numbers for a three-dimensional table.

In a two-dimensional table, `nindex_1` and `nindex_2` are the size of `index_1` and `index_2` of the `lu_table_template` group. Group together `nindex_1` and `nindex_2` by using quotation marks ("").

In a three-dimensional table, `nindex_1 × nindex_2 × nindex_3` are the sizes of `index_1`, `index_2`, and `index_3` of the `lu_table_template` group. Group together `nindex_1`, `nindex_2`, and `nindex_3` by using quotation marks ("").

Transition and cell table delay values must be 0.0 or greater. Propagation tables can contain negative delay values.

cell_rise Group

The `cell_rise` group defines cell delay lookup tables (independently of transition delay) in CMOS nonlinear timing models.

Note:

The same k-factors that scale the `cell_fall` and `cell_rise` values also scale the `retaining_fall` and `retaining_rise` values. There are no separate k-factors for the `retaining_fall` and `retaining_rise` values.

Syntax

```
library (name_string) {
    cell (name_string) {
        pin (name_string) {
            timing () {
                cell_rise (name_string){
                    ... cell rise description ...
                }
            }
        }
    }
}
```

Complex Attributes

```
index_1 ("float, ..., float");
index_2 ("float, ..., float");
index_3 ("float, ..., float");
values ("float, ..., float", ..., "float, ..., float");
```

Group

```
domain
```

domain Group

For information about the `domain` group syntax and usage, see the description in the ["domain Group"](#).

Examples from a CMOS library

```
cell_rise(cell_template) {
    values("0.00, 0.23", "0.11, 0.28");
}

cell_rise(cell_template) {
    values("0.00, 0.25", "0.11, 0.28");
}
```

Each lookup table has an associated string name to indicate where in the `library` group it is to be used. The name must be the same as the string name you previously defined in the `library lu_table_template`. For information about the `lu_table_template` syntax, see the description in ["lu_table_template Group"](#).

You can overwrite `index_1`, `index_2`, or `index_3` in a lookup table, but the overwrite must occur before the actual definition of `values`. The number of floating-point numbers for `index_1`, `index_2`, or `index_3` must be the same as the number you used in the `lu_table_template`.

The delay value of the table is stored in a `values` complex attribute. It is a list of `nindex_1` floating-point numbers for a one-dimensional table, `nindex_1 × nindex_2` floating-point numbers for a two-dimensional table, or `nindex_1 × nindex_2 × nindex_3` floating-point numbers for a three-dimensional table.

In a two-dimensional table, `nindex_1` and `nindex_2` are the sizes of `index_1` and `index_2` of the `lu_table_template` group. Group together `nindex_1` and `nindex_2` by using quotation marks ("").

In a three-dimensional table, `nindex_1 × nindex_2 × nindex_3` are the sizes of `index_1`, `index_2`, and `index_3` of the `lu_table_template` group. Group together `nindex_1`, `nindex_2`, and `nindex_3` by using by quotation marks ("").

Each group represents a row in the table. The number of floating-point numbers in a group must equal `nindex_2`, and the number of groups in the `values` complex attribute must equal `nindex_1`. The floating-point `nindex_2` for a one-dimensional table is "1".

Transition and cell table delay values must be 0.0 or greater. Propagation tables can contain negative delay values.

The `index_3` attribute is part of the functionality that supports three-dimensional tables.

compact_ccs_retain_rise and compact_ccs_retain_fall Groups

The `compact_ccs_retain_rise` and `compact_ccs_retain_fall` groups are provided in the `timing` group for compact CCS retain arcs.

Syntax

```
pin(pin_name) {
    direction : string;
    capacitance : float;
    timing() {
        compact_ccs_retain_rise (template_name) {
            base_curves_group : "base_curves_name";
            index_1 ("float..., float");
            index_2 ("float..., float");
            index_3 ("string..., string");
            values ("..."...)
        }
    }
}
```

compact_ccs_rise and compact_ccs_fall Groups

The `compact_ccs_rise` and `compact_ccs_fall` groups define the compact CCS timing data in the timing arc.

Syntax

```
compact_ccs_rise (template_name) {
    compact_ccs_fall (template_name) {
```

Example

```
timing() {
    compact_ccs_rise (LT3) {
        base_curves_group : "ctbct1";
        values ("0.1, 0.5, 0.6, 0.8, 1, 3", \
                "0.15, 0.55, 0.65, 0.85, 2, 4", \
                "0.2, 0.6, 0.7, 0.9, 3, 2", \
                "0.25, 0.65, 0.75, 0.95, 4, 1");
    }
    compact_ccs_fall (LT3) {
        values ("-0.12, -0.51, 0.61, 0.82, 1, 2", \
                "-0.15, -0.55, 0.65, 0.85, 1, 4", \
                "-0.24, -0.67, 0.76, 0.95, 3, 4", \
                "-0.25, -0.65, 0.75, 0.95, 3, 1");
    }
}
```

Simple Attribute

`base_curves_group`

Complex Attribute

`values`

base_curves_group Simple Attribute

The `base_curves_group` attribute is optional at this level when `base_curves_name` is the same as that defined in the `compact_lut_template` that is being referenced by the `compact_ccs_rise` or `compact_ccs_fall` group.

Syntax

```
base_curves_group : "base_curves_name";
```

Example

`base_curves_group : "ctbct1";`

values Complex Attribute

The `values` attribute defines the compact CCS timing data values. The values are determined by the `index_3` values.

Syntax

```
values ("<float>, <float>, ...", "<float>, \
        <float>, ...");
```

Example

```

values ("0.1, 0.5, 0.6, 0.8, 1, 3", \
"0.15, 0.55, 0.65, 0.85, 2, 4", \
"0.2, 0.6, 0.7, 0.9, 3, 2", \
"0.25, 0.65, 0.75, 0.95, 4, 1");

```

fall_constraint Group

With the `rise_constraint` group, the `fall_constraint` group defines timing constraints (cell delay lookup tables) sensitive to clock or data input transition times. These constraint tables take the place of the `intrinsic_rise` and `intrinsic_fall` attributes used in other delay models.

The `fall_constraint` group is defined in a `timing` group, as shown here:

```

library (name_string) {
  cell (name_string) {
    pin (name_string) {
      timing () {
        fall_constraint (name_string){
          ... fall constraint description...
        }
      }
    }
  }
}

```

Complex Attributes

```

index_1 ("float, ..., float");
index_2 ("float, ..., float");
index_3 ("float, ..., float");
values ("float, ..., float", ..., "float, ..., float");

```

Group

`domain`

domain Group

For information about the `domain` group syntax and usage, see the description in the [“domain Group”](#).

Example

```

fall_constraint(constraint_template) {
  values ("0.0, 0.14, 0.20", \
  "0.22, 0.24, 0.42", \
  "0.34, 0.38, 0.51");
}

...
rise_constraint(constraint_template) {
  values ("0.0, 0.13, 0.19", \
  "0.21, 0.23, 0.41", \
  "0.33, 0.37, 0.50");
}

```

[Example 3-13](#) shows constraints in a timing model.

fall_propagation Group

With the `rise_propagation` group, the `fall_propagation` group specifies transition delay as a term in the total cell delay.

The `fall_propagation` group is defined in the `timing` group, as shown here.

```

library (name_string) {
  cell (name_string) {
    pin (name_string) {
      timing () {

```

Group

domain

domain Group

For information about the domain group syntax and usage, see the description in the [“domain Group”](#).

```
fall_propagation (prop_template) {
    values ("0.02, 0.15", "0.12, 0.30") ;
}
rise_propagation (prop_template) {
    values ("0.04, 0.20", "0.17, 0.35") ;
}
```

fall_transition Group

The fall_transition group is defined in the timing group, as shown here:

```

library (namestring) {
    cell (namestring) {
        pin (namestring) {
            timing () {
                fall_transition (namestring) {
                    ... values description...
                }
            }
        }
    }
}

```

Complex Attributes

```
index_1 ("float, ..., float");
index_2 ("float, ..., float");
index_3 ("float, ..., float");
values ("float, ..., float", ..., "float, ..., float");

intermediate_values ("float, ..., float", ..., "float,
..., float");
```

Note:

As an option, you can use the `intermediate_values` table attribute to specify the transition from the first slew point to the output delay threshold. The `intermediate_values` table attribute has to use the same format as the `table` attribute.

Group

domain

domain Group

For information about the domain group syntax and usage, see the description in the [“domain Group”](#).

Example

```
fall_transition(tran_template) {
    values ("0.01, 0.11, 0.18, 0.40");
}
```

noise_immunity_above_high Group

Use this optional group to describe a noise immunity curve when the input is high and the noise is over the high voltage rail.

You define the noise_immunity_above_high group in a timing group, as shown here:

```
library (name_string) {
    cell (name_string) {
        pin (name_string) {
            timing () {
                noise_immunity_above_high (template_name_string){
                    ... values description...
                }
            }
        }
    }
}
```

template_name

The name of a noise_lut_template group or a poly_template group.

Complex Attributes

```
coefs /* scalable polynomial only */
orders /* scalable polynomial only */
values /* lookup table only */
```

Group

```
domain /* scalable polynomial only */
```

coefs Complex Attribute

Use the coefs attribute to specify a list of the coefficients you use in a polynomial to characterize noise immunity information. This attribute is required in the noise_immunity_above_high group when you specify a scalable polynomial model. The coefficients are represented in the .lib file and saved in the database in column-first order. If any term is missing in the polynomial, you must insert a 0 (zero) in the corresponding position in the coefs attribute to ensure correct processing of the coefficients.

Note:

For a piecewise polynomial, the coefs attribute must be defined inside the domain group inside the noise_immunity_above_high group that defines the range of coefficients.

Syntax

```
pin (input_pin_name) {
    timing () {
        noise_immunity_above_high (poly_template_name_string){
            coefs("float, ..., float")
        }
    }
    ...
}
```

orders Complex Attribute

Use the `orders` attribute to specify the order for the variables for the polynomial to characterize noise immunity information. This attribute is required in the `noise_immunity_above_high` group when you specify a scalable polynomial model.

Note:

For a piecewise polynomial, define the `orders` attribute inside the `domain` group inside the `noise_immunity_above_high` group.

Syntax

```
pin (input_pin_name) {
    timing () {
        noise_immunity_above_high (poly_template_name_string){
            orders("integer, ..., integer")
        }
    }
    ...
}
```

Example

```
pin (z) {
    timing () {
        noise_immunity_above_high (){
            orders("2, 1, 1");
            coefs ("1.0, 2.0, 3.0, 4.0. 5.0, 6.0, 7.0, 8.0, 9.0,
                    10.0, 11.0, 12.0");
        }
    }
    ...
}
```

domain Group

For information about the `domain` group syntax and usage, see the description in the [“domain Group”](#).

noise_immunity_below_low Group

Use this optional group to describe a noise immunity curve when the input is low and the noise is below the low voltage rail.

For information about the `noise_immunity_below_low` group syntax and attributes, see [“noise_immunity_above_high Group”](#).

noise_immunity_high Group

Use this optional group to describe a noise immunity curve when the input is high and the noise is below the high voltage rail.

For information about the `noise_immunity_high` group syntax and attributes, see [“noise_immunity_above_high Group”](#).

noise_immunity_low Group

Use this optional group to describe a noise immunity curve when the input is low and the noise is over the low voltage rail.

For information about the `noise_immunity_low` group syntax and attributes, see [“noise_immunity_above_high Group”](#).

output_current_fall Group

Use the `output_current_fall` and the `output_current_rise` groups to specify the output current for a nonlinear lookup table model.

The `output_current_fall` group is defined in the `timing` group, as shown here.

```
library (name_string) {
    cell (name_string) {
        pin (name_string) {
            timing () {
                output_current_fall (name_string){
                    ... description ...
                }
            }
        }
    }
}
```

```
}
```

Groups

```
vector
```

vector Group

Use the `vector` group to store information about the input slew and output load.

The `vector` group is defined in the `output_current_fall` group, as shown here.

```
library (name_string) {
    cell (name_string) {
        pin (name_string) {
            timing () {
                output_current_fall (name_string){
                    vector () {
                        ... description ...
                    }
                }
            }
        }
    }
}
```

Simple Attribute

```
reference_time
```

reference_time Simple Attribute

Use the `reference_time` attribute to specify the time at which the input waveform crosses the rising or falling input delay threshold.

The `reference_time` attribute is defined in the `vector` group, as shown here.

```
library (name_string) {
    cell (name_string) {
        pin (name_string) {
            timing () {
                output_current_fall (name_string){
                    vector () {
                        reference_time : ;
                    }
                }
            }
        }
    }
}
```

Example

```
timing () {
    output_current_rise () {
        vector (CCT) {
            reference_time : 0.05 ;
            index_1 (0.1) ;
            index_1 (1.1) ;
            index_1 (1, 3, 3, 4, 5) ;
            values ( 1.1, 1.3, 1.5, 1.2, 1.4) ;
        }
    }
}
```

output_current_rise Group

For information about using the `output_current_rise` group, see the definition of the [“output_current_fall Group”](#).

`propagated_noise_height_above_high` Group

Use this group to describe noise propagation through a cell when the input is high and the noise is over the high voltage rail.

You define the `propagated_noise_above_high` group in a `timing` group, as shown here:

```
...
timing () {
    propagated_noise_height_above_high (template_name_string) {
        ... values description...
    }
}

template_name
```

The name of a `propagation_lut_template` group or a `poly_template` group.

Complex Attributes

```
coefs /* scalable polynomial only */
orders /* scalable polynomial only */
values /* lookup table only */
```

Group

```
domain /* scalable polynomial only */
```

coefs Complex Attribute

Use the `coefs` attribute to specify a list of the coefficients you use in a polynomial to characterize propagated noise information. This attribute is required in the `propagated_noise_height_above_high` group when you specify a scalable polynomial model. The coefficients are represented in the `.lib` file and saved in the database in column-first order. If any term is missing in the polynomial, you must insert a 0 (zero) in the corresponding position in the `coefs` attribute to ensure correct processing of the coefficients.

Note:

For a piecewise polynomial, define the `coefs` attribute inside the `domain` group inside the `propagated_noise_height_above_high` group that defines the range of coefficients.

Syntax

```
pin (input_pin_name_id) {
    timing () {
        propagated_noise_height_above_high \
            (poly_template_name_id) {
                coefs("float, ..., float")
            }
        ...
    }
}
```

orders Complex Attribute

Use the `orders` attribute to specify the order of the variables for the polynomial to characterize noise immunity information. This attribute is required in the `propagated_noise_height_above_high` group when you specify a scalable polynomial model. For a piecewise polynomial, the `orders` attribute should be used inside the `domain` group inside the `propagated_noise_height_above_high` group.

Syntax

```
pin (input_pin_name) {
    timing () {
        propagated_noise_height_above_high \
            (poly_template_name_string) {
                orders("integer, ..., integer")
            }
        ...
    }
}
```

Example

```
pin (z) {
    timing () {
        orders("2, 1, 1");
        coefs ("1.0, 2.0, 3.0, 4.0. 5.0, 6.0, 7.0, 8.0, 9.0,
                10.0, 11.0, 12.0");
    }
    ...
}
```

domain Group

For information about the `domain` group syntax and usage, see the description in the [“domain Group”](#).

propagated_noise_height_below_low Group

Use this group to describe noise propagation through a cell when the input is low and the noise is below the low voltage rail.

For information about the `propagated_noise_height_below_low` group syntax and attributes, see [“propagated_noise_height_above_high Group”](#).

propagated_noise_height_high Group

Use this group to describe noise propagation through a cell when the input is high and the noise is below the high voltage rail.

For information about the `propagated_noise_height_high` group syntax and attributes, see [“propagated_noise_height_above_high Group”](#).

propagated_noise_height_low Group

Use this group to describe noise propagation through a cell when the input is low and the noise is over the low voltage rail.

For information about the `propagated_noise_height_low` group syntax and attributes, see [“propagated_noise_height_above_high Group”](#).

propagated_noise_peak_time_ratio_above_high Group

Use this group to describe noise propagation through a cell when the input is high and the noise is over the high voltage rail.

For information about the `propagated_noise_peak_time_ratio_above_high` group syntax and attributes, see [“propagated_noise_height_above_high Group”](#).

propagated_noise_peak_time_ratio_below_low Group

Use this group to describe noise propagation through a cell when the input is low and the noise is below the low voltage rail.

For information about the `propagated_noise_peak_time_ratio_below_low` group syntax and attributes, see [“propagated_noise_height_above_high Group”](#).

propagated_noise_peak_time_ratio_high Group

Use this group to describe noise propagation through a cell when the input is high and the noise is below the high voltage rail.

For information about the `propagated_noise_peak_time_ratio_high` group syntax and attributes, see [“propagated_noise_height_above_high Group”](#).

propagated_noise_peak_time_ratio_low Group

Use this group to describe noise propagation through a cell when the input is low and the noise is over the low voltage rail.

For information about the `propagated_noise_peak_time_ratio_low` group syntax and attributes, see [“propagated_noise_height_above_high Group”](#).

propagated_noise_width_above_high Group

Use this group to describe noise propagation through a cell when the input is high and the noise is over the high voltage rail.

For information about the `propagated_noise_width_above_high` group syntax and attributes, see [“propagated_noise_height_above_high Group”](#).

[propagated_noise_width_below_low Group](#)

Use this group to describe noise propagation through a cell when the input is low and the noise is below the low voltage rail.

For information about the `propagated_noise_width_below_low` group syntax and attributes, see "[propagated_noise_height_above_high Group](#)".

[propagated_noise_width_high Group](#)

Use this group to describe noise propagation through a cell when the input is high and the noise is below the high voltage rail.

For information about the `propagated_noise_width_high` group syntax and attributes, see "[propagated_noise_height_above_high Group](#)".

[propagated_noise_width_low Group](#)

Use this group to describe noise propagation through a cell when the input is low and the noise is over the low voltage rail.

For information about the `propagated_noise_width_low` group syntax and attributes, see "[propagated_noise_height_above_high Group](#)".

[receiver_capacitance1_fall Group](#)

You can define the `receiver_capacitance1_fall` group at the pin level and at the timing level. Define the `receiver_capacitance1_fall` group at the timing level to specify receiver capacitance for a timing arc. For information about using the group at the pin level, see "[receiver_capacitance1_fall Group](#)".

Syntax

```
receiver_capacitance1_fall (value) {
```

Complex Attribute

```
    values
```

Example

```
timing() {
    ...
    receiver_capacitance1_fall () {
        values ("2.0, 4.0, 1.0, 3.0");
    }
}
```

[receiver_capacitance1_rise Group](#)

For information about using the `receiver_capacitance1_rise` group, see the description of the [receiver_capacitance1_fall Group](#).

[receiver_capacitance2_fall Group](#)

For information about using the `receiver_capacitance2_fall` group, see the description of the [receiver_capacitance1_fall Group](#).

[receiver_capacitance2_rise Group](#)

For information about using the `receiver_capacitance2_rise` group, see the description of the [receiver_capacitance1_fall Group](#).

[retaining_fall Group](#)

The `retaining_fall` group specifies the length of time the output port retains its current logical value of 1 after the output port's corresponding input port's value has changed.

This attribute is used only with nonlinear delay models.

Note:

The same k-factors that scale the `cell_fall` and `cell_rise` values also scale the `retaining_fall` and

`retaining_rise` values. There are no separate k-factors for the `retaining_fall` and `retaining_rise` values.

Syntax

```
library (namestring) {
    cell (namestring) {
        pin (namestring) {
            timing () {
                retaining_fall (namestring) {
                    ... retaining fall description ...
                }
            }
        }
    }
}
```

Complex Attributes

```
index_1 ("float, ..., float");
index_2 ("float, ..., float");
index_3 ("float, ..., float");
values ("float, ..., float", "float, ..., float", "float, ..., float");
```

Group

domain

domain Group

For information about the `domain` group syntax and usage, see the description in the ["domain Group"](#).

Example

```
retaining_rise (retaining_table_template) {
    values ("0.00, 0.23", "0.11, 0.28");
}
retaining_fall (retaining_table_template) {
    values ("0.01, 0.30", "0.12, 0.18");
}
```

retaining_rise Group

The `retaining_rise` group specifies the length of time an output port retains its current logical value of 0 after the output port's corresponding input port's value has changed.

This attribute is used only with nonlinear delay models.

Note:

The same k-factors that scale the `cell_fall` and `cell_rise` values also scale the `retaining_fall` and `retaining_rise` values. There are no separate k-factors for the `retaining_fall` and `retaining_rise` values.

Syntax

```
library (namestring) {
    cell (namestring) {
        pin (namestring) {
            timing () {
                retaining_rise (namestring) {
                    ... retaining rise description ...
                }
            }
        }
    }
}
```

Complex Attributes

```
index_1 ("float, ..., float");
index_2 ("float, ..., float");
index_3 ("float, ..., float");
values ("float, ..., float", "float, ..., float", "float,
..., float");
```

Group

```
domain
```

domain Group

For information about the `domain` group syntax and usage, see the description in the [“domain Group”](#).

Example

```
retaining_rise (retaining_table_template) {
    values ("0.00, 0.23", "0.11, 0.28");
}
retaining_fall (retaining_table_template) {
    values ("0.01, 0.30", "0.12, 0.18");
}
```

retain_fall_slew Group

Use this group in the `timing` group to define a slew table associated with the `retaining_fall` delay. The slew table describes the rate of decay of the output logic value.

Syntax

```
retain_fall_slew (retaining_time_template_string) {
    values (index1_float, index2_float, index3_float);
}
retain_fall_slew (retaining_time_template_string) {
    orders("variable1_integer, variable2_integer");
    coeffs("coefficient_1_float, ..., coefficient_n_float");
    variable_n_range(float, float);
}
```

retaining_time_template

Name of the table template to use for the lookup table.

index1, index2, index3

Values to use for indexing the lookup table.

variable1, variable2

The orders of the variables for the polynomial.

coefficient_1, ..., coefficient_n

Specifies the coefficients used in the polynomial to characterize timing information.

Examples

```
cell (cell_name) {
    ...
    pin (pin_name) {
        direction : output;
        ...
        timing () {
            related_pin : "related_pin";
            ...
            retaining_fall (retaining_table_template) {
                values ("0.00, 0.23", "0.11, 0.28");
            }
            ...
            retain_fall_slew (retaining_time_template) {
```

```

        values ( "0.01, 0.02" ) ;
    }
    ...
}
}

cell (cell_name) {
...
pin (pin_name) {
    direction : output :
...
timing ( ) {
    related_pin : "related_pin" ;
...
    retaining_fall (retaining_table_template) {
        orders ("1, 1");
        coefs ("0.2407, 3.1568, 0.0129, 0.0143");
        variable_1_range (0.01, 3.00);
        variable_2_range (0.01, 3.00);
    }
...
    retain_fall_slew (retaining_time_template) {
        orders ("1, 1");
        coefs ("0.2407, 3.1568, 0.0129, 0.0143");
        variable_1_range (0.01, 3.00);
        variable_2_range (0.01, 3.00);
    }
...
}
}
}
}
```

retain_rise_slew Group

Use this group in the `timing` group to define a slew table associated with the `retaining_rise` delay. The slew table describes the rate of decay of the output logic value.

Syntax

```

retain_rise_slew (retaining_time_template_string) {
    values(index1_float, index2_float, index3_float);
}
retain_rise_slew (retaining_time_template_string) {
    orders("variable1_integer, variable2_integer");
    coefs("coefficient_1_float, ..., coefficient_n_float");
    variable_n_range(float, float);
}

```

`retaining_time_template`

Name of the table template to use for the lookup table.

`index1_float, index2_float, index3_float`

Values to use for indexing the lookup table.

`variable1, variable2`

The orders of the variables for the polynomial.

`coefficient_1_float, ..., coefficient_n_float`

Specifies the coefficients used in the polynomial to characterize timing information.

Examples

```

cell (cell_name) {
...
pin (pin_name) {
    direction : output :

```

```

...
    timing () {
        related_pin : "related_pin"
        ...
        retaining_rise (retaining_table_template) {
            values ( "0.00, 0.23", "0.11, 0.28" );
        }
        ...
        retain_rise_slew (retaining_time_template) {
            values ( "0.01, 0.02" );
        }
        ...
    }
}

cell (cell_name) {
    ...
    pin (pin_name) {
        direction : output :
        ...
        timing () {
            related_pin : "related_pin"
            ...
            retaining_rise (retaining_table_template) {
                orders ("1, 1");
                coefs ("0.2407, 3.1568, 0.0129, 0.0143");
                variable_1_range (0.01, 3.00);
                variable_2_range (0.01, 3.00);
            }
            ...
            retain_rise_slew (retaining_time_template) {
                orders ("1, 1");
                coefs ("0.2407, 3.1568, 0.0129, 0.0143");
                variable_1_range (0.01, 3.00);
                variable_2_range (0.01, 3.00);
            }
            ...
        }
    }
}

```

[rise_constraint Group](#)

With the fall_constraint group, the rise_constraint group defines timing constraints (cell delay lookup tables) sensitive to clock or data input transition times. These constraint tables take the place of the `intrinsic_rise` and `intrinsic_fall` attributes used in the other delay models.

[Syntax](#)

```

library (name_string) {
    cell (name_string) {
        pin (name_string) {
            timing () {
                rise_constraint (name_string){
                    ... values description...
                }
            }
        }
    }
}

```

[Complex Attributes](#)

```

index_1 ("float, ..., float");
index_2 ("float, ..., float");
index_3 ("float, ..., float");
values ("float, ..., float", ..., "float, ..., float");

```

[Group](#)

```
domain
```

domain Group

For information about the `domain` group syntax and usage, see the description in the “[domain Group](#)”.

Example

```
rise_constraint(constraint_template) {
    values ("0.0, 0.13, 0.19", \
            "0.21, 0.23, 0.41", \
            "0.33, 0.37, 0.50");
}
```

[Example 3-13](#) shows constraints in a timing model.

Example 3-13 CMOS Nonlinear Timing Model Using Constraints

```
library( vendor_b ) {
    /* 1. Use delay lookup table */
    delay_model : table_lookup;
    /* 2. Define template of size 3 x 3*/
    lu_table_template(constraint_template) {
        variable_1 : constrained_pin_transition;
        variable_2 : related_pin_transition;
        index_1 ("0.0, 0.5, 1.5");
        index_2 ("0.0, 2.0, 4.0");
    }
    ...
    cell(dff) {
        pin(d) {
            direction: input;
            timing( "t1" | "t1", "t2", "t3" ) {
                related_pin : "clk";
                timing_type : setup_rising;
                ...
                /* Inherit the 'constraint_template' template */
                rise_constraint(constraint_template) {
                    /* Specify all the values */
                    values ("0.0, 0.13, 0.19", \
                            "0.21, 0.23, 0.41", \
                            "0.33, 0.37, 0.50");
                }
                fall_constraint(constraint_template) {
                    values ("0.0, 0.14, 0.20", \
                            "0.22, 0.24, 0.42", \
                            "0.34, 0.38, 0.51");
                }
            }
        }
    }
}
```

rise_propagation Group

With the `fall_propagation` group, the `rise_propagation` group specifies transition delay as a term in the total cell delay.

Syntax

```
library (name_string) {
    cell (name_string) {
        pin (name_string) {
            timing () {
                rise_propagation (name_string){
                    ... rise propagation description ...
                }
            }
        }
    }
}
```

Complex Attributes

```
index_1 ("float, ..., float");
index_2 ("float, ..., float");
index_3 ("float, ..., float");
values ("float, ..., float", ..., "float, ..., float");
```

Group

domain

domain Group

For information about the domain group syntax and usage, see the description in the [“domain Group”](#).

Example

```
fall_propagation (prop_template) {
    values("0.00, 0.21", "0.14, 0.38") ;
}
rise_propagation (prop_template) {
    values("0.05, 0.25", "0.15, 0.48") ;
}
```

rise_transition Group

The rise_transition group is defined in the timing group, as shown here:

```
library (name_string) {
    cell (name_string) {
        pin (name_string) {
            timing () {
                rise_transition (name_string){
                    ... rise transition description ...
                }
            }
        }
    }
}
```

Complex Attributes

```
index_1 ("float, ..., float");
index_2 ("float, ..., float");
index_3 ("float, ..., float");
values ("float, ..., float", ..., "float, ..., float");

intermediate_values ("float, ..., float", ..., "float,
..., float");
```

Note:

Optionally, you can use the intermediate_values table attribute to specify the transition from the first slew point to the output delay threshold. The intermediate_values table attribute has to use the same format as the table attribute.

Group

domain

domain Group

For information about the domain group syntax and usage, see the description in the [“domain Group”](#).

Examples

```
rise_transition(tran_template) {
    values ("0.01, 0.08, 0.15, 0.40");
```

```

    }

fall_transition(tran_template) {
    values ("0.01, 0.11, 0.18, 0.40");
}

```

steady_state_current_high Group

This optional group defines the current-voltage (I-V) characteristic for a cell timing arc by holding the output signal high.

You define the `steady_state_current_high` group in a `timing` group, as shown here:

```

library (name_string) {
    cell (name_string) {
        pin (name_string) {
            timing () {
                steady_state_current_high (template_name_string){
                    ... values description...
                }
            }
        }
    }
}

```

template_name

The name of an `iv_lut_template` group or a `poly_template` group.

Complex Attributes

```

coefs /* scalable polynomial only */
orders /* scalable polynomial only */
values /* lookup table only */

```

Group

```
domain /* scalable polynomial only */
```

coefs Complex Attribute

Use the `coefs` attribute to specify a list of the coefficients you use in a polynomial to characterize steady-state current information. This attribute is required in the `steady_state_current_high` group when you specify a scalable polynomial model. The coefficients are represented in the `.lib` file and saved in the database in column-first order. If any term is missing in the polynomial, you must insert a 0 (zero) in the corresponding position in the `coefs` attribute to ensure correct processing of the coefficients.

Note:

For a piecewise polynomial, define the `coefs` attribute inside the `domain` group inside the `steady_state_current_high` group that defines the range of coefficients.

Syntax

```

pin (output_pin_name) {
    timing () {
        steady_state_current_high (poly_template_string){
            coefs("float, ..., float")
        }
    }
    ...
}

```

orders Complex Attribute

Use the `orders` attribute to specify the order of the variables for the polynomial to characterize steady state current information. This attribute is required in the `steady_state_current_high` group when you specify a scalable polynomial model.

Note:

For a piecewise polynomial, define the `orders` attribute inside the `domain` group inside the `steady_state_current_high` group.

Syntax

```
pin (output_pin_name) {
    timing () {
        steady_state_current_high (poly_template_name_string){
            orders("integer, ..., integer")
        }
    }
    ...
}
```

Example

```
pin (z) {
    timing () {
        orders("2, 1, 1");
        coefs ("1.0, 2.0, 3.0, 4.0. 5.0, 6.0, 7.0, 8.0, 9.0,
               10.0, 11.0, 12.0");
        variable_n_range
    }
    ...
}
```

Syntax

```
pin (output_pin_name) {
    timing () {
        steady_state_current_high (lut_table_template_string){
            orders("integer, ..., integer")
            coefs("float, ..., float")
            values (integer, integer);
        }
    }
    ...
}
```

Example

```
pin (z) {
    timing () {
        steady_state_current_high (){
            values ("2, 1.8, ...-0.8");
        }
    }
    ...
}
```

domain Group

For information about the `domain` group syntax and usage, see the description in the ["domain Group"](#).

steady_state_current_low Group

This optional group defines the current-voltage (I-V) characteristic for a cell timing arc by holding the output signal low.

Complex Attribute

```
coefs
orders
values

intermediate_values ("float, ..., float", ..., "float,
...,float");
```

Note:

Optionally, you can use the `intermediate_values` table attribute to specify the transition from the first slew point to the output delay threshold. The `intermediate_values` table attribute has to use the same format as the `table` attribute.

Group

`domain`

For information about the `steady_state_current_tristate` group syntax and attributes, see [“steady_state_current_high Group”](#).

`steady_state_current_tristate Group`

This optional group defines the current-voltage (I-V) characteristic for tri-state timing arcs.

Complex Attributes

```
coefs  
orders  
values  
  
intermediate_values ("float, ..., float", ..., "float,  
...,float");
```

Note:

Optionally, you can use the `intermediate_values` table attribute to specify the transition from the first slew point to the output delay threshold. The `intermediate_values` table attribute has to use the same format as the `table` attribute.

Group

`domain`

For information about the `steady_state_current_tristate` group syntax and attributes, see [“steady_state_current_high Group”](#).

`pin_based_variation Group`

The `pin_based_variation` group is similar to the `timing_based_variation` group in that it specifies the rising and falling output transitions for variation parameters (by the `va_compact_ccs_rise` and `va_compact_ccs_fall` groups) and specifies variation-aware receiver capacitance information. If a receiver capacitance group exists in a pin group, the variation-aware CCS receiver model groups, such as the following, are required in the `pin_based_variation` group.

- `va_receiver_capacitance1_rise`
- `va_receiver_capacitance1_fall`
- `va_receiver_capacitance2_rise`
- `va_receiver_capacitance2_fall`

See Also

[timing_based_variation Group](#)

Syntax

```
pin(pin_name)  
...  
pin_based_variation(){  
    va_parameters (<string>, ...);  
    nominal_va_values (<float>, ...);  
    va_receiver_capacitance1_rise (template_name) {  
        va_values (<float>, ...);  
        values ("<float>, ...", ...);  
        ...}  
    va_receiver_capacitance2_rise (template_name) {  
        ...}  
    va_receiver_capacitance1_fall (template_name) {  
        ...}  
    va_receiver_capacitance2_fall (template_name) {  
        ...}  
    ...}  
}
```

Example

```
pin_based_variation(){
    va_parameters (channel_length, threshold_voltage) ;
    nominal_va_values (0.5, 0.5) ;
    va_receiver_capacitance1_rise (LUT3) {
        va_values (0.50, 0.45) ;
        values ("0.29, 0.30, 0.31") ;
    }
    ...
    va_receiver_capacitance2_rise (LUT3) {
        va_values (0.50, 0.45) ;
    }
    ...
    va_receiver_capacitance1_fall (LUT3) {
        va_values (0.50, 0.45) ;
    }
    ...
    va_receiver_capacitance2_fall (LUT3) {
        va_values (0.50, 0.45) ;
    }
}
```

Complex Attributes

```
va_parameters
nominal_va_values
```

For information about the `va_parameters` and `nominal_va_values` attributes, see "["va_parameters Complex Attribute"](#)" and "["nominal_va_values Complex Attribute"](#)".

Groups

```
va_receiver_capacitance1_rise
va_receiver_capacitance1_fall
va_receiver_capacitance2_rise
va_receiver_capacitance2_fall
va_compact_ccs_rise
va_compact_ccs_fall
```

For information about the `va_compact_ccs_rise` and `va_compact_ccs_fall` groups, see "["va_compact_ccs_rise and va_compact_ccs_fall Groups"](#)".

Variation-Aware CCS Receiver Model Groups

The following variation-aware CCS receiver model groups specify characterization corners with variation values in `timing_based_variation` and `pin_based_variation` groups:

- `va_receiver_capacitance1_rise`
- `va_receiver_capacitance1_fall`
- `va_receiver_capacitance2_rise`
- `va_receiver_capacitance2_fall`

Syntax

```
va_receiver_capacitance1_rise (template_name)
{
    va_values (<float>, ...) ;
    values ("<float>, ...", ...) ;
}
va_receiver_capacitance2_rise (template_name) {
}
va_receiver_capacitance1_fall (template_name) {
}
va_receiver_capacitance2_fall (template_name) {
```

Example

```
pin_based_variation(){
    va_parameters (channel_length, threshold_voltage) ;
    nominal_va_values (0.5, 0.5) ;
    va_receiver_capacitance1_rise (LUT3) {
        va_values (0.50, 0.45) ;
        values ("0.29, 0.30, 0.31") ;
```

```

}

...
va_receiver_capacitance2_rise (LUT3) {
    va_values (0.50, 0.45) ;
}

}
va_receiver_capacitance1_fall (LUT3) {
    va_values (0.50, 0.45) ;
}

}
va_receiver_capacitance2_fall (LUT3) {
    va_values (0.50, 0.45) ;
...
}

}

```

Complex Attributes

```

va_values
values

```

For information about the `va_values` and `values` attributes, see [“va_values Complex Attribute”](#) and [“values Complex Attribute”](#).

timing_based_variation Group

The `timing_based_variation` group is similar to the `pin_based_variation` group in that it specifies variation-aware receiver capacitance information (but in a timing group rather than in a pin group), and it specifies the rising and falling output transitions for variation parameters. The rising and falling output transitions are specified in the `va_compact_ccs_rise` and `va_compact_ccs_fall` groups, respectively.

The following information applies to the `timing_based_variation` group:

- The `va_compact_ccs_rise` group is required only if a `compact_ccs_rise` group exists within a timing group.
- The `va_compact_ccs_fall` group is required only if a `compact_ccs_fall` group exists within a timing group.

See Also

[pin_based_variation Group](#)

Syntax

```

timing()

...
timing_based_variation(){
    va_parameters (<string>, ...);
    nominal_va_values (<float>, ...);
    va_compact_ccs_rise (template_name) {
        va_values (<float>, ...);
        values ("<float>, ...", ...);
    }
...
}

```

Example

```

timing_based_variation()
va_parameters (channel_length, threshold_voltage) ;
nominal_va_values (0.50, 0.50) ;
va_compact_ccs_rise (LUT4x4) {
    va_values (0.50, 0.45) ;
    values ("0.1, 0.5, 0.6, 0.8, 1, 3", \
            "0.15, 0.55, 0.65, 0.85, 2, 4", \
            ...) ;
}
...
}

```

Complex Attributes

```

va_parameters
nominal_va_values

```

Groups

```

va_compact_ccs_rise
va_compact_ccs_fall

```

```
va_receiver_capacitance1_rise  
va_receiver_capacitance1_fall  
va_receiver_capacitance2_rise  
va_receiver_capacitance2_fall  
va_rise_constraint  
va_fall_constraint
```

For information about the variation-aware CCS receiver model groups (such as `va_receiver_capacitance1_rise`), see [“Variation-Aware CCS Receiver Model Groups”](#).

`va_parameters` Complex Attribute

The `va_parameters` attribute specifies a list of variation parameters within the `timing_based_variation` or `pin_based_variation` groups. The following information applies to the `va_parameters` attribute:

- One or more variation parameters is allowed.
- The variation parameters are represented by a string.
- All `va_parameters` values must be unique.
- The `va_parameters` attribute must be defined before it is referenced by `nominal_va_values` and `va_values`.

The `va_parameters` attribute can be specified within a variation group or at the library level. (The variation groups include `timing_based_variation` and `pin_based_variation`.)

- If `va_parameters` is specified at the library level, all cells under the library default to the same variation parameters.
- If `va_parameters` is defined in a variation group, all `va_values` and `nominal_va_values` attribute values under the same variation group refer to `va_parameters`.

The `va_parameters` values can be parameters that are user-defined or predefined. The parameters defined in `default_operating_conditions` are process, temperature, and voltage.

The voltage names are defined using the `voltage_map` complex attribute. For more information about the `voltage_map` attribute, see [“voltage_map Complex Attribute”](#).

Syntax

```
va_parameters (<string>), ...);
```

Example

```
timing_based_variation()  
    va_parameters (channel_length, threshold_voltage);
```

`nominal_va_values` Complex Attribute

The `nominal_va_values` attribute characterizes nominal values for all variation parameters. The following information applies to the `nominal_va_values` attribute.

- The attribute is required for every `timing_based_variation` group.
- The `nominal_va_values` attribute values map one-to-one to the corresponding `va_parameters` values.
- If the nominal compact CCS driver and the variation-aware compact CCS driver model groups are defined under the same timing group, the `nominal_va_values` values are applied to the nominal compact CCS driver and the variation-aware compact CCS driver groups.

Syntax

```
nominal_va_values (<float>, ...);
```

Example

```
timing_based_variation()  
    va_parameters (channel_length, threshold_voltage)  
    nominal_va_values (0.50, 0.50);
```

`va_compact_ccs_rise` and `va_compact_ccs_fall` Groups

The `va_compact_ccs_rise` and `va_compact_ccs_fall` groups specify characterization corners with variation parameter values. The following information applies to the `va_compact_ccs_rise` and `va_compact_ccs_fall` groups.

- The groups can be specified under different `timing_based_variation` groups if they cannot share the same `va_parameters`.

- The `template_name` value refers to the `compact_lut_template` group.
- You must characterize two corners at each side of the nominal value for all variation parameters specified in `va_parameters`. When corners are characterized for one of the parameters, all other variations are assumed to be nominal values. Therefore, for a `timing_based_variation` group with n variation parameters exactly 2^n characterization corners are required.

Syntax

```
va_compact_ccs_rise (template_name) {
  va_compact_ccs_fall (template_name) {
```

Example

```
timing_based_variation()
  va_parameters (channel_length, threshold_voltage) ;
  nominal_va_values (0.50, 0.50) ;
  va_compact_ccs_rise (LUT4x4) {
    va_values (0.50, 0.45) ;
    values ("0.1, 0.5, 0.6, 0.8, 1, 3", \
            "0.15, 0.55, 0.65, 0.85, 2, 4", \
            ...) ;
  }
  ...
}
va_compact_ccs_fall (LUT4x4) {
  values ("-0.1, -0.5, 0.6, 0.8, 1, 3", \
          "-0.15, -0.55, 0.65, 0.85, 2, 4", \
          "...");
```

Complex Attributes

`va_values`
`values`

va_compact_ccs_retain_rise and va_compact_ccs_retain_fall Groups

The `va_compact_ccs_retain_rise` and `va_compact_ccs_retain_fall` groups in the `timing_based_variation` group specify characterization corners with variation value parameters for retain arcs.

Syntax

```
pin(pin_name) {
  direction : string;
  capacitance : float;
  timing() {
    compact_ccs_rise(template_name) { ... }
    compact_ccs_fall(template_name) { ... }
    timing_based_variation() {
      va_parameters(string, ...);
      nominal_va_values(float, ...);
      va_compact_ccs_retain_rise(template_name) {
        va_values(float, ...);
        values ("...,float,...,integer,...", ...);
      }
      ...
      va_compact_ccs_retain_fall(template_name) {
        va_values(float, ...);
        values ("...,float,...,integer,...", ...);
      }
    ...
  }
```

va_values Complex Attribute

The `va_values` attribute defines the values of each variation parameter for all corners characterized in the variation-aware compact CCS driver and receiver model groups, such as the following groups:

- `va_compact_ccs_rise`
- `va_compact_ccs_fall`
- `va_receiver_capacitance1_rise`
- `va_receiver_capacitance1_fall`
- `va_receiver_capacitance2_rise`
- `va_receiver_capacitance2_fall`

Syntax

```
va_values (<float>, ...);
```

Example

```
va_compact_ccs_rise (LUT4x4) {  
    va_values (0.50, 0.45);
```

values Complex Attribute

The `values` attribute follows the same rules as the nominal compact CCS driver model groups (such as `compact_ccs_rise` and `compact_ccs_fall`) with the following exceptions:

- `left_id` and `right_id` are optional.
- The `left_id` and `right_id` values must be represented in a pair; they can either be omitted or included in the `compact_lut_template`.
- If `left_id` and `right_id` are not defined in the variation-aware compact CCS driver groups, the values default to the values defined in the nominal compact CCS driver model groups. For more information, see [“compact_ccs_rise and compact_ccs_fall Groups”](#).

Syntax

```
values ("..., <float>, ..., <integer>,  
      ...");
```

Example

```
va_compact_ccs_rise (LUT4x4) {  
    va_values (0.50, 0.45);  
    values ("0.1, 0.5, 0.6, 0.8, 1, 3",  
           "0.15, 0.55, 0.65, 0.85, 2, 4",  
           "...");  
}
```

va_rise_constraint and va_fall_constraint Groups

The `va_rise_constraint` and `va_fall_constraint` groups specify characterization corners with variation values in the `timing_based_variation` group. The attributes under these groups undergo screening and checking in the same way as the nominal timing constraint models. The following information applies to the `va_rise_constraint` and `va_fall_constraint` groups.

- All variation-aware constraint groups in the `timing_based_variation` group share the same parameters.
- Both groups can be specified under different `timing_based_variation` groups if they cannot share the same `va_parameters`.
- The `template_name` value refers to the `lu_table_template` group.

Syntax

```
va_rise_constraint (template_name) {  
    va_values (<float>, ...);  
    values ("<float>, ...");  
}  
va_fall_constraint (template_name) {  
    ...  
}
```

Example

```
va_rise_constraint (LUT5x5) {  
    va_values (0.50, 0.45);  
    values ("-0.1452, -0.1452, -0.1452, -0.1452,  
            ...");  
}  
...  
va_fall_constraint (LUT5x5) {  
    va_values (0.55, 0.50);  
    ...  
}
```

Complex Attribute

`va_values`

For information about the `va_values` attribute, see [“`va_values` Complex Attribute”](#).

3.2.16 `tLatch` Group

In timing analysis, use a `tLatch` group to describe the relationship between the data pin and the enable pin on a transparent level-sensitive latch.

You define the `tLatch` group in a `pin` group, but it is only effective if you also define the `timing_model_type` attribute in the cell that the pin belongs to. For more information about the `timing_model_type` attribute, see [“`timing_model_type` Simple Attribute”](#).

Syntax

```
library (namestring) {
    cell (namestring) {
        ...
        timing_model_type : valueenum ;
        ...
        pin (data_pin_namestring) {
            tLatch (enable_pin_namestring)(
                ... tLatch description ...
            )
        }
    }
}
```

Simple Attributes

`edge_type`
`tDisable`

`edge_type` Simple Attribute

Use the `edge_type` attribute to specify whether the latch is positive (high) transparent or negative (low) transparent.

Syntax

`edge_type : nameid ;`

`name`

Valid values are `rising` and `falling`.

Example

```
edge_type : rising ;
```

`tDisable` Simple Attribute

The `tDisable` attribute disables transparency in a latch. During path propagation, all data pin output pin arcs that reference a `tLatch` group whose `tDisable` attribute is set to true on an edge triggered flip flop are disabled and ignored..

Syntax

`tDisable : valueBoolean`

`value`

The valid values are `TRUE` and `FALSE`. When set to `FALSE`, the latch is ignored.

Example

```
tDisable : FALSE ;
```



Index

[A](#) [B](#) [C](#) [D](#) [E](#) [F](#) [G](#) [H](#) [I](#) [J](#) [K](#) [L](#) [M](#) [N](#) [O](#) [P](#) [Q](#) [R](#) [S](#) [T](#) [U](#) [V](#) [W](#) [X](#) [Y](#) [Z](#)

A

area_coefficient attribute [3.2.4](#)

area attribute

 in cell group [2.1.2](#) [3.1.2](#)

 in wire_load group [1.9.45](#)

array value, of base_type [1.9.43](#)

atributes, technology library

 clear_preset_var1 [2.1.4](#)

 clear_preset_var2 [2.1.4](#) [2.1.4](#)

attributes

 technology library

 output_threshold_pct_fall [1.6.22](#)

attributes, related_outputs [2.1.4](#)

attributes, technology library

 area [1.9.45](#) [2.1.2](#) [3.1.2](#)

 area_coefficient [3.2.4](#)

 auxiliary_pad_cell [2.1.2](#)

 base_name [2.1.2](#)

 base_type [2.1.4](#)

 bit_from [1.9.43](#) [2.1.4](#)

 bit_to [1.9.43](#) [2.1.4](#)

 bit_width [1.9.43](#) [2.1.4](#) [3.1.2](#)

 bus_naming_style [1.6.1](#) [2.1.2](#)

 bus_type [2.1.4](#)

 calc_mode [1.9.19](#) [1.9.24](#) [1.9.29](#) [1.9.31](#)

 capacitance [1.9.45](#) [1.9.45](#) [2.1.4](#) [2.1.4](#) [3.1.2](#)

 capacitive_load_unit [1.8.1](#)

 cell_footprint [2.1.2](#)

 cell_leakage_power [2.1.2](#)

 cell_name [2.2.1](#)

 clear [2.1.4](#) [2.1.4](#) [2.1.4](#)

 clear_preset_var1 [2.1.4](#)

 clock [3.1.2](#)

 clock_gate_clock_pin [3.1.2](#)

 clock_gate_enable_pin [3.1.2](#)

 clock_gate_obs_pin [3.1.2](#)

 clock_gate_out_pin [3.1.2](#)

 clock_gate_test_pin [3.1.2](#)

 clock_gating_integrated_cell [2.1.2](#)

 clock_pin [2.1.4](#)

 clocked_on [2.1.4](#) [2.1.4](#)

 clocked_on_also [2.1.4](#) [2.1.4](#)

 coefs [3.2.13](#) [3.2.13](#) [3.2.15](#) [3.2.15](#) [3.2.15](#) [3.2.15](#)

 comment [1.6.2](#)

 complimentary_pin [3.1.2](#)

 connection_class [3.1.2](#)

 constraint [3.2.12](#)

 constraint_high [3.2.11](#)

 constraint_low [3.2.11](#)

 contention_condition [2.1.2](#)

 current_unit [1.6.3](#)

 data_type [1.9.43](#) [2.1.4](#)

 date [1.6.4](#) [1.6.4](#)

 default_fpga_isd [1.6.5](#)

 default_part [1.8.2](#)

 default_step_level [1.9.27](#)

 default_threshold_voltage_group [1.6.6](#)

define [1.8.3](#)
define_cell_area [1.8.4](#)
define_group [1.8.5](#)
delay_model [1.6.7](#)
direction [2.1.4](#) [2.1.4](#) [2.1.4](#) [3.1.2](#)
divided_by [2.1.4](#)
dont_fault [2.1.2](#) [3.1.2](#)
dont_touch attribute [2.1.2](#)
dont_use [2.1.2](#)
downnto [1.9.43](#)
drive [1.9.17](#)
drive_current [3.1.2](#)
drive_type [2.1.2](#)
driver_type [3.1.2](#)
duty_cycle [2.1.4](#)
edge_type [3.2.16](#)
edges [2.1.4](#)
edif_name [2.1.2](#)
em_temp_degradation_factor [1.6.11](#) [2.1.2](#)
fall_capacitance [3.1.2](#)
fall_capacitance_range [3.1.3](#)
fall_current_slope_after_threshold [3.1.2](#)
fall_current_slope_before_threshold [3.1.2](#)
fall_delay_intercept [3.2.15](#)
fall_pin_resistance [3.2.15](#)
fall_resistance [3.2.15](#)
fall_time_after_threshold [3.1.2](#)
fall_time_before_threshold [3.1.2](#)
falling_together_group [3.2.8](#)
fanout_length [1.9.45](#)
fanout_load [3.1.2](#)
faster_factor [1.9.42](#)
fault [3.1.2](#)
fault_model [3.1.2](#)
fpga_arc_condition [2.1.4](#) [3.2.15](#)
fpga_cell_type [2.1.2](#)
fpga_domain_style [1.6.12](#) [2.1.2](#) [3.2.15](#)
fpga_isd
 in cell group [2.1.2](#)
 in part group [1.9.27](#)
 in speed_grade group [1.9.27](#)
fpga_technology [1.6.13](#)
function [2.1.4](#) [3.1.2](#) [3.1.2](#)
handle_negative_constraint [2.1.2](#)
has_builtin_pad [3.1.2](#)
height_coefficient [3.2.4](#)
hysteresis [3.1.2](#)
in_place_swap_mode [1.6.14](#)
include_file [1.3](#)
index_output [2.1.4](#) [2.1.4](#)
input_map [3.1.2](#)
input_signal_level [3.1.2](#)
input_switching_condition [2.1.4](#)
input_threshold_pct_fall [1.6.15](#) [3.1.2](#)
input_threshold_pct_rise [1.6.16](#) [3.1.2](#)
input_voltage [3.1.2](#)
interdependence_id [3.2.15](#)
interface_timing [2.1.2](#)
internal_node [3.1.2](#)
intrinsic_rise [3.2.15](#)
invert [2.1.4](#)
inverted_output [3.1.2](#)
io_type [1.9.17](#) [2.1.2](#)
is_inverting [3.2.1](#)
is_level_shifter [2.1.2](#) [2.1.2](#) [2.1.2](#)
is_needed [3.2.1](#)
is_pad [3.1.2](#)
isolation_cell_enable_pin [3.1.2](#)
leakage_power_unit [1.6.17](#)
level_shifter_enable_pin [3.1.2](#)
library_features [1.8.6](#)

map_only [2.1.2](#)
map_to_logic [3.1.2](#)
mapping [1.9.29](#) [1.9.31](#)
master_pin [2.1.4](#)
max_capacitance [3.1.2](#)
max_count [1.9.27](#)
max_fanout [3.1.2](#)
max_input_noise [3.1.2](#)
max_transition [3.1.2](#)
members [2.1.4](#) [2.1.4](#)
miller_cap_fall [3.2.1](#)
miller_cap_rise [3.2.1](#)
min_capacitance [3.1.2](#)
min_fanout [3.1.2](#)
min_input_noise [3.1.2](#)
min_period [3.1.2](#)
min_pulse_width_high [3.1.2](#)
min_pulse_width_low [3.1.2](#)
mode [3.2.15](#)
multicell_pad_pin [3.1.2](#)
multiplied_by [2.1.4](#)
next_state [2.1.4](#) [2.1.4](#)
nextstate_type [3.1.2](#)
nom_calc_mode [1.6.18](#)
nom_process [1.6.19](#)
nom_temperature [1.6.20](#)
nom_voltage [1.6.21](#)
num_blockrams [1.9.27](#)
num_cols [1.9.27](#)
num_ffs [1.9.27](#)
num_luts [1.9.27](#)
num_rows [1.9.27](#)
orders [1.9.29](#) [3.2.13](#) [3.2.13](#) [3.2.15](#) [3.2.15](#) [3.2.15](#) [3.2.15](#) [3.2.15](#)
output_signal_level [3.1.2](#)
output_switching_condition [2.1.4](#)
output_threshold_pct_rise [1.6.23](#)
output_voltage [3.1.2](#)
pad_cell [2.1.2](#)
pad_type [2.1.2](#)
pg_type [2.1.4](#)
piece_define [1.8.7](#)
piece_type [1.6.24](#)
pin_count [1.9.27](#)
pin_equal [2.1.3](#)
pin_func_type [3.1.2](#)
pin_opposite [2.1.3](#)
power_cell_type [2.1.2](#)
power_gating_cell [2.1.2](#)
power_gating_pin [3.1.3](#)
power_level [2.1.4](#)
power_rail
 in operating_conditions group [1.9.24](#)
 in power_supply group [1.9.32](#)
prefer_tied [3.1.2](#)
preferred [2.1.2](#)
preferred_input_pad_voltage [1.6.27](#)
preferred_output_pad_slew_rate [1.6.25](#) [1.6.26](#)
preferred_output_pad_voltage [1.6.28](#)
preset [2.1.4](#) [2.1.4](#) [2.1.4](#) [2.1.4](#)
primary_output [3.1.2](#)
process [1.9.24](#)
pulling_current [3.1.2](#)
pulling_resistance [3.1.2](#)
pulling_resistance_unit [1.6.29](#)
pulse_clock [3.1.2](#)
rail_connection [2.1.3](#)
reference_time [2.1.4](#) [2.1.4](#) [3.2.15](#)
related_bus_pins [3.2.3](#)
related_ground_pin [3.1.2](#)
related_inputs [2.1.4](#)
related_outputs [2.1.4](#)

related_pg_pin [2.1.4](#)
related_pin [3.2.3](#)
related_power_pin [3.1.2](#)
resistance [1.9.45](#) [1.9.45](#)
resource_usage [2.1.3](#)
revision [1.6.30](#)
rise_capacitance [3.1.2](#)
rise_capacitance_range [3.1.3](#)
rise_current_slope_after_threshold [3.1.2](#)
rise_current_slope_before_threshold [3.1.2](#)
rise_resistance [3.2.15](#)
rise_time_after_threshold [3.1.2](#)
rise_time_before_threshold [3.1.2](#)
routing_layers [1.8.8](#)
scaling_factors [2.1.2](#)
sdf_cond [2.1.4](#) [3.2.11](#) [3.2.11](#) [3.2.12](#) [3.2.12](#) [3.2.15](#)
sdf_cond_end [3.2.15](#)
sdf_cond_start [3.2.15](#)
shifts [2.1.4](#)
short (model group) [2.2.1](#)
signal_type [2.1.4](#) [3.1.2](#)
simulation [1.6.31](#)
single_bit_degenerate attribute [2.1.2](#)
slew [1.9.17](#)
slew_derate_from_library [1.6.32](#)
slew_lower_threshold_pct_fall [1.6.33](#) [3.1.2](#)
slew_lower_threshold_pct_rise [1.6.34](#) [3.1.2](#)
slew_type [2.1.2](#)
slew_upper_threshold_pct_fall [1.6.35](#) [3.1.2](#)
slew_upper_threshold_pct_rise [1.6.36](#) [3.1.2](#)
slope_fall [3.2.15](#)
slope_rise [3.2.15](#)
slowest_factor [1.9.42](#)
stage_type [3.2.1](#) [3.2.1](#)
state_function [3.1.2](#)
steady_state_resistance_above_high [3.2.15](#)
steady_state_resistance_below_low [3.2.15](#)
steady_state_resistance_high [3.2.15](#)
steady_state_resistance_low [3.2.15](#)
step_level [1.9.27](#)
switching_interval [3.2.8](#)
switching_together [3.2.8](#)
tdisable [3.2.16](#)
technology [1.8.9](#)
temperature [1.9.24](#)
test_output_only [3.1.2](#)
three_state [3.1.2](#)
threshold_voltage_group [2.1.2](#)
tied_off [3.2.15](#)
time_unit [1.6.37](#)
timing_model_type [2.1.2](#)
timing_sense [3.2.15](#)
timing_type [3.2.15](#)
total_track_area [2.1.4](#)
tracks [2.1.4](#)
tree_type [1.9.24](#)
typical_capacitances [2.1.4](#)
use_for_size_only [2.1.2](#)
valid_speed_grade [1.9.27](#)
valid_step_levels [1.9.27](#)
value [2.1.4](#) [2.1.4](#) [2.1.4](#)
variable_n_range [1.9.29](#) [1.9.31](#) [3.2.13](#) [3.2.13](#)
variables [1.9.29](#) [1.9.29](#) [1.9.31](#) [1.9.31](#)
vhdl_name [2.1.2](#) [3.1.2](#)
voltage [1.9.24](#)
voltage_map [1.8.10](#)
voltage_name [2.1.4](#)
voltage_unit [1.6.38](#)
when [2.1.4](#) [3.2.3](#) [3.2.11](#) [3.2.12](#) [3.2.15](#)
 in dynamic_current group [2.1.4](#)
 in intrinsic_parasitic group [2.1.4](#)

in leakage_current group [2.1.4](#)
when_end [3.2.15](#) [3.2.15](#)
width_coefficient [3.2.4](#)
x_function [3.1.2](#)

attributes, user-defined [1.8.3](#)

auxiliary_pad_cell attribute [2.1.2](#)

B

backslash, as escape character [2.1.4](#) [3.1.2](#)

base_curve_type attribute [1.9.2](#)

base_name attribute [2.1.2](#)

base_type attribute [1.9.43](#) [2.1.4](#)

bit_from attribute [1.9.43](#) [2.1.4](#)

bit_to attribute [1.9.43](#) [2.1.4](#)

bit_width attribute [1.9.43](#)

 in pin group [3.1.2](#)

 in type group [2.1.4](#)

bit width of multibit cell [2.1.4](#)

Boolean

 operators, valid [2.1.4](#) [3.1.2](#) [3.2.8](#)

bundle group

 bundle members [2.1.4](#)

 bundle names [2.1.4](#)

 capacitance attribute [2.1.4](#)

 direction attribute [2.1.4](#)

 function attribute [2.1.4](#)

 members attribute [2.1.4](#) [2.1.4](#)

 pin attributes [2.1.4](#)

 pin group in [2.1.4](#)

 pin names [2.1.4](#)

bus_hold pin [3.1.2](#)

bus_naming_style attribute [1.6.1](#) [2.1.2](#)

 characters in [1.6.1](#)

 symbols in [1.6.1](#)

bus_type attribute [2.1.4](#)

bus, reversing order [3.1.2](#)

bus group

 bus_type attribute [2.1.4](#)

 bus pin [2.1.4](#) [2.1.4](#)

 capacitance attribute [2.1.4](#) [2.1.4](#)

 direction attribute [2.1.4](#)

 in multibit flip-flop registers [2.1.4](#)

 in multibit latch registers [2.1.4](#)

 pin attributes [2.1.4](#)

 pin group [2.1.4](#)

 type group, use in [1.9.43](#)

bus pin

 in bundle group

 example [2.1.4](#)

 specifying default attributes [2.1.4](#)

 overriding default attributes [2.1.4](#)

 specifying default attributes [2.1.4](#)

bus pin group
 bus members in flip-flop bank [2.1.4](#)
 example [2.1.4](#)
 naming convention [2.1.4](#)

C

calc_mode attribute
 in lu_table_template group [1.9.19](#)
 in operating_conditions group [1.9.24](#)
 in poly_template group [1.9.29](#)
 in power_poly_template group [1.9.31](#)

capacitance
 in pin group in bundle group [2.1.4](#)
 load units [1.8.1](#)
 wire length [1.8.7](#)

capacitance attribute
 in bundle group [2.1.4](#)
 in bus group [2.1.4](#)
 in pin group [3.1.2](#)
 in wire_load group [1.9.45](#) [1.9.45](#)

capacitance group [3.2.13](#)

capacitive_load_unit attribute [1.8.1](#)

ccsn_first_stage group [3.2.1](#)

ccsn_last_stage group [3.2.2](#)

cell_degradation group [3.2.15](#)

cell_fall group [3.2.15](#)

cell_footprint attribute [2.1.2](#)

cell_leakage_power attribute [2.1.2](#)

cell_name attribute [2.2.1](#)

cell_rise group [3.2.15](#)

cell delay

 cell_fall group [3.2.15](#)
 cell_rise group [3.2.15](#)

cell group

 area attribute [2.1.2](#) [3.1.2](#)
 clock_gating_integrated_cell attribute [2.1.2](#)
 example, CMOS [2.1.4](#)
 ff_bank group [2.1.4](#)
 ff group [2.1.4](#)
 group statements
 bundle [2.1.4](#)
 latch [2.1.4](#)
 latch_bank [2.1.4](#)
 leakage_current [2.1.4](#)
 leakage_power [2.1.4](#)
 lut [2.1.4](#)
 pin [3.1](#)
 routing_track [2.1.4](#) [2.1.4](#)
 statetable [2.1.4](#)
 test_cell [2.1.4](#)
 type [2.1.4](#)
 is_isolation_cell attribute [2.1.2](#)
 is_level_shifter attribute [2.1.2](#) [2.1.2](#)
 lut group [2.1.4](#)
 syntax [2.1](#)

cell swapping
in_place_swap_mode attribute [1.6.14](#)

clear_preset_var1 attribute
in ff_bank group [2.1.4](#)
in ff group [2.1.4](#)

clear_preset_var2 attribute
in ff_bank group [2.1.4](#)
in ff group [2.1.4](#)

clear, timing_type value [3.2.15](#)

clear attribute
in ff_bank group [2.1.4](#)
in ff group [2.1.4](#)
in latch_bank group [2.1.4](#)
in latch group [2.1.4](#)

clock_gate_clock_pin attribute [3.1.2](#)

clock_gate_enable_pin attribute [3.1.2](#)

clock_gate_obs_pin attribute [3.1.2](#)

clock_gate_out_pin attribute [3.1.2](#)

clock_gate_test_pin attribute [3.1.2](#)

clock_gating_flag attribute [3.2.15](#)

clock_gating_integrated_cell attribute
defined [2.1.2](#)
setting pin attributes [2.1.2](#)

clock_pin attribute [2.1.4](#)

clock attribute [3.1.2](#)

clocked_on_also attribute [2.1.4](#) [2.1.4](#)

clocked_on attribute [2.1.4](#) [2.1.4](#)

clock pin
active edge [2.1.4](#) [2.1.4](#)
min_period attribute [3.1.2](#)

CMOS, library group example [1.5](#)

coefs attribute [3.2.13](#) [3.2.13](#) [3.2.15](#) [3.2.15](#) [3.2.15](#) [3.2.15](#)
in lower group [3.2.13](#)

comment attribute [1.6.2](#)

compact_ccs_power group [2.1.4](#)

compacts CCS power [2.1.4](#)

complex sequential cells [2.1.4](#)

complimentary_pin attribute [3.1.2](#)

composite current source
template variables [3.2.15](#) [3.2.15](#)

conditional timing check
in timing group [3.2.15](#)
in VITAL models [3.2.15](#)

connection_class attribute [3.1.2](#)

constraint_high attribute [3.2.11](#)

constraint_low attribute [3.2.11](#)

constraint attribute [3.2.12](#)

constraint table

 lu_table_template group
 constrained_pin_transition [1.9.19](#) [1.9.19](#)

cont_layer group [1.6.10](#)

contention_condition attribute [2.1.2](#)

control signals in multibit register [2.1.4](#) [2.1.4](#)

copyright information [1.6.2](#)

critical_area_lut_template group [1.6.9](#)

critical_area_table group [2.1.4](#)

current_unit attribute [1.6.3](#)

curve_x attribute [1.9.3](#)

curve_y attribute [1.9.4](#)

D

data_in attribute

 for latches [2.1.4](#) [2.1.4](#) [2.1.4](#)
 in latch_bank group [2.1.4](#)

data_type attribute [1.9.43](#) [2.1.4](#)

date attribute [1.6.4](#)

dc_current_template group [1.9.11](#)

dc_current group [3.2.1](#)

dc_shell

 set_dont_touch command [2.1.2](#)
 set_map_only command [2.1.2](#)

default_cell_leakage_power attribute [1.7](#)

default_connection_class attribute [1.7](#)

default_fall_delay_intercept attribute [1.7](#)

default_fall_pin_resistance attribute [1.7](#)

default_fanout_load attribute [1.7](#)

default_fpga_isd attribute [1.6.5](#)

default_inout_pin_cap attribute [1.7](#)

default_inout_pin_fall_res attribute [1.7](#)

default_inout_pin_rise_res attribute [1.7](#)

default_input_pin_cap attribute [1.7](#)

default_intrinsic_fall attribute [1.7](#)

default_intrinsic_rise attribute [1.7](#)

default_leakage_power_density attribute [1.7](#)

default_max_capacitance attribute [1.7](#)

default_max_fanout attribute [1.7](#)

default_max_transition attribute [1.7](#)

default_max_utilization attribute [1.7](#)
default_min_porosity attribute [1.7](#)
default_operating_conditions attribute [1.7](#)
default_output_pin_cap attribute [1.7](#)
default_output_pin_fall_res attribute [1.7](#)
default_output_pin_rise_res attribute [1.7](#)
default_part attribute [1.8.2](#)
default_rise_delay_intercept attribute [1.7](#)
default_rise_pin_resistance attribute [1.7](#)
default_slope_fall attribute [1.7](#)
default_slope_rise attribute [1.7](#)
default_step_level attribute [1.9.27](#)
default_threshold_voltage_group attribute [1.6.6](#)
default_timing attribute [3.2.15](#)
default_wire_load_area attribute [1.7](#)
default_wire_load_capacitance attribute [1.7](#)
default_wire_load_model attribute [1.7](#)
default_wire_load_resistance attribute [1.7](#)
default_wire_load_selection attribute [1.7](#)
default_wire_load attribute [1.7](#)
default attributes
 overriding [1.7](#)
 values [1.7](#)
default pin attributes [1.7](#)
defect_type attribute [2.1.4](#)
define_cell_area attribute [1.8.4](#)
define_group attribute [1.8.5](#)
define attribute [1.8.3](#)
delay_model attribute [1.6.7](#)
 delay models supported [1.6.7](#)
design translation [2.1.2](#)
device_layer group [1.6.10](#)
D flip-flop [2.1.4](#) [2.1.4](#)
differential I/O
 complementary_pin attribute [3.1.2](#)
 definition [3.1.2](#)
 fault_model attribute [3.1.2](#)
direction attribute
 in bundle group [2.1.4](#)
 in bus group [2.1.4](#)
 in pin group [3.1.2](#)
 in test_cell group [2.1.4](#)

dist_conversion_factor attribute [1.6.8](#)

distance_unit attribute [1.6.8](#)

divided_by attribute [2.1.4](#)

domain group

- in cell_fall group [3.2.15](#)
- in cell_rise group [3.2.15](#)
- in fall_constraint group [3.2.15](#)
- in fall_power group [3.2.8](#)
- in fall_propagation group [3.2.15](#)
- in fall_transition group [3.2.15](#)
- in lu_table_template group [1.9.19](#)
- in noise_immunity_above_high group [3.2.15](#)
- in poly_template group [1.9.29](#) [1.9.30](#)
- in power_poly_template group [1.9.31](#)
- in power group [3.2.8](#)
- in propagated_noise_height_above_high group [3.2.15](#)
- in retaining_fall group [3.2.15](#)
- in retaining_rise group [3.2.15](#)
- in rise_power group [3.2.8](#)
- in rise_propagation group [3.2.15](#)
- in rise_transition group [3.2.15](#)
- in steady_state_current_high group [3.2.15](#)
- in timing group [3.2.15](#)

dont_fault attribute [2.1.2](#) [3.1.2](#)

dont_touch attribute [2.1.2](#)

dont_use attribute [2.1.2](#)

downto attribute [1.9.43](#) [2.1.4](#)

drive_current attribute [3.1.2](#)

drive_type attribute [2.1.2](#)

drive attribute [1.9.17](#)

drive capability [3.2.15](#)

driver_type attribute [3.1.2](#)

driver types, multiple [3.1.2](#)

duty_cycle attribute [2.1.4](#)

dynamic_current group [2.1.4](#)

E

edge_type attribute [3.2.16](#)

edges attribute [2.1.4](#)

edif_name attribute [2.1.2](#)

electromigration group [3.2.3](#)
when attribute [3.2.3](#)

em_lut_template group [1.9.12](#)

em_max_toggle_rate group [3.2.3](#)

em_temp_degradation_factor attribute [1.6.11](#) [2.1.2](#)

enable attribute

- for latches [2.1.4](#)
- in latch_bank group [2.1.4](#)

in latch group [2.1.4](#) [2.1.4](#)

F

fall_capacitance_range attribute [3.1.3](#)

fall_capacitance_range group [3.2.13](#) [3.2.13](#)

fall_capacitance attribute
in pin group [3.1.2](#)

fall_capacitance group [3.2.13](#)

fall_constraint group [3.2.15](#)

fall_current_slope_after_threshold attribute [3.1.2](#)

fall_current_slope_before_threshold attribute [3.1.2](#)

fall_delay_intercept attribute [3.2.15](#)

fall_net_delay group [1.9.13](#)

fall_pin_resistance attribute [3.2.15](#)

fall_power group [3.2.8](#)

fall_propagation group [3.2.15](#)

fall_resistance attribute [3.2.15](#)

fall_time_after_threshold attribute [3.1.2](#)

fall_time_before_threshold attribute [3.1.2](#)

fall_transition_degradation group [1.9.14](#)

fall_transition group [3.2.15](#)

falling_edge, timing_type value [3.2.15](#)

falling_together_group attribute [3.2.8](#)

falling-edge-triggered-devices [2.1.4](#)

fanout

control signals in multibit register [2.1.4](#) [2.1.4](#)

fanout_length attribute [1.9.45](#)

fanout_load attribute [3.1.2](#)

faster_factor attribute [1.9.42](#)

fault_model attribute [3.1.2](#)

ff_bank group [2.1.4](#)

clear_preset_var1 attribute [2.1.4](#)

clear_preset_var2 attribute [2.1.4](#)

clear attribute [2.1.4](#)

data_in attribute [2.1.4](#)

in test cell group [2.1.4](#)

next_state attribute [2.1.4](#)

preset attribute [2.1.4](#)

ff group

clear_preset_var1 attribute [2.1.4](#)

clear_preset_var2 attribute [2.1.4](#)

in test_cell group [2.1.4](#)

master-slave flip-flop [2.1.4](#)

next_state attribute [2.1.4](#)

preset attribute [2.1.4](#)

single-stage D flip-flop [2.1.4](#) [2.1.4](#)

file size, reducing [1.3](#)

flip-flop

D [2.1.4](#) [2.1.4](#)

JK [2.1.4](#)

JK with scan [2.1.4](#) [2.1.4](#)

master-slave [2.1.4](#)

single-stage [2.1.4](#)

footprint class [2.1.2](#)

fpga_arc_condition attribute [2.1.4](#) [3.2.15](#)

fpga_cell_type attribute [2.1.2](#)

fpga_condition_value group [2.1.4](#)

fpga_condition group [2.1.4](#)

fpga_domain_style attribute

in cell group [2.1.2](#)

in library group [1.6.12](#)

in pin group [3.2.15](#)

fpga_isd attribute

in cell group [2.1.2](#)

in part group [1.9.27](#)

in speed_grade group [1.9.27](#)

fpga_isd group [1.9.17](#)

fpga_technology attribute [1.6.13](#)

function attribute

bused pin names [2.1.4](#)

in bundle group [2.1.4](#)

in pin group [3.1.2](#)

of bus pins [2.1.4](#) [3.1.2](#) [3.1.2](#)

pin names as arguments [2.1.4](#)

G

gate mapping [2.1.2](#)

generated_clock Group [2.1.4](#)

group statements

cell group

dc_current [3.2.1](#)

domain [1.9.31](#)

dynamic_current [2.1.4](#)

electromigration [3.2.3](#)

intrinsic_capacitance [2.1.4](#)

intrinsic_parasitic [2.1.4](#)

intrinsic_resistance [2.1.4](#)

lu_table_template [1.9.19](#)

out_put_rise [3.2.1](#)

output_fall [3.2.1](#)

propogated_noise_high [3.2.1](#)

propogated_noise_low [3.2.1](#)

switching_group [2.1.4](#) [2.1.4](#) [2.1.4](#)

syntax

capacitance group [3.2.13](#)

cell_degradation [3.2.15](#)

cell_fall [3.2.15](#)

cell_rise [3.2.15](#)

cell group

dc_current_template [1.9.11](#)

domain [1.9.19](#) [1.9.29](#) [1.9.30](#)

fall_capacitance [3.2.13](#)
fall_capacitance_range [3.2.13](#)
fall_net_delay [1.9.13](#)
fall_transition_degradation [1.9.14](#)
fpga_condition [2.1.4](#)
fpga_condition_value [2.1.4](#)
fpga_isd [1.9.17](#)
hyperbolic_noise_above_high [3.2.4](#)
hyperbolic_noise_below_low [3.2.5](#)
hyperbolic_noise_high [3.2.6](#)
hyperbolic_noise_low [3.2.7](#)
iv_lut_template [1.9.18](#)
lower [3.2.13](#)
max_cap [3.2.9](#)
max_trans [3.2.10](#)
maxcap_lut_template [1.9.20](#)
maxtrans_lut_template [1.9.21](#)
min_pulse_width [3.2.11](#)
minimum_period [3.2.12](#)
mode_definition [2.1.4](#)
noise_immunity_above_high [3.2.15](#)
noise_immunity_below_low [3.2.15](#)
noise_immunity_high [3.2.15](#)
noise_immunity_low [3.2.15](#)
noise_lut_template [1.9.22](#)
operating_conditions [1.9.24](#)
output_current_fall [3.2.15](#)
output_current_rise [3.2.15](#)
part [1.9.27](#)
pg_current_template [1.9.28](#)
pg_pin [2.1.4](#)
pin_capacitance [3.2.13](#)
poly_template [1.9.29](#)
power_lut_template [1.9.30](#)
power_poly_template [1.9.31](#)
power_supply [1.9.32](#)
propagated_lut_template [1.9.33](#)
propagated_noise_height_above_high [3.2.15](#)
propagated_noise_height_below_low [3.2.15](#)
propagated_noise_height_high [3.2.15](#)
propagated_noise_height_low [3.2.15](#)
propagated_noise_peak_time_ratio_above_high [3.2.15](#)
propagated_noise_peak_time_ratio_below_low [3.2.15](#)
propagated_noise_peak_time_ratio_low [3.2.15](#)
propagated_noise_width_above_high [3.2.15](#)
propagated_noise_width_below_low [3.2.15](#)
propagated_noise_width_high [3.2.15](#)
propagated_noise_width_low [3.2.15](#)
propagated_peak_time_ratio_width_high [3.2.15](#)
receiver_capacitance [3.2.14](#)
receiver_capacitance1_fall [3.2.14](#) [3.2.15](#)
receiver_capacitance1_rise [3.2.14](#) [3.2.15](#)
receiver_capacitance2_fall [3.2.14](#) [3.2.15](#)
receiver_capacitance2_rise [3.2.14](#) [3.2.15](#)
retain_fall_slew [3.2.15](#)
retain_rise_slew [3.2.15](#)
rise_capacitance [3.2.13](#)
rise_capacitance_range [3.2.13](#)
rise_net_delay [1.9.34](#)
rise_transition_degradation [1.9.35](#)
routing_track [2.1.4](#)
scaled_cell [1.9.36](#)
scaling_factors [1.9.40](#)
speed_grade [1.9.27](#)
steady_state_current_high [3.2.15](#)
steady_state_current_low [3.2.15](#)
steady_state_current_tristate [3.2.15](#)
timing [1.9.41](#)
timing_range [1.9.42](#)
type [1.9.43](#)
upper [3.2.13](#)

user_parameters [1.9.44](#)
user-defined [1.8.5](#)
vector [3.2.15](#)
wire_load [1.9.45](#)
wire_load_selection [1.9.46](#)
wire_load_table [1.9.47](#)
user-defined [1.8.5](#)
vector [2.1.4](#)

H

handle_negative_constraint attribute [2.1.2](#)
has_builtin_pad attribute [3.1.2](#)
height_coefficient attribute [3.2.4](#)
high-active clock signal [2.1.4](#)
high-impedance state [3.1.2](#)
hold_falling, timing_type value [3.2.15](#)
hold_rising, timing_type value [3.2.15](#)
hyperbolic_noise_above_high group [3.2.4](#)
hyperbolic_noise_below_low group [3.2.5](#)
hyperbolic_noise_high group [3.2.6](#)
hyperbolic_noise_low group [3.2.7](#)
hysteresis attribute [3.1.2](#)

I

in_place_swap_mode attribute [1.6.14](#)
report_lib, use of [1.6.14](#)
include_file attribute [1.3](#)
index_1 attribute [2.1.4](#)
 em_lut_template group [1.9.12](#)
 in lu_table_template group [1.9.18](#)
 in power_lut_template group [1.9.30](#)
index_2 attribute
 em_lut_template group [1.9.12](#)
 in lu_table_template group [1.9.18](#)
 in power_lut_template group [1.9.30](#)
index_3 attribute
 in lu_table_template group [1.9.18](#)
 in power_lut_template group [1.9.30](#)
index_output attribute [2.1.4](#) [2.1.4](#)
in-place optimization [1.6.14](#)
input_map attribute [3.1.2](#)
input_signal_level attribute [3.1.2](#)
input_switching_condition attribute [2.1.4](#)
input_threshold_pot_fall attribute [1.6.15](#) [3.1.2](#)
input_threshold_pct_rise attribute [1.6.16](#) [3.1.2](#)

input_voltage group [1.9.16](#)

variables [1.9.16](#)

interdependence_id attribute

in pin group [3.2.15](#)

interface_timing attribute [2.1.2](#)

internal_node attribute [3.1.2](#)

internal_power group [3.2.8](#)

equal_or_opposite_output attribute [3.2.8](#)

fall_power group [3.2.8](#)

falling_together_group attribute [3.2.8](#)

one-dimensional table [3.2.8](#)

power_level attribute [3.2.8](#)

power group [3.2.8](#)

related_pin attribute [3.2.8](#)

rise_power attribute [3.2.8](#)

rising_together_group attribute [3.2.8](#)

switching_interval attribute [3.2.8](#)

switching_together_group attribute [3.2.8](#)

three-dimensional table [3.2.8](#)

two-dimensional table [3.2.8](#)

when attribute [3.2.8](#)

intrinsic_capacitance group [2.1.4](#)

intrinsic_parasitic group [2.1.4](#)

intrinsic_resistance group [2.1.4](#)

intrinsic_rise attribute [3.2.15](#)

invert attribute [2.1.4](#)

inverted_output attribute [3.1.2](#)

io_type attribute [1.9.17](#) [2.1.2](#)

is_inverting attribute [3.2.1](#)

is_isolation_cell attribute [2.1.2](#)

is_level_shifter attribute [2.1.2](#) [2.1.2](#)

is_needed attribute [3.2.1](#)

is_pad attribute [3.1.2](#)

is_pll_cell attribute [2.1.2](#)

is_pll_feedback_pin attribute [3.1.2](#)

is_pll_output_pin attribute [3.1.2](#)

is_pll_reference_pin attribute [3.1.2](#)

isolation_cell_enable_pin attribute [3.1.2](#)

iv_lut_template group [1.9.18](#)

J

JK flip-flop [2.1.4](#) [2.1.4](#) [2.1.4](#)

L

latch_bank group [2.1.4](#)

enable attribute [2.1.4](#)
in test_cell group [2.1.4](#)
preset attribute [2.1.4](#)

latch group
in cell group [2.1.4](#)
in test cell group [2.1.4](#)

leakage_current group [2.1.4](#)

leakage_power_unit attribute [1.6.17](#)

leakage_power group [2.1.4](#)

leakage power, defining cell [2.1.2](#)

level_shifter_enable_pin attribute [3.1.2](#)

level-sensitive memory devices [2.1.4](#)

libraries, power units in [1.6.17](#)

library_features attribute [1.8.6](#)

library group, technology library
examples, CMOS [1.5](#)
naming [1.4](#)
syntax [1.2](#)

library groups, technology library
em_lut_template [1.9.12](#)
fall_net_delay [1.9.13](#)
fall_transition_degradation [1.9.14](#)
input_voltage [1.9.16](#)
lu_table_template [1.9.19](#)
operating_conditions [1.9.24](#)
output_current_template [1.9.25](#)
output_voltage [1.9.26](#)
part [1.9.27](#)
power_lut_template [1.9.30](#)
power_supply group [1.9.32](#)
rise_net_delay [1.9.34](#)
rise_transition_degradation [1.9.35](#)
scaled_cell [1.9.36](#)
scaling_factors [1.9.40](#)
timing [1.9.41](#)
timing_range [1.9.42](#)
type [1.9.43](#)
user_parameters [1.9.44](#)
wire_load [1.9.45](#)
wire_load_selection [1.9.46](#)
wire_load_table [1.9.47](#)

low-active
clear signal [2.1.4](#)
clock signal [2.1.4](#)

lower group [3.2.13](#)

LSSD methodology
pin identification [2.1.4](#) [3.1.2](#)

lu_table_template group [1.9.19](#)

lut group [2.1.4](#)

map_only attribute [2.1.2](#)

map_to_logic attribute [3.1.2](#)

M

mapping attribute [1.9.29](#) [1.9.31](#)

master_pin attribute [2.1.4](#)

master-slave

 clocks [2.1.4](#) [2.1.4](#)

 flip-flop [2.1.4](#)

max_capacitance attribute [3.1.2](#)

max_cap group [3.2.9](#)

max_clock_tree_path, timing_type value [3.2.15](#)

max_count attribute [1.9.27](#)

max_fanout attribute [3.1.2](#)

max_input_noise attribute [3.1.2](#)

max_trans group [3.2.10](#)

max_transition attribute [3.1.2](#)

maxcap_lut_template group [1.9.20](#)

maxtrans_lut_template group [1.9.21](#)

member pins [2.1.4](#)

members attribute [2.1.4](#)

 in bundle group [2.1.4](#)

miller_cap_fall attribute [3.2.1](#)

miller_cap_rise attribute [3.2.1](#)

min_capacitance attribute [3.1.2](#)

min_clock_tree_path, timing_type value [3.2.15](#)

min_fanout attribute [3.1.2](#)

min_input_noise attribute [3.1.2](#)

min_period attribute [3.1.2](#)

min_pulse_width_high attribute [3.1.2](#)

min_pulse_width_low attribute [3.1.2](#)

min_pulse_width group [3.2.11](#)

 constraint_high attribute [3.2.11](#)

 constraint_low attribute [3.2.11](#)

 sdf_cond attribute [3.2.11](#)

 when attribute [3.2.11](#)

minimum_period, timing_type value [3.2.15](#)

minimum_period group

 constraint attribute [3.2.12](#)

 in pin group [3.2.12](#)

 sdf_cond attribute [3.2.12](#)

 when attribute [3.2.12](#)

minimum_pulse_width, timing_type value [3.2.15](#)

mode_definition group

 syntax [2.1.4](#)

mode attribute [3.2.15](#)

model group

 syntax [2.2](#)

modeling
capacitance
 total pin [1.6.24](#)
 total pin and wire [1.6.24](#)
 wire [1.6.24](#)

multibit registers
 flip-flop [2.1.4](#)

multicell_pad_pin attribute [3.1.2](#)

multiple paths [3.2.15](#)

multiple power supply report
 example [1.9.32](#)

multiplied_by attribute [2.1.4](#)

N

name mapping
 report_lib vhdl_name [2.1.2](#)

naming a technology library group [1.4](#)

n-channel open drain [3.1.2](#)

negative_unate value, of timing_sense [3.2.15](#)

negative-edge-triggered devices, see falling-edge-triggered devices [2.1.4](#)

negative timing constraints [2.1.2](#)

next_state attribute
 in ff_bank group [2.1.4](#) [2.1.4](#)
 in ff group [2.1.4](#)

nextstate_type attribute [3.1.2](#)

noise_immunity_above_high group [3.2.15](#)

noise_immunity_below_low group [3.2.15](#)

noise_immunity_high group [3.2.15](#)

noise_immunity_low group [3.2.15](#)

noise_lut_template group [1.9.22](#)

nom_calc_mode attribute [1.6.18](#)

nom_temperature attribute [1.6.20](#)

nom_voltage attribute [1.6.21](#)

non_unate value, of timing_sense [3.2.15](#)

num_blockrams attribute [1.9.27](#)

num_cols attribute [1.9.27](#)

num_ffs attribute [1.9.27](#)

num_luts attribute [1.9.27](#)

num_rows attribute [1.9.27](#)

O

open_source pin [3.1.2](#)

operating_conditions group [1.9.24](#)

 effect on input voltage groups [1.9.16](#)

 effect on output voltage groups [1.9.26](#)

operators

 precedence of [2.1.4](#) [3.2.8](#)

operators, valid [2.1.4](#)

orders attribute [1.9.29](#) [3.2.13](#) [3.2.13](#) [3.2.15](#) [3.2.15](#) [3.2.15](#) [3.2.15](#) [3.2.15](#)

 in lower group [3.2.13](#)

out_put_rise group [3.2.1](#)

output_current_fall group [3.2.15](#)

output_current_rise group [3.2.15](#)

output_current_template group [1.9.25](#)

output_fall group [3.2.1](#)

output_signal_level attribute [3.1.2](#)

output_switching_condition attribute [2.1.4](#)

output_threshold_pct_fall attribute [1.6.22](#)

output_threshold_pct_rise attribute [1.6.23](#)

output_voltage, variables [1.9.26](#)

output_voltage group [1.9.26](#)

P

pad_cell attribute [2.1.2](#)

pad_driver_sites [1.8.4](#)

pad_input_driver_sites [1.8.4](#)

pad_output_driver_sites [1.8.4](#)

pad_slots [1.8.4](#)

pad_type attribute [2.1.2](#)

pad cells

 pad_cell attribute [2.1.2](#)

 pad_type attribute [2.1.2](#)

 power_cell_type attribute [2.1.2](#)

pads

 input voltage levels [1.9.16](#)

 output voltage levels [1.9.16](#) [1.9.26](#) [1.9.26](#)

 slew-rate control [3.1.2](#)

pad slots, defining number of [1.8.4](#)

parallel single-bit sequential cells [2.1.4](#)

part group [1.9.27](#)

path tracing

 defining multiple paths [3.2.15](#)

p-channel open drain [3.1.2](#)

pg_current_template group [1.9.28](#)

pg_pin group [2.1.4](#)

pg_type attribute [2.1.4](#)

phase-locked loop cells [2.1.2](#)

physical_connection attribute [2.1.4](#)

physical time unit in library [1.6.37](#)

piece_define attribute [1.8.7](#)

piece_type attribute [1.6.24](#)

pin_capacitance group [3.2.13](#)

pin_count attribute [1.9.27](#)

pin_equal attribute [2.1.3](#)

pin_func_type attribute [3.1.2](#)

pin_opposite attribute [2.1.3](#)

pin default attributes [1.7](#)

pin group

bit_width attribute [3.1.2](#)

capacitance attribute [3.1.2](#)

cell_degradation group [3.2.15](#)

clock_gate_clock_pin attribute [3.1.2](#)

clock_gate_enable_pin attribute [3.1.2](#)

clock_gate_obs_pin attribute [3.1.2](#)

clock_gate_out_pin attribute [3.1.2](#)

clock_gate_test_pin attribute [3.1.2](#)

clock attribute [3.1.2](#)

coefs attribute [3.2.13](#) [3.2.15](#)

complementary_pin attribute [3.1.2](#)

connection_class attribute [3.1.2](#)

direction attribute [3.1.2](#)

dont_fault attribute [3.1.2](#)

drive_current attribute [3.1.2](#)

driver_type attribute [3.1.2](#)

examples, CMOS [3.1.1](#)

fall_capacitance attribute [3.1.2](#)

fall_current_slope_after_threshold attribute [3.1.2](#)

fall_current_slope_before_threshold attribute [3.1.2](#)

fall_time_after_threshold attribute [3.1.2](#)

fall_time_before_threshold attribute [3.1.2](#)

fanout_load attribute [3.1.2](#)

fault_model attribute [3.1.2](#)

function attribute [3.1.2](#)

hysteresis attribute [3.1.2](#)

in bundle group [2.1.4](#) [2.1.4](#)

in bus group [2.1.4](#)

input_map attribute [3.1.2](#)

input_signal_level attribute [3.1.2](#)

input_voltage attribute [3.1.2](#)

internal_node attribute [3.1.2](#)

internal_power group [3.2.8](#)

equal_or_opposite_output attribute [3.2.8](#)

fall_power group [3.2.8](#)

falling_together_group attribute [3.2.8](#)

power_level attribute [3.2.8](#)

power group [3.2.8](#)

related_pin attribute [3.2.8](#)

rise_power attribute [3.2.8](#)

rising_together_group attribute [3.2.8](#)

switching_interval attribute [3.2.8](#)

switching_together_group attribute [3.2.8](#)

when attribute [3.2.8](#)

in test_cell group [2.1.4](#)

direction attribute [2.1.4](#)
inverted_output attribute [3.1.2](#)
is_pad attribute [3.1.2](#)
isolation_cell_enable_pin attribute [3.1.2](#)
level_shifter_enable_pin attribute [3.1.2](#)
map_to_logic attribute [3.1.2](#)
max_capacitance attribute [3.1.2](#)
max_fanout attribute [3.1.2](#)
max_transition attribute [3.1.2](#)
min_capacitance attribute [3.1.2](#)
min_fanout attribute [3.1.2](#)
min_period attribute [3.1.2](#)
min_pulse_width_high attribute [3.1.2](#)
min_pulse_width_low attribute [3.1.2](#)
min_pulse_width group [3.2.11](#)
minimum_period group [3.2.12](#)
multicell_pad_pin attribute [3.1.2](#)
nextstate_type attribute [3.1.2](#)
orders attribute [1.9.29](#) [3.2.13](#) [3.2.15](#) [3.2.15](#)
output_signal_level attribute [3.1.2](#)
output_voltage attribute [3.1.2](#)
pin_func_type attribute [3.1.2](#)
prefer_tied attribute [3.1.2](#)
primary_output attribute [3.1.2](#)
pulling_current attribute [3.1.2](#)
pulling_resistance attribute [3.1.2](#)
pulse_clock attribute [3.1.2](#)
related_bus_pins attribute [3.2.15](#)
related_grond_pin attribute [3.1.2](#)
related_output_pin attribute [3.2.15](#)
related_pin attribute [3.2.15](#)
related_power_pin attribute [3.1.2](#)
rise_capacitance attribute [3.1.2](#)
rise_current_slope_after_threshold attribute [3.1.2](#)
rise_current_slope_before_threshold attribute [3.1.2](#)
rise_time_after_threshold attribute [3.1.2](#)
rise_time_before_threshold attribute [3.1.2](#)
signal_type attribute [3.1.2](#)
slew_control attribute [3.1.2](#)
state_function attribute [3.1.2](#)
test_output_only attribute [3.1.2](#)
three_state attribute [3.1.2](#)
timing group [3.2.15](#)
tlatch group [3.2.16](#)
vhdl_name attribute [3.1.2](#)

pin names

as function arguments [2.1.4](#)
starting with numerals [2.1.4](#) [3.1.2](#)

pins

pin group

poly_layer group [1.6.10](#)

poly_template group [1.9.29](#)

positive_unate value, of timing_sense [3.2.15](#)

positive-edge-triggered devices, see rising-edge-triggered devices [2.1.4](#)

power_cell_type attribute [2.1.2](#)

power_down_function attribute [3.1.2](#)

power_gating_cell attribute [2.1.2](#)

power_gating_pin attribute [3.1.3](#)

power_level attribute

 in internal_power group [3.2.8](#)
 in leakage_power group [2.1.4](#)

power_lut_template group [1.9.30](#)

power_lut_template report, example [1.9.30](#)

power_poly_template group [1.9.31](#)

power_rail attribute

 in operating_conditions group [1.9.24](#)

 in power_supply group [1.9.32](#)

power_supply group [1.9.32](#)

 example [1.9.32](#)

 multiple power supply report [1.9.32](#)

power group [3.2.8](#)

power lookup table template

 example [1.9.30](#)

power units [1.6.17](#)

prefer_tied attribute [3.1.2](#)

preferred_input_pad_voltage attribute [1.6.27](#)

preferred_output_pad_slew_rate_control attribute [1.6.25](#) [1.6.26](#)

preferred_output_pad_voltage attribute [1.6.28](#)

preferred attribute [2.1.2](#)

preset, timing_type value [3.2.15](#)

preset attribute

 in ff_bank group [2.1.4](#)

 in ff group [2.1.4](#)

 in latch_bank group

[2.1.4](#)

 in latch group [2.1.4](#)

primary_output attribute [3.1.2](#)

process attribute [1.9.24](#)

propagated_lut_template group [1.9.33](#)

propagated_noise_height_above_high group [3.2.15](#)

propagated_noise_height_below_low group [3.2.15](#)

propagated_noise_height_high group [3.2.15](#)

propagated_noise_height_low group [3.2.15](#)

propagated_noise_peak_time_ratio_above_high group [3.2.15](#)

propagated_noise_peak_time_ratio_below_low group [3.2.15](#)

propagated_noise_peak_time_ratio_high group [3.2.15](#)

propagated_noise_peak_time_ratio_low group [3.2.15](#)

propagated_noise_width_above_high group [3.2.15](#)

propagated_noise_width_below_low group [3.2.15](#)

propagated_noise_width_high group [3.2.15](#)

propagated_noise_width_low group [3.2.15](#)

propogated_noise_high group [3.2.1](#)

propogated_noise_low group [3.2.1](#)

pulling_current attribute [3.1.2](#)

pulling_resistance_unit attribute [1.6.29](#)

pulling_resistance attribute [3.1.2](#)

pulse_clock attribute [3.1.2](#)

R

rail_connection attribute [2.1.3](#)

range of bus members
in related_pin [3.2.15](#)

receiver_capacitance1_fall group
in receiver_capacitance group [3.2.14](#)
in timing group [3.2.15](#)

receiver_capacitance1_rise group
in receiver_capacitance group [3.2.14](#)
in timing group [3.2.15](#)

receiver_capacitance2_fall group
in receiver_capacitance group [3.2.14](#)
in timing group [3.2.15](#)

receiver_capacitance2_rise group
in receiver_capacitance group [3.2.14](#)
in timing group [3.2.15](#)

receiver_capacitance group [3.2.14](#)

recovery_falling, timing_type value [3.2.15](#)

recovery_rising, timing_type value [3.2.15](#)

reducing file size [1.3](#)

reference_time attribute [2.1.4](#) [2.1.4](#) [3.2.15](#)

registers [2.1.4](#)

related_bias_pin attribute [2.1.4](#)

related_bus_pins attribute [3.2.3](#)
in pin group [3.2.15](#)

related_ground_pin attribute [3.1.2](#)

related_inputs attribute [2.1.4](#)

related_layer attribute [2.1.4](#)

related_outputs attribute [2.1.4](#)

related_output_pin attribute
in pin group [3.2.15](#)

related_outputs attribute [2.1.4](#)

related_pg_pin attribute [2.1.4](#)

related_pin attribute [3.2.3](#) [3.2.8](#)
timing group [3.2.15](#)

related_power_pin attribute [3.1.2](#)

removal_falling, timing_type value [3.2.15](#)

removal_rising, timing_type value [3.2.15](#)

report_lib command

in-place swap mode information [1.6.14](#)
routing layer information [1.8.8](#)

report_lib -power command
multiple power supply report [1.9.32](#)

report_lib -vhdl_name command [2.1.2](#)

resistance attribute [1.9.45](#) [1.9.45](#)

resource_usage attribute [2.1.3](#)

retain_fall_slew group [3.2.15](#)

retain_rise_slew group [3.2.15](#)

retaining_fall group [3.2.15](#)

retaining_rise group [3.2.15](#)

revision attribute [1.6.30](#)

rise_capacitance_range attribute [3.1.3](#)

rise_capacitance_range group [3.2.13](#)
in pin_capacitance group [3.2.13](#)

rise_capacitance attribute [3.1.2](#)

rise_capacitance group [3.2.13](#)

rise_constraint group [3.2.15](#)

rise_current_slope_after_threshold attribute [3.1.2](#)

rise_current_slope_before_threshold attribute [3.1.2](#)

rise_delay_intercept attribute
timing group
CMOS libraries [3.2.15](#)

rise_net_delay group [1.9.34](#)

rise_pin_resistance attribute [3.2.15](#)
timing group
CMOS libraries [3.2.15](#)

rise_power group [3.2.8](#)

rise_propagation group [3.2.15](#) [3.2.15](#)

rise_resistance attribute
timing group [3.2.15](#)

rise_time_after_threshold attribute [3.1.2](#)

rise_time_before_threshold attribute [3.1.2](#)

rise_transition_degradation group [1.9.35](#)

rise_transition group [3.2.15](#)

rising_edge, timing_type value [3.2.15](#)

rising_together_group attribute [3.2.8](#)

rising-edge-triggered-devices [2.1.4](#)

routing_layer group [1.6.10](#)

routing_layers attribute [1.8.8](#)

routing_track group [2.1.4](#)
total_track_area attribute [2.1.4](#)
tracks attribute [2.1.4](#)

S

scaled_cell group [1.9.36](#)

scaling_factors attribute [2.1.2](#)

scaling_factors group [1.9.40](#)

scan-in pin
in pin group
in test cells [2.1.4](#)

scan-in pin, inverted
in pin group
in test cells [2.1.4](#)

scan input on JK flip-flop [2.1.4](#)

scan-out pin [2.1.4](#)
in pin group
in test cells [2.1.4](#)

scan-out pin, inverted
in pin group
in test cells [2.1.4](#)

sdf_cond_end attribute [3.2.15](#)

sdf_cond_start attribute [3.2.15](#)

sdf_cond attribute
in min_pulse_width group [3.2.11](#)
in minimum_period group [3.2.12](#)
in mode_definition group [2.1.4](#)
timing group [3.2.15](#)

sdf_edges attribute
timing group [3.2.15](#)

sequential cells, complex
statetable group [2.1.4](#)

set_dont_touch command [2.1.2](#) [2.1.2](#)

set_map_only command [2.1.2](#)

setup_falling, timing_type value [3.2.15](#)

setup_rising, timing_type value [3.2.15](#)

shifts attribute
in generated_clock group [2.1.4](#)

short attribute
in model group [2.2.1](#)

signal_type attribute [2.1.4](#) [3.1.2](#)

in pin group
in test cells [2.1.4](#)
test_clock [2.1.4](#)
test_scan_clock [2.1.4](#)
test_scan_clock_a [2.1.4](#)
test_scan_clock_b [2.1.4](#)
test_scan_enable [2.1.4](#)
test_scan_enable_inverted [2.1.4](#)
test_scan_in [2.1.4](#)
test_scan_in_inverted [2.1.4](#)
test_scan_out [2.1.4](#)
test_scan_out_inverted [2.1.4](#)
test pin types [2.1.4](#) [3.1.2](#)

simulation attribute [1.6.31](#)

simulation library files
generating [1.6.31](#)

single_bit_degenerate attribute [2.1.2](#)

single-latch LSSD methodology
pin identification [2.1.4](#) [3.1.2](#)

skew_falling, timing_type value [3.2.15](#)

skew_rising, timing_type value [3.2.15](#)

slave clock [2.1.4](#) [2.1.4](#)

slew_control attribute [3.1.2](#)

slew_derate_from_library attribute [1.6.32](#)

slew_lower_threshold_pct_fall attribute [1.6.33](#) [3.1.2](#)

slew_lower_threshold_pct_rise attribute [1.6.34](#) [3.1.2](#)

slew_type attribute [2.1.2](#)

slew_upper_threshold_pct_fall attribute [1.6.35](#) [3.1.2](#)

slew_upper_threshold_pct_rise attribute [1.6.36](#) [3.1.2](#)

slew attribute [1.9.17](#)

slew-rate control [3.1.2](#)

slope_fall attribute [3.2.15](#)

slope_rise attribute [3.2.15](#)

slowest_factor attribute [1.9.42](#)

speed_grade group [1.9.27](#)

SR latch [2.1.4](#)

stage_type attribute [3.2.1](#) [3.2.1](#)

state_function attribute [3.1.2](#)

state declaration

 clocked_on_also attribute [2.1.4](#) [2.1.4](#)
 clocked_on attribute [2.1.4](#)

state-dependent timing

 in timing group
 when attribute [3.2.15](#)

statetable cells

 inverted_output attribute [3.1.2](#)

statetable group [2.1.4](#)

state variables

 for flip-flops [2.1.4](#)
 with function attribute [2.1.4](#)

steady_state_current_high group [3.2.15](#)

steady_state_current_low group [3.2.15](#)

steady_state_current_tristate group [3.2.15](#)

step_level attribute [1.9.27](#)

switching_group group [2.1.4](#) [2.1.4](#) [2.1.4](#)

switching_interval attribute [3.2.8](#)

switching_together_group attribute [3.2.8](#)

T

table attribute

statetable group [2.1.4](#)

tables

lu_table_template group [1.9.19](#)

tdisable attribute [3.2.16](#)

technology attribute [1.8.9](#)

technology library

(see attributes, technology library)

temperature attribute [1.9.24](#)

test_cell group [2.1.4](#)

ff_bank group [2.1.4](#)

ff group [2.1.4](#)

latch group [2.1.4](#) [2.1.4](#)

test_output_only attribute [2.1.4](#) [3.1.2](#)

test pin attributes

function [2.1.4](#)

signal_type [2.1.4](#)

test pins, naming [2.1.4](#)

three_state attribute [3.1.2](#)

in multibit latch registers [2.1.4](#)

three-state cell

timing_sense attribute [3.2.15](#)

threshold_voltage_group attribute [2.1.2](#)

time_unit attribute [1.6.37](#)

timing_model_type attribute [2.1.2](#)

timing_range group [1.9.42](#)

timing_sense attribute [3.2.15](#)

values [3.2.15](#) [3.2.15](#) [3.2.15](#)

timing_type attribute [3.2.15](#)

timing arc

defining identical [3.2.15](#)

half-unate [3.2.15](#)

timing constraints

negative [2.1.2](#)

timing group [1.9.41](#)

clock_gating_flag attribute [3.2.15](#)

default_timing attribute [3.2.15](#)

fall_delay_intercept attribute [3.2.15](#)

fall_pin_resistance attribute [3.2.15](#)

fall_resistance attribute [3.2.15](#)

in pin group [3.2.15](#)

intrinsic_rise attribute [3.2.15](#)

related_bus_pins attribute [3.2.15](#)

related_output_pin attribute [3.2.15](#)

related_pin attribute [3.2.15](#)

retaining_fall group [3.2.15](#)

retaining_rise group [3.2.15](#)
rise_delay_intercept [3.2.15](#)
rise_pin_resistance attribute [3.2.15](#) [3.2.15](#)
rise_resistance attribute [3.2.15](#)
sdf_cond_end attribute [3.2.15](#)
sdf_cond_start attribute [3.2.15](#)
sdf_cond attribute [3.2.15](#)
sdf_edges attribute [3.2.15](#)
slope_fall attribute [3.2.15](#)
slope_rise attribute [3.2.15](#)
steady_state_resistance_above_high attribute [3.2.15](#)
steady_state_resistance_below_low attribute [3.2.15](#)
steady_state_resistance_high attribute [3.2.15](#)
steady_state_resistance_low attribute [3.2.15](#)
tied_off attribute [3.2.15](#)
timing_sense attribute [3.2.15](#)
timing_type attribute [3.2.15](#)
when_end attribute [3.2.15](#)
when_start attribute [3.2.15](#)
when attribute [3.2.15](#)
 conditional timing check [3.2.15](#) [3.2.15](#)
 state-dependent timing [3.2.15](#)

tlatch group
 edge_type attribute [3.2.16](#)
 in pin group [3.2.16](#)
 tdisable attribute [3.2.16](#)

total_track_area attribute [2.1.4](#)

tracks attribute [2.1.4](#)

transition time
 max_transition attribute [3.1.2](#)

tree_type attribute [1.9.24](#)

type group [1.9.43](#) [2.1.4](#)
 base_type attribute [1.9.43](#) [2.1.4](#)
 bit_from attribute [1.9.43](#) [2.1.4](#)
 bit_to attribute [1.9.43](#) [2.1.4](#)
 bit_width attribute [1.9.43](#) [2.1.4](#)
 data_type attribute [1.9.43](#) [2.1.4](#)
 downto attribute [1.9.43](#) [2.1.4](#)
 example [1.9.43](#) [2.1.4](#)

typical_capacitances attribute [2.1.4](#)

U

unate, definition of [3.2.15](#)

units
 capacitive load [1.8.1](#)
 voltage [1.6.38](#)

upper group [3.2.13](#)

use_for_size_only attribute [2.1.2](#)

user_parameters group [1.9.44](#)

user_pg_type attribute [2.1.4](#)

user-defined
 attributes [1.8.3](#)
 groups [1.8.5](#)

V

valid_speed_grade attribute [1.9.27](#)

valid_step_levels attribute [1.9.27](#)

value attribute [2.1.4](#) [2.1.4](#) [2.1.4](#)

values attribute [2.1.4](#) [2.1.4](#)

variable_1 attribute

power_lut_template group [1.9.30](#)

variable_2 attribute

power_lut_template group [1.9.30](#)

variable_3 attribute

power_lut_template group [1.9.30](#)

variable_n_range attribute [1.9.29](#) [1.9.31](#) [3.2.13](#) [3.2.13](#)

variables attribute [1.9.29](#) [1.9.29](#) [1.9.31](#) [1.9.31](#)

VDD, voltage levels

output_voltage group [1.9.26](#)

vector group [2.1.4](#) [3.2.15](#)

vhdl_name attribute [2.1.2](#) [3.1.2](#)

VHDL models

timing group

when_end attribute [3.2.15](#)

when_start attribute [3.2.15](#)

vih voltage range [1.9.16](#)

vil voltage range [1.9.16](#)

vil voltage ratings [3.1.2](#)

vimax voltage range [1.9.16](#)

vimin voltage range [1.9.16](#)

VITAL models

conditional_timing_check [3.2.15](#)

handle_negative_constraint attribute [2.1.2](#)

voltage

input_voltage group [1.9.16](#)

output_voltage group [1.9.26](#)

voltage_map attribute [1.8.10](#)

voltage_name attribute [2.1.4](#)

voltage_unit attribute [1.6.38](#)

voltage attribute [1.9.24](#)

voltage_ranges

input_voltage group [1.9.16](#)

output_voltage group [1.9.26](#)

vol voltage ratings [3.1.2](#)

VSS, voltage levels

output_voltage group [1.9.26](#)

W

when_end attribute
in timing group
in VHDL models [3.2.15](#)

when_start attribute
in timing group
in VHDL models [3.2.15](#)

when attribute [3.2.15](#)
conditional timing check
in VITAL models [3.2.15](#)
in dynamic_current group [2.1.4](#)
in electromigration group
in pin group [3.2.3](#)
in internal_power group
in pin group [3.2.8](#)
in intrinsic_parasitic group [2.1.4](#)
in leakage_current group [2.1.4](#)
in leakage_power group [2.1.4](#)
in min_pulse_width group
in pin group [3.2.11](#)
in minimum_period group
in pin group [3.2.12](#)
in mode_definition group [2.1.4](#)
in timing group [3.2.15](#)

width_coefficient attribute [3.2.4](#)

wire_load_selection group [1.9.46](#)

wire_load_table group [1.9.47](#)

wire_load group [1.9.45](#)

X

x_function attribute [3.1.2](#)